



MONITOR

MTR-90

595-2696-02

Copyright © 1981
ZENITH DATA SYSTEMS
All Rights Reserved
Printed in the United States of America

ZENITH DATA SYSTEMS
SAINT JOSEPH, MICHIGAN 49085

TABLE OF CONTENTS

Introduction	3
Theory of Operation	4
Power Up and Reset	4
General Operations	4
Clock Interrupts	4
MTR-90 Commands	5
B(oot)	5
B(oot) S(D)	6
C(onvert)	7
G(o)	7
I(n)	7
O(ut)	8
P(rogram Counter)	8
R(adix)	9
S(ubstitute)	9
T(est Memory)	9
V(iew)	10
Program Execution Control	11
Appendix A MTR-90 Listing	12
Appendix B Octal Definitions	136
Appendix C Hexadecimal Definitions	138
Appendix D SW501 Switch Settings	140
Appendix E CPU Jumpers	141

INTRODUCTION

This Manual describes the functions and operation of the Z-89/90 Monitor Program, MTR-90, which is contained in a read-only memory (ROM) on the Z-89/90 CPU board. Some of the major features of MTR-90 include:

Disk system bootstrap routines.

Memory contents display and alteration.

Program execution control.

Variable radix settings for display addresses and conversion.

Input/output to specified ports.

Memory diagnostic routine.

In addition, by means of a flag byte maintained in read/write memory, MTR-90 can be instructed to bypass some or all of its normal functions. In this manner, a sophisticated user can augment or replace these functions.

THEORY OF OPERATION

This section supplements information in the "Operations" and "Circuit Description" sections of your Z-89/Z-90 Operations Manual. In order to use all of the features of MTR-90, it is necessary to understand the 8080 and Z-80 opcodes and the circuitry of your Z-89/90. This section details the operation of MTR-90. For a listing of the MTR-90 program, see Appendix A.

Power Up and Reset

MTR-90 initializes the Z-89/90 whenever you apply power to or reset the computer. To power up, use the switch on the right rear of the Z-89/90. To reset, simultaneously press the RESET key and the right-hand shift key on the keyboard. When reset, MTR-90 sounds the electronic "bell" and displays the "H:" prompt on the terminal screen.

During the initialization procedure, MTR-90 determines the high limit of continuous RAM. Once MTR-90 has established this high memory limit, the Z-80 stack pointer is set to the value of the upper memory limit. Then MTR-90 enters a loop and awaits a command.

General Operations

When you power up or reset your Z-89/90, MTR-90 responds by clearing the screen and displaying "H:". This "H:" prompt informs you that MTR-90 is ready to respond to commands. When you enter a character, MTR-90 will either accept it, completing a command word, or beep, which signifies an invalid command word or an inability to boot.

The DELETE key kills a partially entered line and causes MTR-90 to return the "H:" prompt. This is useful for correcting typing errors.

Clock Interrupts

The clock interrupt is a crucial element in the operation of the Z-89/90. It is a level one interrupt, and is generated on the Z-89/90 CPU board every two milliseconds. MTR-90 maintains a tick counter called "TICCNT", which counts one tick every 2 milliseconds. Refer to the listing in Appendix A for the location of TICCNT.

Note that MTR-90 uses interrupts, so you should not disable interrupts using the DI instruction for other than very short periods of time. MTR-90 also requires a stack pointer at the top of memory with at least 80 bytes of stack area.

NOTE: In this manual, the symbol Δ means press the space bar and \oplus means press the RETURN key.

MTR-90 COMMANDS

The following section summarizes valid commands to MTR-90. Each command is listed in alphabetical order along with a brief explanation and examples. You need only enter the first letter of these commands — MTR-90 will respond with what is enclosed in parentheses. In most cases, you will need to press RETURN before MTR-90 will respond. Where a command requires numeric input, we have used the hexadecimal, octal, and split octal number bases.

B(oot)

Typing B(oot) and pressing RETURN initiates boot from drive 0 of the disk drives which have been configured for primary boot using SW501 switch 4 (see Appendix D). This command may optionally be followed by a unit number which specifies a drive other than drive zero. The unit number may be optionally followed by a command string which begins with a colon. The command string is currently used only by those Heath/Zenith operating systems which support the H/Z-67 Winchester disk subsystem. For more detailed information about how MTR-90 accomplishes bootstrap, see Appendix A.

If the boot fails, the computer will display a question mark, beep, and display the H: again. The possible causes for a boot failure include:

1. The boot device is not activated within 15 seconds.
2. The DELETE key is pressed during boot.
3. Switch SW501 is not set properly.
4. A disk error occurs.

The DELETE Key cancels the B(oot) command and repeats the H: prompt, unless boot has already begun, in which case the system displays the message "?Boot Error".

EXAMPLE 1: Boot from unit zero of the primary boot drives.

H: B(oot) 

EXAMPLE 2: Boot from unit 2 of the primary boot drives.

H: B(oot)2 

EXAMPLE 3: Boot from primary boot Z-67 unit 2, passing the command line "HDOS;1" to the secondary Z-67 boot routine.

H: B(oot)2:HDOS;1 

B(oot) S(D)

The B(oot) S(D) command initiates boot from unit zero of the drives which have been configured using SW501 switch 4 as secondary boot drives (see Appendix D). This command may optionally be followed by a unit number which specifies a drive other than drive zero. The unit number may be optionally followed by a command string which begins with a colon. The command string is currently used only by those Heath/Zenith operating systems which support the H/Z-67 Winchester disk subsystem.

If the boot fails, the computer will display a question mark, beep, and display the H: again. The possible causes for a boot failure are:

1. The boot device is not activated within 15 seconds.
2. The DELETE key is pressed during boot.
3. Switch SW501 is not set properly.
4. A disk error occurs.

The DELETE key cancels the B(oot) S(D) command and repeats the H: prompt, unless boot has already begun, in which case the system prints the message "?Boot Error".

EXAMPLE 1: Boot from secondary boot drives, unit zero.

H: B(oot) S(D) 

EXAMPLE 2: Boot from unit 2 of the secondary boot drives.

H: B(oot) S(D)2 

EXAMPLE 3: Boot from secondary boot Z-67 unit 2, passing the command line "HDOS;1" to the Z-67 boot routine.

```
H: B(oot) S(D)2:HDOS;1 @@
```

C(onvert)

The C(onvert) command converts a sixteen-bit number specified in the opposite radix to the current radix. To set the current radix, see the R(adix) command on Page 9.

EXAMPLE: Convert FFFF hex to split octal, where octal is the current radix.

```
H: (C(onvert)FFFF @@  
377377  
H:
```

G(o)

The G(o) command initiates a user program, beginning at the address specified in the current radix as an argument to the G(o) command. If no argument is supplied with the G(o) command, then execution begins at the address contained in the program counter.

EXAMPLE: Go to address 40200 octal.

```
H: G(o)40200 @@
```

I(n)

I(n) inputs a number from the port specified as an argument to the I(n) command. The port number must be specified in the current radix.

EXAMPLE: Input data from port 177 octal, where octal is the current radix.

```
H: I(n)177 @@  
370  
H:
```

O(ut)

The O(ut) command outputs the specified data to the specified port. The first number is the port, and the second the data. Both values should be expressed in the current radix, and should be separated by a comma.

EXAMPLE: Send FF out port A7, where hex is the current radix.

```
H: O(ut)A7,FF  ↵
```

P(program Counter)

The P(program Counter) command sets the current address in the program counter. This command is used to specify the object of the G(o) command. The address specified should be expressed in the current radix.

Simply typing P and RETURN causes the system to display the current contents of the program counter and then to await a new value. Typing P followed by a value sets the PC to that value. Typing P and RETURN, then pressing RETURN again without entering a value terminates the command and does not alter the PC.

EXAMPLE 1: Set the program counter to 100 hex, where the current radix is hexadecimal.

```
H: P(program Counter)  100  ↵
H:
```

EXAMPLE 2: Display the contents of the program counter without altering its contents.

```
H: P(program Counter)  ↵
FFFF  ↵
H:
```

EXAMPLE 3: Set the program counter to 40100 octal after examining the current value, where the current radix is octal.

```
H: P(program Counter)  ↵
377377 40100
H:
```

Note that the operator entered the 40100 in this example.

R(adix)

The R(adix) command sets the current working radix for all other commands.

Valid arguments to radix are O(ctal) and H(exadecimal). The default current radix on power up is octal. Typing R and RETURN with no argument displays the current radix.

EXAMPLE: Set the current radix to hexadecimal and then check it.

```
H: R(adix) H(exadecimal)
H: R(adix) @
Hexadecimal
H:
```

S(ubstitute)

The substitute command can be used to examine or alter the contents of a memory location. The argument to S(ubstitute) is the first address to be examined (and optionally changed). When the starting address has been entered and terminated by pressing RETURN, the system displays address/value pairs. To replace the old value with a new one, type a new value, then a space. To proceed to the next memory location, type a space without entering anything else. To examine a previously displayed memory location, type a hyphen. To terminate, press RETURN.

EXAMPLE: Modify address 40100 octal, where octal is the current radix, then check the memory location.

```
H: S(ubstitute) 40100 @
40100 000 377 △ [operator types 377 and a space]
40101 000 -      [operator types a hyphen]
40100 377 @      [operator presses RETURN]
H:
```

T(est Memory)

The T(est Memory) command initiates the RAM memory test. The test references memory locations in the current radix. Error messages report the addresses of any bad memory locations.

V(iew)

The V(iew) command displays the contents of blocks of memory on the screen in the current radix and in ASCII. Non-printable characters appear as a graphics dot. Characters with the high order (parity) bit set appear in reverse video. The display begins at the first address specified, and continues through the second address. Starting and ending addresses should be separated with a comma.

If no starting or ending address is given, or if an address of zero is specified as the starting or ending address, the display begins at zero. V(iew) displays 128 bytes of data in octal if the current radix is octal, or 256 bytes in hexadecimal if the current radix is hexadecimal. Subsequent V(iew) commands which do not supply an argument display the next 128 or 256 bytes, depending on the setting of the current radix.

EXAMPLE 1: View the contents of memory locations 2280 through 2300 hex, where hexadecimal is the current radix.

```
H: V(iew)2280,2300 @@  
2280 20 21 32 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F !"#$%&'()*+,-./  
2290 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F !"#$%&'()*+,-./  
H:
```

EXAMPLE 2: View the contents of memory locations 0000 through 0128, where the current radix is octal. Then proceed to examine the next 128 bytes.

```
H: V(iew) @@  
000000 303 000 004 041 012 040 303 073 C 0 0 ! 0 C ;  
000010 000 315 132 000 026 000 303 201 0 M Z 0 0 0 C 0  
000020 000 315 132 000 032 303 244 001 0 M Z 0 0 C $ 0
```

```
000170 037 040 361 361 301 321 341 373 0 q q A Q a {  
H: V(iew) @@  
000200 311 052 033 040 043 042 033 040 I * 0 # " 0  
etc.
```

EXAMPLE 3: View memory locations beginning with 2280 hex and continuing for 256 bytes, where hexadecimal is the current radix.

```
H: V(iew) 2280, @@  
2280 4A 4A 4A 4A ... 4A JJJJJJJJJJJJJJJ
```

```
2370 4A 4A 4A 4A ... 4A JJJJJJJJJJJJJJJ
```

PROGRAM EXECUTION CONTROL

When debugging an assembly language program, you can use MTR-90 commands to set breakpoints at, and continue execution from, various points in the program. Debugging can take place at any location above the lower 4K of memory. Be careful not to attempt to debug a program in the lower 4K of memory, as this area is occupied by MTR-90.

To set a breakpoint, use the S(ubstitute) command and put an HLT (hexadecimal 76, octal 166) instruction wherever you want the program to stop.

When your program reaches the breakpoint HLT instruction, it will return control to MTR-90 which will display an "H", then advance to a new line and display "H:". You can then use any MTR-90 command.

To continue your program, first restore the byte in the location into which you placed the breakpoint HLT. Since the computer had to execute the HLT instruction, the PC will point one beyond where you placed the HLT. To continue, decrement the PC value by one. Do this by entering the P(rogram Counter) command and pressing RETURN. When MTR-90 has displayed the current value of the PC, subtract one from that value, then enter the result into the PC.

You can alternatively use the G(o) command to start the program from whatever address you prefer, including from the location where you put the HLT.

Note that if the program which you are debugging uses keyboard interrupts, your program may contend with MTR-90 for console input. Your program should see every character input because the program receives the input via interrupts. But if the MTR-90 checks the keyboard for input after your program, the MTR-90 will not receive the input and no characters will be displayed on the screen. In other words, the fact that your keyboard input does not appear on the screen during program debugging using breakpoints does not mean that your program is at fault.

Appendix A

MTR-90 Listing

This appendix contains a listing of MTR-90. This program contains control routines for primitive keyboard input and screen output. MTR-90 needs available RAM in locations 2000H (040 000 octal) to 203FH (40 077 octal) and from 2150H (41 120 octal) to 2155 (41 125 octal). MTR-90 also needs 80 bytes of stack area in high memory.

000.001

1 .DEBUG EQU 1
2

ASSEMBLE FOR DEBUG

6 *** MTR90 - H/Z-89 MONITOR ISSUE 09.02.01
7 *
8 * MTR89 IS A MODIFICATION OF MTR88 BY REX CHEN IN MAY, 1980.
9 * MTR89 IS IDENTICAL TO THE MTR88 IN THAT ALL ENTRY POINTS TO
10 * THE CURRENT ROUTINES REMAIN UNCHANGED AND ALL ROUTINES
11 * REMAIN UNALTERED WITH THE FOLLOWING EXCEPTIONS:
12 *
13 * (1). "TYPE SPACES TO DETERMINE BAUD RATE" MESSAGE IS REMOVED.
14 * (2). THE BOOTSTRAP FOR THE Z-47 IS INSTALLED.
15 * (3). 15 SECONDS TIME OUT FOR Z-87, OR H-17 AND Z-47 IS INSERTED.
16 * (4). <DELETE> KEY SERVES AS AN ABORT-BOOT KEY.
17 * (5). ALLOWS BOOT FROM SELECT DEVICE AND UNIT.
18 *
19 * MTR90 IS A MODIFICATION OF MTR89 TO ALLOW BOOTING FROM
20 * THE H67, H37, AND 1 FUTURE DEVICE. ALSO THE H47 CODE WAS
21 * CHANGED, AND HEXIDECIMAL ROUTINES WERE ADDED.
22 * SEVERAL NEW "CONVENIENCE" COMMANDS WERE ADDED, THANKS TO
23 * THE ADDITION OF THE EXTRA 2K SPACE.
24 *
25 * MTR90-1 Employs a software fix for a hardware deficiency in disk
26 * drives. It seems that a disk drive head may go into the negative
27 * track area (-1, -2, ...) and not know it, so all disk drivers
28 * have been modified to step the head in and then issuing a second
29 * restore command. This can be taken care of in the hardware, but
30 * people are opposed to adjusting hardware properly.
31 *
32 * MTR88 IS AN ADAPTATION OF PAM/8 ORIGINALLY WRITTEN FOR THE
33 * HEATH H8 COMPUTER BY J. G. LETWIN IN 1976 AND MODIFIED BY
34 * R. N. BORCHARDT IN 1979 FOR USE IN THE HEATH H88/H89
35 * COMPUTERS.
36 *
37 * MTR88 PROVIDES COMPATABILITY WITH PAM/8 SUCH THAT ALL ROUTINES
38 * HAVE RETAINED PREVIOUSLY DESCRIBED ENTRY POINTS AND ENTRY AND
39 * EXIT CONDITIONS. ROUTINES WHICH ARE NOT APPLICABLE SUCH AS
40 * THOSE PERTAINING TO THE FRONT PANEL DISPLAY HAVE BEEN DELETED.
41 *
42 * COPYRIGHT 05/1976, WINTEK CORPORATION
43 * 902 N. 9TH ST.
44 * LAFAYETTE, IND.
45 *
46 * COPYRIGHT 01/1979, HEATH COMPANY
47 * BENTON HARBOR, MI.
48 *
49 * COPYRIGHT 05/1980, ZENITH DATA SYSTEMS INC.
50 * ST. JOSEPH, MI.

53 *** MTR88 - H88/H89 MONITOR.
54 *
55 * THIS PROGRAM RESIDES (IN ROM) IN THE LOW 2048 BYTES OF THE HEATH
56 * H88/H89 COMPUTERS.

58 *** INTERRUPTS.
59 *
60 * MTR88 IS THE PRIMARY PROCESSOR FOR ALL INTERRUPTS.
61 * THEY ARE PROCESSED AS FOLLOWS:
62 *
63 * RST USE
64 *
65 * 0 MASTER CLEAR. (NEVER USED FOR I/O OR RST)
66 *
67 * 1 CLOCK INTERRUPT. NORMALLY TAKEN BY MTR88,
68 * SETTING BIT *UD.CLK* IN BYTE *.MFLAG* ALLOWS
69 * USER PROCESSING (VIA A JUMP THROUGH *UIVEC*).
70 * UPON ENTRY OF THE USER ROUTINE, THE STACK
71 * CONTAINS:
72 * (STACK+0) = RETURN ADDRESS (TO MTR88)
73 * (STACK+2) = (STACKPTR+14)
74 * (STACK+4) = (AF)
75 * (STACK+6) = (BC)
76 * (STACK+8) = (DE)
77 * (STACK+10) = (HL)
78 * (STACK+12) = (PC)
79 * THE USER'S ROUTINE SHOULD RETURN TO MTR88 VIA
80 * A *RET* WITHOUT ENABLING INTERRUPTS.
81 *
82 * 2 SINGLE STEP INTERRUPTS RECEIVED WHEN IN
83 * USER MODE CAUSES A JUMP THROUGH *UIVEC*+3.
84 * STACK UPON USER ROUTINE ENTRY:
85 * (STACK+0) = (STACKPTR+12)
86 * (STACK+2) = (AF)
87 * (STACK+4) = (BC)
88 * (STACK+6) = (DE)
89 * (STACK+8) = (HL)
90 * (STACK+10) = (PC)
91 * THE USER'S ROUTINE SHOULD HANDLE IT'S OWN RETURN
92 * FROM THE INTERRUPT.
93 *
94 *
95 * THE FOLLOWING INTERRUPTS ARE VECTORED DIRECTLY THROUGH *UIVEC*.
96 * THE USEK ROUTINE MUST HAVE SETUP A JUMP IN *UIVEC* BEFORE ANY
97 * OF THESE INTERRUPTS MAY OCCUR.
98 *
99 * 3 I/O 3. CAUSES A DIRECT JUMP THROUGH *UIVEC*+6
100 *
101 * 4 I/O 4. CAUSES A DIRECT JUMP THROUGH *UIVEC*+9
102 *
103 * 5 I/O 5. CAUSES A DIRECT JUMP THROUGH *UIVEC*+12
104 *
105 * 6 I/O 6. CAUSES A DIRECT JUMP THROUGH *UIVEC*+15
106 *

MTR90-1 - H/Z-89 MONITOR
Introduction

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:40:25 17-FEB-82

Page 3

107 * 7 I/O 7. CAUSES A DIRECT JUMP THROUGH *UIYEC**+18

109 ** ASSEMBLY CONSTANTS

000.331	111	MI.EXX	EQU	3310	Z80 EXX INSTRUCTION
000.000	112				
	113	XTEXT		MTR88	DEFINE MTR88 OLD EQUATES

MTR90-1 - H/Z-89 MONITOR
EQUATES FOR MTR88

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 4

10:40:26 17-FEB-82

116X ** IO PORTS

117X
 118X *** ALL REFERENCES TO THE H8 FRONT PANEL PORTS ARE TRAPPED BY THE
 119X * Z80 NMI OF THE H88/H89. OP.CTL WILL STILL PERFORM AS IN AN H8
 120X * IN RESPECT TO THE CLOCK AND SINGLE STEP CONTROL. FOR MORE
 121X * INFORMATION SEE THE NMI ROUTINE.
 122X

000.360	123X IP.PAD EQU	360Q	PAD INPUT PORT
000.360	124X OP.CTL EQU	360Q	CONTROL OUTPUT PORT
000.360	125X OP.DIG EQU	360Q	DIGIT SELECT OUTPUT PORT
000.361	126X OP.SEG EQU	361Q	SEGMENT SELECT OUTPUT PORT
	127X		
	128X * H88/H89 CONTROL PORT		
000.362	129X H88.CTL EQU	362Q	H88/H89 PORT FOR THE CLOCK AND SINGLE STEP
000.002	130X H888.CK EQU	00000010B	2MS CLOCK ENABLE/DISABLE
000.001	131X H888.SS EQU	00000001B	SINGLE STEP ENABLE/DISABLE
132X			
000.362	133X H88.SH EQU	362Q	8 POSITION DIP SWITCH
000.200	134X H885.AT EQU	10000000B	AUTO BOOT SWITCH
000.100	135X H885.BR EQU	01000000B	BAUD RATE SWITCH
000.040	136X H885.M EQU	00100000B	MEMORY TEST/NORMAL OPERATION SWITCH
000.020	137X H885.DV EQU	00010000B	=0, BOOT FROM DEVICE AT 174-177Q =1, BOOT FROM DEVICE AT 170-173Q
138X *			
000.014	139X H885.0 EQU	00001100B	DEVICE AT 170-173Q: 0 = Z37, 1 = Z47
140X *			2 = Z67, 3 = UNKNOWN
000.003	141X H885.4 EQU	00000011B	DEVICE AT 174-177Q: 0 = H17, 1 = Z47
142X *			2 = Z67, 3 = UNKNOWN

144X ** CASSETTE PORTS

145X
 000.371 146X IP.TPC EQU 371Q TAPE CONTROL IN
 000.371 147X OP.TPC EQU 371Q TAPE CONTROL OUT
 000.370 148X IP.TPD EQU 370Q TAPE DATA IN
 000.370 149X OP.TPD EQU 370Q TAPE DATA OUT

151X ** ASCII CHARACTERS

152X
 000.026 153X A.SYN EQU 026Q SYNC CHARACTER
 000.002 154X A.STX EQU 002Q STX CHARACTER
 000.007 155X A.BEL EQU 007Q BELL CHARACTER
 000.010 156X A.BKS EQU 010Q BACKSPACE CHARACTER
 000.012 157X A.LF EQU 012Q LINE FEED CHARACTER
 000.015 158X A.CR EQU 015Q CARRIAGE RETURN CHARACTER
 000.033 159X A.ESC EQU 033Q ESCAPE CHARACTER
 000.177 160X A.DEL EQU 177Q DELETE OR RUBOUT CHARACTER

162X ** FRONT PANEL HARDWARE CONTROL BITS

163X

000.020	164X CB.SSI	EQU	00010000B	SINGLE STEP INTERRUPT
000.040	165X CB.MTL	EQU	00100000B	MONITOR LIGHT
000.100	166X CB.CLI	EQU	01000000B	CLOCK INTERRUPT ENABLE
000.200	167X CB.SPK	EQU	10000000B	SPEAKER ENABLE

169X ** DISPLAY MODE FLAGS (IN *DSPMOD*)

170X

000.000	171X DM.MR	EQU	0	MEMORY READ
000.001	172X DM.MW	EQU	1	MEMORY WRITE
000.002	173X DM.RR	EQU	2	REGISTER READ
000.003	174X DM.RW	EQU	3	REGISTER WRITE

176X ** MACHINE INSTRUCTIONS

177X

000.166	178X MI.HLT	EQU	01110110B	HALT
000.311	179X MI.RET	EQU	11001001B	RETURN
000.333	180X MI.IN	EQU	11011011B	INPUT
000.323	181X MI.OUT	EQU	11010011B	OUTPUT
000.072	182X MI.LDA	EQU	00111010B	LDA
000.346	183X MI.ANI	EQU	11100110B	ANI
000.021	184X MI.LXID	EQU	00010001B	LXI D
000.303	185X MI.JMP	EQU	11000011B	JMP
000.335	186X MI.LDXA	EQU	11011101B	LD IX, (BYTE A)
000.041	187X MI.LDXB	EQU	00100001B	LD IX, (BYTE B)
000.375	188X MI.LDYA	EQU	11111101B	LD IY, (BYTE A)
000.041	189X MI.LDYB	EQU	00100001B	LD IY, (BYTE B)
000.010	190X MI.EXAF	EQU	00001000B	EX AF,AF'
000.335	191X MI.JIXA	EQU	11011101B	JP (IX) (BYTE A)
000.351	192X MI.JIXB	EQU	11101001B	JP (IX) (BYTE B)
000.375	193X MI.JIYA	EQU	11111101B	JP (IY) (BYTE A)
000.351	194X MI.JIYB	EQU	11101001B	JP (IY) (BYTE B)

196X ** USER OPTION BITS.

197X *

198X * THESE BITS ARE SET IN CELL .MFLAG.

199X

000.200	200X UD.HLT	EQU	10000000B	DISABLE HALT PROCESSING
000.100	201X UD.NFR	EQU	CB.CLI	NO REFRESH FRONT PANEL
000.002	202X UD.DDU	EQU	00000010B	DISABLE DISPLAY UPDATE
000.001	203X UD.CLK	EQU	00000001B	ALLOW PRIVATE INTERRUPT PROCESSING
000.000	204	XTEXT	H17DEF	EQUATES FOR H17 BOOT ROM

				206X ** H17 CONTROL INFORMATION.
000.177	208X DP.DC	EQU	07FH	DISK CONTROL PORT
000.001	210X DF.HD	EQU	00000001B	HOLE DETECT
000.002	211X DF.T0	EQU	00000010B	TRACK 0 DETECT
000.004	212X DF.WP	EQU	00000100B	WRITE PROTECT
000.010	213X DF.SD	EQU	00001000B	SYNC DETECT
000.001	215X DF.WG	EQU	00000001B	WRITE GATE ENABLE
000.002	216X DF.DS0	EQU	00000010B	DRIVE SELECT 0
000.004	217X DF.DS1	EQU	00000100B	DRIVE SELECT 1
000.010	218X DF.DS2	EQU	00001000B	DRIVE SELECT 2
000.020	219X DF.M0	EQU	00010000B	MOTOR ON (BOTH DRIVES)
000.040	220X DF.OI	EQU	00100000B	DIRECTION (0-OUT)
000.100	221X DF.ST	EQU	01000000B	STEP COMMAND (ACTIVE HIGH)
000.200	222X DF.WR	EQU	10000000B	WRITE ENABLE RAM
000.174	228X UP.DP	EQU	07CH	DATA PORT
000.175	229X UP.FC	EQU	07DH	FILL CHARACTER
000.175	230X UP.ST	EQU	07DH	STATUS FLAGS
000.176	231X UP.SC	EQU	07EH	SYN CHARACTER (OUTPUT)
000.176	232X UP.SR	EQU	07EH	SYNC RESET (INPUT)
000.001	234X UF.RDA	EQU	00000001B	RECEIVE DATA AVAILABLE
000.002	235X UF.RDR	EQU	00000010B	RECEIVER OVERRUN
000.004	236X UF.RPE	EQU	00000100B	RECEIVER PARITY ERROR
000.100	237X UF.FCT	EQU	01000000B	FILL CHAR TRANSMITTED
000.200	238X UF.TBM	EQU	10000000B	TRANSMITTER BUFFER EMPTY
000.375	244X C.DSYN	EQU	0FDH	PREFIX SYNC CHARACTER
000.000	245 XTEXT	H37DEF		DEFINE H37 PARAMETERS
000.170	246X **	H37DEF		- H37 DISK CONTROLLER DEFINITIONS
000.170	248X DK.PORT	EQU	170Q	BASE UART PORT
000.172	250X FD.STAT	EQU	DK.PORT+2	STATUS PORT
000.172	251X FD.CMD	EQU	DK.PORT+2	COMMAND PORT
000.173	252X FD.TRK	EQU	DK.PORT+3	TRACK REGISTER
000.172	253X FD.SEC	EQU	DK.PORT+2	SECTOR REGISTER
000.173	254X FD.DAT	EQU	DK.PORT+3	DATA PORT
000.170	255X DK.CON	EQU	DK.PORT	CONTROL PORT
000.171	256X DK.INT	EQU	DK.PORT+1	INTERFACE CONTROL
000.000	257X			
000.000	258X **	COMMANDS SENT TO FD.CMD		
000.000	259X			
000.020	260X FDC.RST	EQU	00000008	RESTORE
000.020	261X FDC.SEK	EQU	00010000B	SEEK TRACK IN FD.TRK

000.040	262X FDC.STP EQU	00100000B	STEP IN SAME DIR AS LAST
000.100	263X FDC.STI EQU	01000000B	STEP IN
000.140	264X FDC.STO EQU	01100000B	STEP OUT
	265X		
000.200	266X FDC.RDS EQU	10000000B	READ SECTOR
000.240	267X FDC.WTS EQU	10100000B	WRITE SECTOR
	268X		
000.300	269X FDC.RDA EQU	11000000B	READ ADDRESS
000.340	270X FDC.RDT EQU	11100000B	READ TRACK
000.360	271X FDC.WTT EQU	11110000B	WRITE TRACK
	272X		
000.320	273X FDC.FI EQU	11010000B	FORCE INTERRUPT
	274X		
	275X **	OPTIONS FOR FDC.RST THRU FDC.STO	
	276X		
000.020	277X FDF.UTR EQU	00010000B	UPDATE TRACK REGISTER
000.010	278X FDF.HLB EQU	00001000B	LOAD HEAD AT BEGINING
000.004	279X FDF.VRF EQU	00000100B	VERIFY DESTINATION
	280X		
000.000	281X FDF.S6 EQU	00000000B	STEP 6 MS
000.001	282X FDF.S12 EQU	00000001B	STEP 12 MS
000.002	283X FDF.S20 EQU	00000010B	STEP 20 MS
000.003	284X FDF.S30 EQU	00000011B	STEP 30 MS
	285X		
	286X **	OPTIONS FOR FDC.RDS THRU FDC.WTT	
	287X		
000.020	288X FDF.MRF EQU	00010000B	MULTY RECORD FLAG
000.010	289X FDF.SLF EQU	00001000B	SECTOR LENGTH SHIFT RIGHT
000.004	290X FDF.DLF EQU	00000100B	15 (30) MS DELAY
000.002	291X FDF.SSI EQU	00000010B	SELECT SIDE 1
000.001	292X FDF.DDM EQU	00000001B	DELETED DATA MARK
	293X		
	294X **	STATUS BIT DEFINITIONS	
	295X		
000.200	296X FDS.NRD EQU	10000000B	NOT READY
000.100	297X FDS.WPV EQU	01000000B	WRITE PROTECT
000.040	298X FDS.HLD EQU	00100000B	HEAD IS LOADED
000.040	299X FDS.RTE EQU	00100000B	RECORD TYPE
000.040	300X FDS.WTF EQU	00100000B	WRITE FAULT
000.020	301X FDS.SEK EQU	00010000B	SEEK ERROR
000.020	302X FDS.RNF EQU	00010000B	RECORD NOT FOUND
000.010	303X FDS.CRC EQU	00001000B	CRC ERROR
000.004	304X FDS.TKO EQU	00000100B	OVER TRACK ZERO
000.004	305X FDS.LDT EQU	00000100B	LOST DATA
000.002	306X FDS.IND EQU	00000010B	INDEXZ PULSE
000.002	307X FDS.DRQ EQU	00000010B	DATA REQUEST
000.001	308X FDS.BSY EQU	00000001B	BUSY
	309X		
	310X *	BITS SET IN DK.CON	
	311X		
000.001	312X CON.EI EQU	00000001B	ENABLE INT-REQ
000.002	313X CON.DRQ EQU	00000010B	ENABLE DRQ INTERRUPT
000.004	314X CON.MFM EQU	00000100B	SET MFM RECORDING
000.010	315X CON.MD EQU	00001000B	ALL MOTORS ON
000.020	316X CON.DSO EQU	00010000B	DRIVE 0
000.040	317X CON.DS1 EQU	00100000B	DRIVE 1

MTR90-1 - H/Z-89 MONITOR
EQUATES FOR MTR88

#09.02.01.

H17

Unix H8ASM V1.4.1 5-Jul-80
10:40:31 17-FEB-82

Page 8

000.100	318X CON.DS2	EQU	010000008	DRIVE 2
000.200	319X CON.DS3	EQU	100000008	DRIVE 3
	320X			
	321X			
	322X *		Bits set to select alternate registers	
	323X			
000.000	324X CON.CD	EQU	00000000B	SELECT COMMAND/DATA
000.001	325X CON.ST	EQU	00000001B	SELECT SECTOR/TRACK
000.000	326	XTEXT	Z47DEF	DEFINE Z47 EQUATES

328X ** H47DEF - H47 Constant Definitions
329X *

331X * 280 Instructions

332X				
242.355	333X M.INI	EQU	10100010B*256+11101101B	INI Instruction
243.355	334X M.OUTI	EQU	10100011B*256+11101101B	OUTI Instructions

336X ** DISK INTERFACE CONSTANTS

337X *				
338X				
000.170	339X D.STA	EQU	170Q	INTERFACE STATUS PORT
000.171	340X D.DAT	EQU	D.STA+1	INTERFACE DATA PORT
	341X			
000.001	342X S.ERR	EQU	00000001B	ERROR BIT
000.040	343X S.DON	EQU	00100000B	DONE
000.100	344X S.IEN	EQU	01000000B	INTERRUPT ENABLE
000.200	345X S.DTR	EQU	10000000B	DATA TRANSFER REQUEST
	346X			
000.002	347X S.SW0	EQU	00000010B	DIP SWITCH 0
000.004	348X S.SW1	EQU	00000100B	DIP SWITCH 1
000.010	349X S.SW2	EQU	00001000B	DIP SWITCH 2
000.020	350X S.SW3	EQU	00010000B	DIP SWITCH 3
	351X			
000.002	352X W.RES	EQU	00000010B	RESET COMMAND

354X ** STATUS BYTE FLAGS

355X *				
356X				
000.200	357X SB.UNR	EQU	10000000B	UNIT NOT READY
000.100	358X SB.WPD	EQU	01000000B	WRITE PROTECTED DRIVE
000.040	359X SB.DLD	EQU	00100000B	DELETED DATA
000.020	360X SB.NRF	EQU	00010000B	NO RECORD FOUND
000.010	361X SB.CRC	EQU	00001000B	CRC ERROR

000.004	362X	SB.LTD	EQU	00000100B	LATE DATA
000.002	363X	SB.ILC	EQU	00000010B	ILLEGAL COMMAND
000.001	364X	SB.BTO	EQU	00000001B	BAD TRACK OVERFLOW

	366X **	AUXILIARY STATUS BYTE FLAGS			
	367X *				
	368X				
000.100	369X	AS.ODD	EQU	01000000B	TRACK 0 DOUBLE DENSITY
000.040	370X	AS.1DD	EQU	00100000B	TRACK 1-76 DOUBLE DENSITY
000.020	371X	AS.S1A	EQU	00010000B	SIDE 1 AVAILABLE
000.003	372X	AS.SLM	EQU	00000001B	SECTOR LENGTH MASK

	374X **	DISK COMMANDS			
	375X *				
	376X				
000.000	377X	ORG	0		
000.000	378X	DD.BOOT	DS	1	BOOT
000.001	379X	DD.RST	DS	1	READ CONTROLLER STATUS
000.002	380X	DD.RAS	DS	1	READ AUX. STATUS
000.003	381X	DD.LSC	DS	1	LOAD SECTOR COUNT
000.004	382X	DD.RAD	DS	1	READ ADDR. OF LAST SECTOR ACCESSED
000.005	383X	DD.REA	DS	1	READ SECTORS
000.006	384X	DD.WRI	DS	1	WRITE SECTORS
000.007	385X	DD.REAB	DS	1	READ SECTORS BUFFERED
000.010	386X	DD.WRIB	DS	1	WRITE SECTORS BUFFERED
000.011	387X	DD.WRD	DS	1	WRITE SECTORS & DELETE
000.012	388X	DD.WRDB	DS	1	WRITE SECTORS BUFFERED & DELETE
000.013	389X	DD.CPY	DS	1	COPY
000.014	390X	DD.FRM0	DS	1	FORMAT IBM SD
000.015	391X	DD.FRM1	DS	1	FORMAT SD
000.016	392X	DD.FRM2	DS	1	FORMAT IBM DD
000.017	393X	DD.FRM3	DS	1	FORMAT DD
000.020	394X	DD.RRDY	DS	1	READ READY

	396X **	Special De-Bug functions			
	397X *				
	398X				
000.020	399X	ORG	010H		
000.020	400X	DD.SPF0	DS	1	SPECIAL FUNCTION 0
000.021	401X	DD.SPF1	DS	1	SPECIAL FUNCTION 1
000.022	402X	DD.SPF2	DS	1	SPECIAL FUNCTION 2
000.023	403X	DD.SPF3	DS	1	SPECIAL FUNCTION 3
000.024	404X	DD.SPF4	DS	1	SPECIAL FUNCTION 4
000.025	405X	DD.SPF5	DS	1	SPECIAL FUNCTION 5

MTR90-1 - H/Z-89 MONITOR
EQUATES FOR MTR88

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 10
10:40:33 17-FEB-82

407X ** Special Heath Functions

408X *

409X

000.200	410X	OKG	080H	
000.200	411X	DD.SDC	DS 1	SET DRIVE CHARACTERISTIC
000.201	412X	DD.ST	DS 1	SEEK TO TRACK
000.202	413X	DD.DS	DS 1	DISK STATUS
000.203	414X	DD.RDL	DS 1	READ LOGICAL
000.204	415X	DD.WTL	DS 1	WRITE LOGICAL
000.205	416X	DD.RDBL	DS 1	READ BUFFERED LOGICAL
000.206	417X	DD.WTBL	DS 1	WRITE BUFFERED LOGICAL
000.207	418X	DD.WTDL	DS 1	WRITE DELETED DATA LOGICAL
000.210	419X	DD.WDLB	DS 1	WRITE BUFFERED DELETED DATA LOGICAL

421X ** USEFUL FLAGS

422X *

423X

000.000	424X	UNT.0	EQU 00000008	UNIT 0
000.040	425X	UNT.1	EQU 00100008	UNIT 1
000.100	426X	UNT.2	EQU 01000008	UNIT 2
000.140	427X	UNT.3	EQU 01100008	UNIT 3
	428X			
000.140	429X	UNT.M	EQU 01100008	Unit mask
	430X			

431X

432X

000.000	433X	SID.0	EQU 00000008	Side: 0
000.200	434X	SID.1	EQU 10000008	Side: 1
	435X			
000.200	436X	SID.M	EQU 10000008	Side Mask
	437X			
	438X			

439X

000.037	440X	SEC.M	EQU 0001111B	Track Mask
	441X			
	442X			

443X

004.000	444X	SSIZ.M	EQU 1024	Maximum Sector Size
	445X			
	446X			

447X *C.256 EQU 256 SECTOR SIZE = 256 BYTES

448X *C.128 EQU 128 SECTOR SIZE

449X *C.26 EQU 26 H67 DEFINITIONS

000.211	450	XTEXT	H67DEF	H67 DEFINITIONS

453X ** H67 Disk Controller Definitions
454X *

456X ** Register addresses

457X *

458X

000.170	459X	BASE	EQU	1700	Controller base address
	460X				
000.000	461X	RI.DAT	EQU	0	Data In/Out (Read/Write)
000.001	462X	RI.CON	EQU	1	Control (Write Only)
000.001	463X	RI.BST	EQU	1	Bus Status (Read Only)

465X * Control Register Definition

466X

000.100	467X	BC.SEL	EQU	010000008	Select and data bit 0
000.040	468X	BC.IE	EQU	001000008	Interrupt Enable
000.020	469X	BC.RST	EQU	000100008	Reset
000.002	470X	BC.EDT	EQU	000000108	Enable Data

472X * Bus Status Register Definition

473X

000.200	474X	BS.REQ	EQU	100000008	Data Transfer Request
000.100	475X	BS.DTD	EQU	010000008	Data Transfer Direction
000.000	476X	BS.IN	EQU	000000008	Data to Host
000.100	477X	BS.OUT	EQU	010000008	Data to Controller
000.040	478X	BS.LMB	EQU	001000008	Last byte in data/command string
000.020	479X	BS.MTY	EQU	000100008	Message type
000.000	480X	BS.DAT	EQU	000000008	Data
000.020	481X	BS.COM	EQU	000100008	Command
000.010	482X	BS.BSY	EQU	000010008	Busy
000.004	483X	BS.INT	EQU	000001008	Interrupt Pending
000.002	484X	BS.PE	EQU	000000108	Parity Error
000.001	485X	BS.HID	EQU	000000018	Hardware Identification

487X * Status Byte Definitions

488X

000.140	489X	ST.LUN	EQU	011000008	Logical Unit
000.034	490X	ST.SPR	EQU	000111008	Spare
000.002	491X	ST.EKR	EQU	000000108	Error
000.001	492X	ST.PER	EQU	000000018	Parity Error

MTR90-1 - H/Z-89 MONITOR #09.02.01.
H67 Disk Controller Definitions

Unix H8ASM V1.4.1 5-Jul-80 Page 12
10:40:36 17-FEB-82

494X ** Commands

495X *

496X

000.340 497X CLASSM EQU 111000008 Class Mask

498X

000.000 499X CLASS0 EQU 000000008 Class 0

000.040 500X CLASS1 EQU 001000008 Class 1

000.300 501X CLASS6 EQU 110000008 Class 6

502X

000.037 503X OPCODM EQU 000111118 Op-code Mask

000.140 504X LUNM EQU 011000008 Logical Unit Mask

000.037 505X LSA.2 EQU 000111118 Logical Sector Address (2)

507X * Class 0 Commands

508X

000.000 509X D.TDR EQU CLASS0+0 Test drive ready

000.001 510X D.REC EQU CLASS0+1 Recalibrate drive

000.002 511X D.RSY EQU CLASS0+2 Request Syndrome

000.003 512X D.RSE EQU CLASS0+3 Request Sense

000.004 513X D.FOR EQU CLASS0+4 Format Drive

000.005 514X D.CTF EQU CLASS0+5 Check track format

000.006 515X D.FT EQU CLASS0+6 Format Track

000.007 516X D.FBS EQU CLASS0+7 Format bad sector

000.010 517X D.REA EQU CLASS0+8 Read

000.011 518X D.WPS EQU CLASS0+9 Write protect the sector

000.012 519X D.WRI EQU CLASS0+10 Write

000.013 520X D.SEK EQU CLASS0+11 Seek

522X * Class 1 Commands

523X

000.040 524X D.CPB EQU CLASS1+0 Copy block

526X * Class 6 Commands

527X

000.300 528X D.FFD EQU CLASS6+0 Format floppy disk

530X * Type 0 error codes (Drive error Codes)

	531X			
000.000	532X T0.MST	EQU	0	No status
000.001	533X T0.MIS	EQU	1	No Index signal
000.002	534X T0.NSC	EQU	2	No seek complete
000.003	535X T0.WFT	EQU	3	Write fault
000.004	536X T0.DNR	EQU	4	Drive not ready
000.005	537X T0.DNS	EQU	5	Drive not selected
000.006	538X T0.MTO	EQU	6	No track zero
000.007	539X T0.MDS	EQU	7	Multi-drive selected

541X * Type 1 error codes (data error codes)

	542X			
000.000	543X T1.ID	EQU	0	ID Read Error
000.001	544X T1.UDE	EQU	1	Uncorrectable data error
000.002	545X T1.IDNF	EQU	2	ID Address Mark not found
000.003	546X T1.DMF	EQU	3	Data Address Mark Not Found
000.004	547X T1.RNF	EQU	4	Record Not Found
000.005	548X T1.SKE	EQU	5	Seek Error
000.006	549X T1.DTE	EQU	6	DMA Time-out Error (not used)
000.007	550X T1.WP	EQU	7	Write protected
000.010	551X T1.CDE	EQU	8	Correctable Data field Error
000.011	552X T1.BBF	EQU	9	Bad Block Found
000.012	553X T1.FE	EQU	10	Format Error

555X * Type 2 Error Codes (Command error codes)

	556X			
000.000	557X T2.ILC	EQU	0	Illegal Command
000.001	558X T2.IDA	EQU	1	Illegal Disk Address
000.002	559X T2.IFN	EQU	2	Illegal Function
000.211	560	XTEXT	H0SEQU	HDOS EQUATES

562X ** HDOS SYSTEM EQUIVALENCES.

563X *

564X

024.000	565X S.GRT0	EQU	24000A	SYSTEM AREA FOR GRT0
025.000	566X S.GRT1	EQU	25000A	SYSTEM AREA FOR GRT1
026.000	567X S.GRT2	EQU	26000A	SYSTEM AREA FOR GRT2
	568X			
030.000	569X ROMBOOT	EQU	30000A	ROM BOOT ENTRY
	570X			
040.100	571X	ORG	40100A	FREE SPACE FROM PAM-8
	572X			
040.100	573X	DS	8	JUMP TO SYSTEM EXIT
040.110	574X D.CON	DS	16	DISK CONSTANTS
040.130	575X SYDD	EQU	*	SYSTEM DISK ENTRY POINT
040.130	576X D.VEC	DS	24*3	SYSTEM ROM ENTRY VECTORS

MTR90-1 - H/Z-89 MONITOR
H67 Disk Controller Definitions

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 14

10:40:43 17-FEB-82

040.240	577X D.RAM	DS	31	SYSTEM ROM WORK AREA
040.277	578X S.VAL	DS	36	SYSTEM VALUES
040.343	579X S.INT	DS	115	SYSTEM INTERNAL WORK AREAS
041.126	580X	DS	16	
041.146	581X S.SOVR	DS	2	STACK OVERFLOW WARNING
041.150	582X	DS	42200A-*	SYSTEM STACK
001.032	583X STACKL	EQU	*-S.SOVR	STACK SIZE
	584X			
042.200	585X STACK	EQU	*	LWA+1 SYSTEM STACK
042.200	586X USERFWA	EQU	*	USER FWA
042.200	587	XTEXT	DIRDEF	

589X ** DIRECTORY ENTRY FORMAT.

590X				
000.000	591X	ORG	0	
	592X			
	593X			
000.377	594X DF.EMP	EQU	377Q	FLAGS ENTRY EMPTY
000.376	595X DF.CLR	EQU	376Q	FLAGS ENTRY EMPTY, REST OF DIR ALSO CLEAR
	596X			
000.000	597X DIR.NAM	DS	8	NAME
000.010	598X DIR.EXT	DS	3	EXTENSION
000.013	599X DIR.PRO	DS	1	PROJECT
000.014	600X DIR.VER	DS	1	VERSION
000.015	601X DIRIDL	EQU	*	FILE IDENTIFICATION LENGTH
	602X			
000.015	603X DIR.CLU	DS	1	CLUSTER FACTOR
000.016	604X DIR.FLG	DS	1	FLAGS
000.017	605X	DS	1	RESERVED
000.020	606X DIR.FGN	DS	1	FIRST GROUP NUMBER
000.021	607X DIR.LGN	DS	1	LAST GROUP NUMBER
000.022	608X DIR.LSI	DS	1	LAST SECTOR INDEX (IN LAST GROUP)
000.023	609X DIR.CRD	DS	2	CREATION DATE
000.025	610X DIR.ALD	DS	2	LAST ALTERATION DATE
	611X			
000.027	612X DIRELEN	EQU	*	DIRECTORY ENTRY LENGTH
000.027	613	XTEXT	ESINT	

615X ** S.INT - SYSTEM INTERNAL WORKAREA DEFINITIONS.

616X *				
617X *	THESE CELLS ARE REFERENCED BY OVERLAYS AND MAIN CODE, AND			
618X *	MUST THEREFORE RESIDE IN FIXED LOW MEMORY.			
	619X			
	620X			
040.343	621X	ORG	S.INT	
	622X			
	623X **	CONSOLE STATUS FLAGS		
	624X			
040.343	625X S.CDB	DS	1	CONSOLE DESCRIPTOR BYTE
000.000	626X CDB.H85	EQU	00000000B	
000.001	627X CDB.H84	EQU	00000001B	=0 IF H8-5, =1 IF H8-4

040.344	628X S.BAUD DS	2	[0-14] H8-4 BAUD RATE, =0 IF H8-5 [15] =1 IF 2 STOP BITS
	629X *		
	630X		
	631X ** TABLE ADDRESS WORDS		
	632X		
040.346	633X S.DLINK DS	2	ADDRESS OF DATA IN HDOS CODE
040.350	634X S.DFWA DS	2	FWA OVERLAY TABLE
040.352	635X S.CFWA DS	2	FHA CHANNEL TABLE
040.354	636X S.DFWA DS	2	FHA DEVICE TABLE
040.356	637X S.RFWA DS	2	FWA RESIDENT HDOS CODE
	638X		
	639X ** DEVICE DRIVER DELAYED LOAD FLAGS		
	640X		
040.360	641X S.DDLDA DS	2	DRIVER LOAD ADDRESS (HIGH BYTE=0 IF NO LOAD PENDING)
040.362	642X S.DDLEN DS	2	CODE LENGTH IN BYTES
040.364	643X S.DDGRP DS	1	GROUP NUMBER FOR DRIVER
040.365	644X DS	1	HOLD PLACE
	645X *S.DDSEC DS	2	SECTOR NUMBER FOR DRIVER (* OBSOLETE ! *)
040.366	646X S.DDDTA DS	2	DEVICE'S ADDRESS IN DEVLIST +DEV.RES
040.370	647X S.DDOPC DS	1	OPEN OPCODE PENDING
	648X		
	649X ** OVERLAY MANAGEMENT FLAGS		
	650X		
000.001	651X OVL.IN EQU	00000001B	IN MEMORY
000.002	652X OVL.RES EQU	00000010B	PERMANENTLY RESIDENT
000.014	653X OVL.NUM EQU	00001100B	OVERLAY NUMBER MASK
000.200	654X OVL.UCS EQU	10000000B	USER CODE SWAPPED FOR OVERLAY
	655X		
040.371	656X S.OVLFL DS	1	OVERLAY FLAG
040.372	657X S.UCSF DS	2	FHA SWAPPED USER CODE
040.374	658X S.UCSL DS	2	LENGTH SWAPPED USER CODE
040.376	659X S.OVLS DS	2	SIZE OF OVERLAY CODE
041.000	660X S.OVLE DS	2	ENTRY POINT OF OVERLAY CODE
	661X		
041.002	662X S.SSM DS	2	SWAP AREA SECTOR NUMBER
041.004	663X S.OSN DS	2	OVERLAY SECTOR NUMBER
	664X		
	665X * SYSCALL PROCESSING WORK AREAS		
	666X		
041.006	667X S.CACC DS	1	(ACC) UPON SYSCALL
041.007	668X S.CODE DS	1	SYSCALL INDEX IN PROGRESS
	669X		
	670X * JUMPS TO ROUTINES IN RESIDENT HDOS CODE		
	671X		
041.010	672X S.JUMPS DS	0	START OF JUMP VECTORS
041.010	673X S.SDD DS	3	JUMP TO STAND-IN DEVICE DRIVER
041.013	674X S.FASER DS	3	JUMP TO FATERR (FATAL SYSTEM ERROR)
041.016	675X S.DIREA DS	3	JUMP TO DIREAD (DISK FILE READ)
041.021	676X S.FCI DS	3	JUMP TO FCI (FETCH CHANNEL INFO)
041.024	677X S.SCI DS	3	JUMP TO SCI (STORE CHANNEL INFO)
041.027	678X S.GUP DS	3	JUMP TO GUP (GET UNIT POINTER)
	679X		
041.032	680X S.MOUNT DS	1	<>0 IF THE SYSTEM DISK IS MOUNTED
041.033	681X S.DCS DS	1	DEFAULT CLUSTER SIZE-1
	682X		
041.034	683X S.BOOTF DS	1	BOOT FLAGS

MTR90-1 - H/Z-89 MONITOR #09.02.01.
H67 Disk Controller Definitions ESINT Unix H8ASM V1.4.1 5-Jul-80 Page 16
10:40:56 17-FEB-82

000.001	684X BOOT.P EQU	000000018	EXECUTE PROLOGUE UPON BOOTUP	
000.002	685X BOOT.SY EQU	000000108	SY: Device Driver loaded	/2.1b/
686X				
687X *	STACK VALUE SAVED FOR OVERLAY SYSCALLS			
688X				
041.035	689X S.OVSTK DS	2	VALUE OF SP UPON SYSCALLS USING OVERLAY	
690X				
041.037	691X DS	1	RESERVED	

693X **	ACTIVE I/O AREA.			
694X *				
695X *	THE AIO.XXX AREA CONTAINS INFORMATION ABOUT THE I/O OPERATION			
696X *	CURRENTLY BEING PERFORMED. THE INFORMATION IS OBTAINED FROM			
697X *	THE CHANNEL TABLE, AND WILL BE RESTORED THERE WHEN DONE.			
698X *				
699X *	NORMALLY, THE AIO.XXX INFORMATION WOULD BE OBTAINED DIRECTLY			
700X *	FROM VARIOUS SYSTEM TABLES VIA POINTER REGISTERS. SINCE THE			
701X *	8080 HAS NO GOOD INDEXED ADDRESSING, THE DATA IS MANUALLY			
702X *	COPIED INTO THE AIO.XXX CELLS BEFORE PROCESSING, AND			
703X *	BACKDATED AFTER PROCESSING.			
704X				
041.040	705X AIO.VEC DS	3	JUMP INSTRUCTION	
041.041	706X AIO.DDA EQU	*-2	DEVICE DRIVER ADDRESS	
041.043	707X AIO.FLG DS	1	FLAG BYTE	
041.044	708X AIO.GRT DS	2	ADDRESS OF GROUP RESERV TABLE	
041.046	709X AIO.SPG DS	1	SECTORS PER GROUP	
041.047	710X AIO.CGN DS	1	CURRENT GROUP NUMBER	
041.050	711X AIO.CSI DS	1	CURRENT SECTOR INDEX	
041.051	712X AIO.LGN DS	1	LAST GROUP NUMBER	
041.052	713X AIO.LSI DS	1	LAST SECTOR INDEX	
041.053	714X AIO.DTA DS	2	DEVICE TABLE ADDRESS	
041.055	715X AIO.DES DS	2	DIRECTORY SECTOR	
041.057	716X AIO.DEV DS	2	DEVICE CODE	
041.061	717X AIO.UNI DS	1	UNIT NUMBER (0-9)	
718X				
041.062	719X AIO.DIR DS	DIRELEN	DIRECTORY ENTRY	
720X				
041.111	721X AIO.CNT DS	1	SECTOR COUNT	
041.112	722X AIO.EOM DS	1	END OF MEDIA FLAG	
041.113	723X AIO.EOF DS	1	END OF FILE FLAG	
041.114	724X AIO.TFP DS	2	TEMP FILE POINTERS	
041.116	725X AIO.CHA DS	2	ADDRESS OF CHANNEL BLOCK (IOC.DDA)	

041.120	727X S.BDA DS	1	Boot Device address (Setup by ROM) /80.09.gc/	
041.121	728X S.SCR DS	2	SYSTEM SCRATCH AREA ADDRESS	
041.123	729X DS	3		
000.000	730X ERKNZ	*-41126A		
041.126	731X S.OS1 DS	1	Operating System ID	/2.1b/
041.127	732X S.OS0 DS	1	Operating System Occurrence	/2.1b/
041.130	733X S.OS2 DS	3	Operating System Sector Zero	/2.1b/

041.133

734

XTEXT MISC

MISCELLANEOUS EQUATES FOR H17 BOOT ROM

	737X **	MISCELLANEOUS EQUATES FROM H17 BOOT ROM.		
	738X *	REFER TO H17 BOOT ROM IF MORE INFORMATION DESIRED		
739X				
036.235	740X WHD	EQU	36235A	WAIT FOR HOLE ROUTINE ENTRY POINT
036.271	741X WNH	EQU	36271A	WAIT FOR NO HOLE ROUTINE ENTRY POINT
	742X			
000.130	743X BOOTAL	EQU	130A	NUMBER OF RAM TO CLEAR
037.132	744X BOOTA	EQU	37132A	RAM CLEAR START LOCATION
030.252	745X \$MOVE	EQU	30252A	MOVE DATA ROUTINE
000.037	746X D.RAML	EQU	37Q	
031.212	747X \$ZERO	EQU	31212A	ZERO RAM ROUTINE
040.037	748X .UIVEC	EQU	40037A	USER INTERRUPT VECTOR
034.031	749X CLOCK17	EQU	34031A	Z17 TIMER INTERRUPT HANDLER LOCATION
033.366	750X R.ABORT	EQU	33366A	RESET Z17 ROUTINE LOCATION
034.077	751X R.READ	EQU	34077A	READ Z17 ROUTINE LOCATION
040.206	752X D.SDP	EQU	40206A	SET DEVICE PARAMETER RAM LOCATION
040.166	753X D.SDT	EQU	40166A	SEEK DESIRED TRACK
040.240	754X D.TT	EQU	40240A	TARGET TRACK BYTE
036.073	755X SDP3	EQU	36073A	SET DEVICE PARAMETER ENTRY
034.027	756X EIXIT	EQU	34027A	EI/RET LOCATION
000.012	757X ERPTCNT	EQU	12Q	ERROR COUNT
040.264	758X D.OECNT	EQU	40264A	
041.133	759	XTEXT	U8251	DEFINE 8251 USART BITS

762X ** 8251 USART BIT DEFINITIONS.

763X *

764X

765X ** PORT ADDRESSES

766X

000.000	767X UDR	EQU	0	DATA REGISTER IS EVEN
000.001	768XUSR	EQU	1	STATUS REGISTER IS NEXT
769X				
000.372	770X SC.UART	EQU	3720	CONSOLE USART ADDRESS (IFF 8251)

771X

772X

773X ** MODE INSTRUCTION CONTROL BITS.

774X

000.100	775X UMI.1B	EQU	010000008	1 STOP BIT
000.200	776X UMI.HB	EQU	100000008	1 1/2 STOP BITS
000.300	777X UMI.2B	EQU	110000008	2 STOP BITS
000.040	778X UMI.PE	EQU	001000008	EVEN PARITY
000.020	779X UMI.PA	EQU	000100008	USE PARITY
000.000	780X UMI.L5	EQU	000000008	5 BIT CHARACTERS
000.004	781X UMI.L6	EQU	000001008	6 BIT CHARACTERS
000.010	782X UMI.L7	EQU	000010008	7 BIT CHARACTERS
000.014	783X UMI.L8	EQU	000011008	8 BIT CHARACTERS
000.001	784X UMI.1X	EQU	000000018	CLOCK X 1
000.002	785X UMI.16X	EQU	000000108	CLOCK X 16
000.003	786X UMI.64X	EQU	000000118	CLOCK X 64

787X

788X ** COMMAND INSTRUCTION BITS.

789X

000.100	790X UCI.IR	EQU	010000008	INTERNAL RESET
000.040	791X UCI.R0	EQU	001000008	READER-ON CONTROL FLAG
000.020	792X UCI.ER	EQU	000100008	ERROR RESET
000.004	793X UCI.RE	EQU	000001008	RECEIVE ENABLE
000.002	794X UCI.IE	EQU	000000108	ENABLE INTERRUPTS FLAG
000.001	795X UCI.TE	EQU	000000018	TRANSMIT ENABLE

796X

797X ** STATUS READ COMMAND BITS.

798X

000.040	799X USR.FE	EQU	001000008	FRAMING ERROR
000.020	800X USR.OE	EQU	000100008	OVERRUN ERROR
000.010	801X USR.PE	EQU	000010008	PARITY ERROR
000.004	802X USR.TXE	EQU	000001008	TRANSMITTER EMPTY
000.002	803X USR.RXR	EQU	000000108	RECEIVER READY
000.001	804X USR.TXR	EQU	000000018	TRANSMITTER READY
041.133	805	XTEXT	U8250	DEFINE 8250 ACE BITS

807X ** 8250 UART CONTROL AND BIT DEFINITIONS.

808X

000.350	809X SC.ACE	EQU	3500	SYSTEM CONSOLE PORT IF 8250 ACE
000.156	810X AC.DLY	EQU	110	220 MIL. SEC. DELAY FOR 8250
811X				
000.000	812X UR.RBR	EQU	0	RECEIVER BUFFER REGISTER (READ ONLY)
813X				
000.000	814X UR.THR	EQU	0	TRANSMITTER HOLDING REGISTER (WRITE ONLY)

	815X			
000.000	816X UR.DLL	EQU 0	DIVISOR LATCH (LEAST SIGNIFICANT)	
	817X			
000.001	818X UR.DLM	EQU 1	DIVISOR LATCH (MOST SIGNIFICANT)	
	819X			
000.001	820X UR.IER	EQU 1	INTERRUPT ENABLE REGISTER	
000.001	821X UC.EDA	EQU 00000001B	ENABLE RECEIVED DATA AVAILABLE INTERRUPT	
000.002	822X UC.TRE	EQU 00000010B	ENABLE TRANSMIT HOLD REGISTER EMPTY INTERRUPT	
000.004	823X UC.RSI	EQU 00000100B	ENABLE RECEIVE STATUS INTERRUPT	
000.010	824X UC.MSI	EQU 00001000B	ENABLE MODEM STATUS INTERRUPT	
	825X			
000.002	826X UR.IIR	EQU 2	INTERRUPT IDENTIFICATION REGISTER	
000.001	827X UC.IIP	EQU 00000001B	INVERTED INTERRUPT PENDING (0 MEANS PENDING)	
000.006	828X UC.IID	EQU 00000110B	INTERRUPT ID	
	829X			
000.003	830X UR.LCR	EQU 3	LINE CONTROL REGISTER	
000.000	831X UC.5BW	EQU 00000000B	5 BIT WORDS	
000.001	832X UC.6BW	EQU 00000001B	6 BIT WORDS	
000.002	833X UC.7BW	EQU 00000010B	7 BIT WORDS	
000.003	834X UC.8BW	EQU 00000011B	8 BIT WORDS	
000.004	835X UC.2SB	EQU 00000100B	TWO STOP BITS SELECTED	
000.010	836X UC.PEN	EQU 00001000B	PARITY COMPUTATION ENABLED	
000.020	837X UC.EPS	EQU 00010000B	EVEN PARITY SELECT	
000.040	838X UC.SKP	EQU 00100000B	STICK PARITY	
000.100	839X UC.SB	EQU 01000000B	SET BREAK	
000.200	840X UC.DLA	EQU 10000000B	DIVISOR LATCH ACCESS	
	841X			
000.004	842X UR.MCR	EQU 4	MODEM CONTROL REGISTER	
000.001	843X UC.DTR	EQU 00000001B	DATA TERMINAL READY	
000.002	844X UC.RTS	EQU 00000010B	REQUEST TO SEND	
000.004	845X UC.QU1	EQU 00000100B	OUT 1	
000.010	846X UC.QU2	EQU 00001000B	OUT 2	
000.020	847X UC.L00	EQU 00010000B	LOOP	
	848X			
000.005	849X UR.LSR	EQU 5	LINE STATUS REGISTER	
000.001	850X UC.DR	EQU 00000001B	DATA READY	
000.002	851X UC.OR	EQU 00000010B	OVERRUN	
000.004	852X UC.PE	EQU 000000100B	PARITY ERROR	
000.010	853X UC.FE	EQU 00001000B	FRAMING ERROR	
000.020	854X UC.BI	EQU 00010000B	BREAK INTERRUPT	
000.040	855X UC.THE	EQU 00100000B	TRANSMITTER HOLDING REGISTER EMPTY	
000.100	856X UC.TSE	EQU 01000000B	TRANSMITTER SHIFT REGISTER EMPTY	
	857X			
000.006	858X UR.MSR	EQU 6	MODEM STATUS REGISTER	
000.001	859X UC.DCS	EQU 00000001B	DELTA CLEAR TO SEND	
000.002	860X UC.DDR	EQU 00000010B	DELTA DATA SET READY	
000.004	861X UC.TER	EQU 00000100B	TRAILING EDGE OF RING	
000.010	862X UC.DRL	EQU 00001000B	DELTA RECEIVE LINE SIGNAL DETECT	
000.020	863X UC.CTS	EQU 00010000B	CLEAR TO SEND	
000.040	864X UC.DSR	EQU 00100000B	DATA SET READY	
000.100	865X UC.RI	EQU 01000000B	RING INDICATOR	
000.200	866X UC.RLS	EQU 10000000B	RECEIVED LINE SIGNAL DETECT	

MTR90-1 - H/Z-89 MONITOR
HARDWARE INTERRUPT VECTORS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 20

10:41:12 17-FEB-82

869 *** INTERRUPT VECTORS.
870 *
871

873 ** LEVEL 0 - RESET
874 *
875 * THIS 'INTERRUPT' MAY NOT BE PROCESSED BY A USER PROGRAM.

000.000	877	ORG	00A
	878		
000.000 303 000 004	879	INIT0	JMP INITOX DO H88 EXTENSION OF INITIALIZATION
000.003 041 012 040	880	INIT0.0	LXI H,PRSRAM+PRSL-1 (HL) = RAM DESTINATION FOR CODE
000.006 303 073 000	881	JMP	INIT INITIALIZE
	882		
377.073	883	ERRPL	INIT-1000A BYTE IN WORD 10A MUST BE 0
	884		

000.010	888	INT1	EQU 10Q INTERRUPT ENTRY POINT
	889		
000.000	890	ERRNZ	*-11Q INTO TAKES UP ONE BYTE
	891		
000.011 315 132 000	892	CALL	SAVALL SAVE USER REGISTERS
000.014 026 000	893	MVI	D,0
000.016 303 201 000	894	JMP	CLOCK PROCESS CLOCK INTERRUPT
377.201	895	ERRPL	CLOCK-1000A EXTRA BYTE MUST BE 0

897 ** LEVEL 2 - SINGLE STEP
898 *
899 * IF THIS INTERRUPT IS RECEIVED WHEN NOT IN MONITOR MODE,
900 * THEN IT IS ASSUMED TO BE GENERATED BY A USER PROGRAM
901 * (SINGLE STEPPING OR BREAKPOINTING). IN SUCH CASE, THE
902 * USER PROGRAM IS ENTERED THROUGH (UIVEC+3)
903

000.020	904	INT2	EQU 20A LEVEL 2 ENTRY
	905		
000.000	906	ERRNZ	*-21A INT1 TAKES EXTRA BYTE
	907		
000.021 315 132 000	908	CALL	SAVALL SAVE REGISTERS
000.024 032	909	LDAX	D (A) = (CTLFLG)
040.011	910	SET	CTLFLG
000.025 303 244 001	911	JMP	STPRTN STEP RETURN

913 *** I/O INTERRUPT VECTORS.
914 *
915 * INTERRUPTS 3 THROUGH 7 ARE AVAILABLE FOR GENERAL I/O USE.
916 *
917 * THESE INTERRUPTS ARE NOT SUPPORTED BY MTR88, AND SHOULD
918 * NEVER OCCUR UNLESS THE USER HAS SUPPLIED HANDLER ROUTINES
919 * (THROUGH UIVEC)
920
000.030 921 ORG 30A
922
000.030 303 045 040 923 INT3 JMP UIVEC+6 JUMP TO USER ROUTINE
924
000.033 102 061 064 925 DB 102Q,61Q,64Q,62Q,102Q PART NUMBER 444-142

927
000.040 928 ORG 40A
929
000.040 303 050 040 930 INT4 JMP UIVEC+9 JUMP TO USER ROUTINE
931
000.043 044 122 116 932 DB 44Q,122Q,116Q,102Q,44Q SUPPORT CODE

934
000.050 935 ORG 50A
936
000.050 303 053 040 937 INT5 JMP UIVEC+12 JUMP TO USER ROUTINE
938
939
940 ** DLY - DELAY TIME INTERVAL.
941 *
942 * ENTRY (A) = MILLISECOND DELAY COUNT/2
943 * EXIT NONE
944 * USES A,F
945
000.000 946 ERRNZ *-53A
947
000.053 365 948 DLY PUSH PSW SAVE COUNT
000.054 257 949 XRA A DONT SOUND HORN
000.055 303 143 002 950 JMP HRNO PROCESS AS HORN

952
000.060 953 ORG 60A
954
000.060 303 056 040 955 INT6 JMP UIVEC+15 JUMP TO USER ROUTINE
956
957
000.063 076 320 958 60. MVI A,CB.SSI+CB.CLI+CB.SPK OFF MONITOR MODE LIGHT
000.065 303 235 001 959 JMP SST1 RETURN TO USER PROGRAM

MTR90-1 - H/Z-89 MONITOR
HARDWARE INTERRUPT VECTORS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 22
10:41:15 17-FEB-82

	961					
000.070	962	ORG	70A			
	963					
000.070	303 061 040	964	INT7	JMP	UIVEC+18	JUMP TO USER ROUTINE

967 ** INIT - INITIALIZE SYSTEM
968 *
969 * INIT IS CALLED WHENEVER A HARDWARE MASTER-CLEAR IS INITIATED.
970 *
971 * SETUP MTR88 CONTROL CELLS IN RAM.
972 * DECODE HOW MUCH MEMORY EXISTS, SETUP STACKPOINTER, AND
973 * ENTER THE MONITOR LOOP.
974 *
975 * ENTRY FROM MASTER CLEAR
976 * EXIT INTO MTR88 MAIN LOOP
977
000.000 978 ERRNZ #-730
979
000.073 032 980 INIT LDAX D COPY *PRSROM* INTO RAM
000.074 167 981 MOV M,A MOVE BYTE
000.075 053 982 DCX H DECREMENT DESTINATION
000.076 034 983 INR E INCREMENT SOURCE
000.077 302 073 000 984 JNZ INIT IF NOT DONE
985
004.000 986 SINCR EQU 4000A SEARCH INCREMENT
987
000.102 026 004 988 MVI D,SINCR/256 (DE) = SEARCH INCREMENT
000.104 041 000 034 989 LXI H,START-SINCR (HL) = FIRST RAM - SEARCH INCREMENT
990
991 * DETERMINE MEMORY LIMIT.
992
000.107 167 993 INIT1 MOV M,A RESTORE VALUE READ
000.110 031 994 DAD D INCREMENT TRIAL ADDRESS
000.111 176 995 MOV A,M (A) = CURRENT MEMORY VALUE
000.112 065 996 DCR M TRY TO CHANGE IT
000.113 276 997 CMP M
000.114 302 107 000 998 JNE INIT1 IF MEMORY CHANGED
999
000.117 053 1000 INIT2 DCX H
1001
000.120 371 1002 SPHL SET STACKPOINTER = MEMORY LIMIT -1
1003
000.121 345 1004 PUSH H SET *PC* VALUE ON STACK
000.122 041 322 000 1005 LXI H,ERROR
000.125 345 1006 PUSH H SET 'RETURN ADDRESS'

MTR90-1 - H/Z-89 MONITOR
INTERRUPT TIME SUBROUTINES

#09.02.01.

Unix H8ASH V1.4.1 5-Jul-80
10:41:16 17-FEB-82

Page 24

1009	**	SAVALL - SAVE ALL REGISTERS ON STACK.		
1010	*			
1011	*	SAVALL IS CALLED WHEN AN INTERRUPT IS ACCEPTED, IN ORDER TO		
1012	*	SAVE THE CONTENTS OF THE REGISTERS ON THE STACK.		
1013	*			
1014	*	ENTRY	CALLED DIRECTLY FROM INTERRUPT ROUTINE.	
1015	*	EXIT	ALL REGISTERS PUSHED ON STACK,	
1016	*	IF NOT YET IN MONITOR MODE, REGPTR = ADDRESS OF REGISTERS		
1017	*	ON STACK.		
1018	*	(DE) = ADDRESS OF CTLFLG		
1019				
000.004	1020	ERRMI	132A-*	
000.132	1021	ORG	132A	
000.132 343	1022	SAVALL	XTHL	SET H,L ON STACK TOP
000.133 325	1023	PUSH	D	
000.134 305	1024	PUSH	B	
000.135 365	1025	PUSH	PSW	
000.136 353	1026	XCHG	(D,E) = RETURN ADDRESS	
000.137 041 012 000	1027	LXI	H,10	
000.142 071	1028	DAD	SP	(H,L) = ADDRESS OF USERS SP
	1029			
	1030	**	REPLACE THESE INSTRUCTIONS WITH A JUMP AROUND THE NMI VECTOR JUMP	
	1031	*		
	1032	*	PUSH	H SET ON STACK AS "REGISTER"
	1033	*	PUSH	D SET RETURN ADDRESS
	1034	*	LXI	D,CTLFLG
	1035	*	LDAX	D (A) = CTLFLG
	1036			
000.143 303 105 004	1037	JMP	SAVALLX	GO TO SAVALL EXTENSION
	1038			
	1039	**	ENTRY POINT FOR THE Z80 NMI	
	1040	*		
	1041			
000.000	1042	ERRNZ	*-66H	Z80 NMI ADDRESS
	1043			
000.146 303 116 004	1044	NMIENT	JMP	NMI
	1045			
000.000	1046	ERRNZ	SAVALLR-151A	DO NOT CHANGE ORGANIZATION
	1047			
000.151	1048	SAVALLR	EQU	*
	1049		SAVALL EXTENSION RETURN ADDRESS	
000.151 057	1050	CMA		
000.152 346 060	1051	ANI	CB.MTL+CB.SSI	SAVE REGISTER ADDR IF USER OR SINGLE-STEP
000.154 310	1052	RZ	RETURN IF WAS INTERRUPT OF MONITOR LOOP	
000.155 041 002 000	1053	LXI	H,2	
000.160 071	1054	DAD	SP	(H,L) = ADDRESS OF "STACKPTR" ON STACK
000.161 042 035 040	1055	SHLD	REGPTR	
000.164 311	1056	RET		

10:41:17 17-FEB-82

	1058	**	CUI - CHECK FOR USER INTERRUPT PROCESSING.		
	1059	*			
	1060	*	CUI IS CALLED TO SEE IF THE USER HAS SPECIFIED PROCESSING		
	1061	*	FOR THE CLOCK INTERRUPT.		
	1062				
000.000	1063		ERRNZ	*-165A	
	1064				
040.010	1065	.	SET	.MFLAG	REFERENCE TO MFLAG
000.165 012	1066	CUII	LDAX	B	(A) = .MFLAG
000.000	1067		ERRNZ	U0.CLK-1	CODE ASSUMED = 01
000.166 017	1068		RRC		
000.167 334 037 040	1069		CC	UIVEC	IF SPECIFIED, TRANSFER TO USER
	1070				
	1071	*	RETURN TO PROGRAM FROM INTERRUPT.		
	1072				
000.000	1073		ERRNZ	*-172A	
	1074				
000.172 361	1075	INTXIT	POP	PSW	REMOVE FAKE "STACK REGISTER"
000.173 361	1076		POP	PSW	
000.174 301	1077		POP	B	
000.175 321	1078		POP	D	
000.176 341	1079		POP	H	
000.177 373	1080		EI		
000.200 311	1081		RET		

	1084	***	CLOCK - PROCESS CLOCK INTERRUPT	
	1085	*		
	1086	*	CLOCK IS ENTERED WHENEVER A MILLISECOND CLOCK INTERRUPT IS	
	1087	*	PROCESSED.	
	1088	*		
	1089	*	TICCNT IS INCREMENTED EVERY INTERRUPT.	
	1090			
000.000	1091	ERRNZ	*-201A	
	1092			
000.201	052 033 040	1093	CLOCK LHLD TICCNT	
000.204	043	1094	INX H	
000.205	042 033 040	1095	SHLD TICCNT	INCREMENT TICCOUNT
	1096			
000.210	072 011 040	1097	LDA CTLFLG	CLEAR CLOCK INTERRUPT FLIP-FLOP
000.213	323 360	1098	OUT OP·CTL	
	1099			
	1100	*	EXIT CLOCK INTERRUPT.	
	1101			
000.215	001 011 040	1102	LXI B,CTLFLG	
000.220	012	1103	LDAX B	(A) = CTLFLG
000.221	346 040	1104	ANI CB·MTL	
000.223	302 172 000	1105	JNZ INTXIT	IF IN MONITOR MODE
000.226	013	1106	DCX B	
000.000		1107	ERRNZ CTLFLAG-.MFLAG-1	
000.227	012	1108	LDAX B	(A) = .MFLAG
000.000		1109	ERRNZ UD·HLT-2000	ASSUME HIGH-ORDER
000.230	027	1110	RAL	
000.231	332 270 000	1111	JC CLK4	SKIP IT
	1112			
	1113	*	NOT IN MONITOR MODE. CHECK FOR HALT	
	1114			
000.234	076 012	1115	MVI A,10	(A) = INDEX OF *P* REG
000.236	315 052 003	1116	CALL LRA.	LOCATE REGISTER ADDRESS
000.241	136	1117	MOV E,M	*
000.242	043	1118	INX H	
000.243	126	1119	MOV D,H	(D,E) = PC CONTENTS
000.244	033	1120	DCX D	
000.245	032	1121	LDAX D	
000.246	376 166	1122	CPI MI·HLT	CHECK FOR HALT
000.250	302 165 000	1123	JNZ CUII	
000.253	076 007	1124	MVI A,A,BEL	DING BELL
000.255	315 302 003	1125	CALL HCC	
000.260	076 110	1126	MVI A,"H"	"H" FOR HALT
000.262	315 302 003	1127	CALL HCC	
000.265	303 322 000	1128	JMP ERROR	
	1129			
	1130	***	JE ERROR	IF HALT, BE IN MONITOR MODE
	1131			
	1132	*	NONE OF THE ABOVE, SO ALLOW USER PROCESSING OF CLOCK INTERRUPT	
	1133			
000.270	1134 CLK4	EQU *		
000.270	303 165 000	1135 JMP CUII		ALLOW USER PROCESSING OF CLOCK

MTR90-1 - H/Z-89 MONITOR
MEMORY TEST

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:41:19 17-FEB-82

Page 27

```
1138 ** THIS IS ONLY A PORTION OF THE DYNAMIC RAM TEST!!
1139 *
1140 * WAIT BEFORE MAKING ANOTHER LOOP
1141
000.273 041 000 000 1142 DYMEM6 LXI H,0
000.276 053 1143 DYMEM7 DCX H
000.277 174 1144 MOV A,H
000.300 265 1145 ORA L
000.301 302 276 000 1146 JNZ DYMEM7 IF (B,C) NOT ZERO
1147
000.304 303 167 007 1148 JMP DYMEM4 TRY AGAIN BY INCREMENTING ONCE MORE
1149
1150 ** HAVE A FAILURE PRIOR TO REACHING END OF MEMORY!
1151 *
000.307 353 1152 DYMEM9 XCHG
000.310 041 336 014 1153 LXI H,MSG.ERR DISPLAY ERROR MESSAGE
1154
1155 * LD IX,DY9.3 RETURN ADDRESS
000.313 335 041 1156 DB MI.LDXA,MI.LDXB
000.315 160 011 1157 DW DY9.3
000.317 303 265 007 1158 JMP DYMSG
```

```

1161 *** ERROR - COMMAND ERROR.
1162 *
1163 * ERROR IS CALLED AS A 'BAIL-OUT' ROUTINE.
1164 *
1165 * IT RESETS THE OPERATIONAL MODE, AND RESTORES THE STACKPOINTER.
1166 *
1167 * ENTRY NONE
1168 * EXIT TO MTR LOOP
1169 * CTLFLG SET
1170 * .MFLAG CLEARED
1171 * USES ALL

000.000
1172
1173 ERRNZ *-322A
1174
000.322
1175 ERROR EQU *
000.322 041 010 040 1176 LXI H,.MFLAG
000.325 176 1177 MOV A,H (A) = .MFLAG
000.326 346 275 1178 ANI 3770-U0.DDU-U0.NFR RE-ENABLE DISPLAYS
000.330 167 1179 MOV H,A REPLACE
000.331 043 1180 INX H
000.332 066 360 1181 MVI M,CB.SSI+CB.MTL+CB.CLI+CB.SPK RESTORE *CTLFLG*
000.000
000.334 373 1182 ERRNZ CTLFLG-.MFLAG-1
1183 EI
000.335 052 035 040 1184 LHLD REGPTR
000.340 371 1185 SPHL RESTORE STACK POINTER TO EMPTY STATE
000.341 315 136 002 1186 CALL ALARM ALARM FOR 200 MS

```

```

000.000
1188 ** MTR - MONITOR LOOP.
1189 *
1190
1191 ERRNZ *-344A
1192
000.344
1193 MTR EQU *
000.344 373 1194 EI
1195
000.345
1196 MTR1 EQU *
000.345 041 345 000 1197 LXI H,MTR1
000.350 345 1198 PUSH H SET 'MTR1' AS RETURN ADDRESS
000.351 303 135 011 1199 JMP CKAUTO CHECK AUTO BOOT, IF NOT CONTROL BACK TO NEXT
000.354 315 100 006 1200 MTR.15 CALL TYPMSG PRINT "H="
1201
000.357 315 262 003 1202 MTR.2 CALL RCC READ A CONSOLE CHARACTER
000.362 346 137 1203 ANI 0101111B MAKE SURE ITS UPPER CASE TO MATCH TABLE
000.364 041 045 017 1204 LXI H,MTRA LOOK UP CHARACTER IN *MTRA*
000.367 006 012 1205 MVI B,MTRAL (B) = LENGTH OF TABLE
1206
000.371 276 1207 MTR.3 CMP M SEE IF CHARACTER FROM CONSOLE = TABLE ENTRY
000.372 043 1208 INX H HL = ADDRESS
000.373 312 014 001 1209 JZ MTR.4 IF EQUAL
1210
000.376 043 1211 INX H
000.377 043 1212 INX H
001.000 005 1213 DCR B SEE IF PAST END OF TABLE

```

001.001	302 371 000	1214	JNZ	MTR.3	IF NOT PAST
		1215			
001.004	076 007	1216	MVI	A,A.BEL	ELSE, DING ERROR
001.006	315 302 003	1217	CALL	HCC	
001.011	303 357 000	1218	JMP	MTR.2	TRY AGAIN
		1219			
001.014	315 302 003	1220	MTR.4	CALL	HCC
001.017	176	1221	MOV	A,H	WRITE CHARACTER BACK TO CONSOLE
001.020	043	1222	INX	H	GET MS8
001.021	146	1223	MOV	H,M	
001.022	157	1224	MOV	L,A	(H,L) = ROUTINE ADDRESS
001.023	351	1225	PCHL		GO TO ROUTINE

		1227	**	GETBND1 - CONTINUATION OF GETBND	
		1228	*		
		1229			
001.024	041 003 040	1230	GETBND1	LXI	H,IOWRK+1
001.027	026 015	1231	MVI	D,A.CR	
001.031	315 023 015	1232	CALL	IOA	
		1233			
001.034	052 002 040	1234	LHLD	IOWRK	
001.037	115	1235	MOV	C,L	
001.040	104	1236	MOV	B,H	
001.041	321	1237	POP	D	
001.042	341	1238	POP	H	
001.043	311	1239	RET		

		1241	**	VIEW - VIEW MEMORY BLOCKS	
		1242	*		
		1243	*	VIEW START,STOP	
		1244			
001.044	041 113 002	1245	VIEW	LXI	H,MSG.VEW
001.047	315 100 006	1246	CALL	TYPMSG	
001.052	303 351 007	1247	JMP	VIEW3A	GET START IN DE, STOP IN BC
		1248			
001.055	042 067 040	1249	VIEW1	SHLD	BLKICH
001.060	303 066 002	1250	JMP	VIEW2	SAVE START ADDRESS FOR ASCII STUFF

MTR90-1 - H/Z-89 MONITOR
MTR - MAIN EXECUTIVE LOOP.

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 30

10:41:23 17-FEB-82

```

1253 ** SAE - STORE ABUSS AND EXIT.
1254 *
1255 * ENTRY (HL) = ABUSS VALUE
1256 * EXIT TO (RET)
1257 * USES NONE
1258
000.000 1259 ERRMI 1063A-*
001.063 1260 ORG 1063A
1261
001.063 042 024 040 1262 SAE SHLD ABUSS
001.066 311 1263 RET

```

```

1265 ** PIN - PORT IN
1266 *
1267 * PIN INPUTS A BYTE FROM DISK
1268 *
1269 * ENTRY: NONE
1270 *
1271 * EXIT: (A) = INPUT BYTE FROM Z47
1272 *
1273 * USE: AF
1274
001.067 1275 PIN EQU *
001.067 315 170 006 1276 CALL IN. GET STATUS
001.072 346 240 1277 ANI S.DTR+S.DON CHECK FOR DATA TERMINAL REQUEST
001.074 050 371 1278 JR Z,PIN IF NOT READY, WAIT
001.076 067 1279 STC
001.077 360 1280 RP IF NO S.DTR, MUST BE S.DON
001.100 303 150 006 1281 JMP IN1. INPUT A BYTE FROM PORT

```

000.000	1284	ERRMI	1103A-*	
001.103	1285	ORG	1103A	
	1286	**	PCA - PROGRAM COUNTER ALTER	
	1287	*		
	1288	*	PCA INPUTS AND/OR DISPLAYS THE CURRENT USER PROGRAM VALUE AND ALLOWS	
	1289	*	A NEW VALUE TO BE ENTERED OR RETAINS THE CURRENT VALUE IF	
	1290	*	A CR IS TYPED	
	1291	*		
	1292	*	ENTRY NONE	
	1293	*	EXIT NONE	
	1294	*	USES A,D,E,H,L,F	
	1295			
	1296			
001.103 041 214 006	1297	PCA	LXI H,MSG.PC	COMPLETE PC MESSAGE
001.106 315 100 006	1298	CALL	TYPMSG	
001.111 076 012	1299	MVI	A,10	GET LOCATION OF USER PC
001.113 315 052 003	1300	CALL	LRA.	
001.116 136	1301	MOV	E,M	(D,E) = USER PC VALUE
001.117 043	1302	INX	H	
001.120 126	1303	MOV	D,M	
001.121 353	1304	XCHG		(H,L) = USER PC VALUE
	1305			
001.122 315 012 015	1306	CALL	IROC	INPUT NEXT CHARACTER
001.125 332 137 001	1307	JC	PCA1	IF FIRST CHARACTER WAS OCTAL, INPUT NEW PC
	1308			
001.130 315 064 015	1309	CALL	TOA	ELSE, OUTPUT CURRENT VALUE
001.133 315 012 015	1310	CALL	IROC	SEE IF USER WANTS TO CHANGE IT NOW
001.136 320	1311	RNC		IF NO CHANGE, EXIT
	1312			
	1313	*	ENTER NEW USER PC VALUE	
	1314			
001.137 353	1315	PCA1	XCHG	(H,L) = ADDRESS OF USER PC VALUE
001.140 026 015	1316	MVI	D,A,CR	END BYTE WITH A RETURN
001.142 315 023 015	1317	CALL	IOA	INPUT NEW ADDRESS
001.145 311	1318	RET		EXIT

	1320	**	G088 - GO TO USER ROUTINE FROM H88 MONITOR	
	1321	*		
	1322	*	G088 WAITS FOR A CARRIAGE RETURN OR A NEW ADDRESS TERMINATED WITH	
	1323	*	A CARRIAGE RETURN. IF NO ADDRESS IS ENTERED, G088 TRANSFERS	
	1324	*	CONTROL TO THE ADDRESS SPECIFIED BY THE USER PC VALUE	
	1325			
	1326			
001.146 041 165 006	1327	G088	LXI H,MSG.GO	COMPLETE GO MESSAGE
001.151 315 100 006	1328	CALL	TYPMSG	
001.154 315 012 015	1329	CALL	IROC	INPUT A RETURN OR AN OCTAL CHARACTER
001.157 322 177 001	1330	JNC	G088.1	IF RETURN, GO TO CURRENT USER PC
	1331			
001.162 365	1332	PUSH	PSW	ELSE SAVE OCTAL CHARACTER AND FLAGS
001.163 076 012	1333	MVI	A,10	GET ADDRESS OF USER PC
001.165 315 052 003	1334	CALL	LRA.	
001.170 043	1335	INX	H	POINT TO MSB
001.171 361	1336	POP	PSW	GET FIRST CHARACTER BACK

MTR90-1 - H/Z-89 MONITOR
MONITOR TASK SUBROUTINES.

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 32

GO88

10:41:24 17-FEB-82

001.172 026 015 1337	MVI	D,A.CR	END ADDRESS WITH A RETURN
001.174 315 023 015 1338	CALL	IOA	INPUT NEW GO ADDRESS
001.177 315 370 005 1339	CALL	WCR.	ECHO RETURN
001.202 303 222 001 1340	JMP	GO	EXECUTE USER ROUTINE

1342 **	AUTOBO	- AUTO BOOT	
1343 *			
1344 *	ENTRY:	NONE	
1345 *			
1346 *	EXIT:	(SEE "DEVICE" ROUTINE)	
1347 *			
1348 *	USE:	ALL	
1349			
001.205 257 1350	AUTOBO XRA	A	SET TO PRIMARY FLAG
001.206 315 273 002 1351	CALL	DEVICE	CHECK DEVICE INFORMATION
001.211 303 342 001 1352	JMP	BOOTO	GOTO BOOT IT

000.006	1354	ERRMI	1222A-*
001.222	1355	ORG	1222A
	1356 **	GO	- RETURN TO USER MODE
	1357 *		
	1358 *	ENTRY	NONE
000.000	1359		
	1360	ERRNZ	*-1222A
	1361		
001.222 303 063 000	1362 GO	JMP	GO.

	1364 **	SSTEP	- SINGLE STEP INSTRUCTION.	
	1365 *			
	1366 *	ENTRY	NONE	
	1367			
000.000	1368	ERRNZ	*-1225A	
001.225	1369			
001.225 363	1370 SSTEP	EQU	*	SINGLE STEP
	1371	DI		DISABLE INTERRUPTS UNTIL THE RIGHT TIME
001.226 072 011 040	1372	LDA	CTLFLG	
001.231 356 020	1373	XRI	C8.SSI	CLEAR SINGLE STEP INHIBIT
001.233 323 360	1374	OUT	OP.CTL	PRIME SINGLE STEP INTERRUPT
001.235 062 011 040	1375 SST1	STA	CTLFLG	SET NEW FLAG VALUES
001.240 341	1376	POP	H	CLEAN STACK
001.241 303 172 000	1377	JMP	INTXIT	RETURN TO USER ROUTINE FOR STEP

MTR90-1 - H/Z-89 MONITOR
MONITOR TASK SUBROUTINES.

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

10:41:25 17-FEB-82

Page 33

1379	**	STPRTN	- SINGLE STEP RETURN	
000.000	1380			
	1381	ERRNZ	*-1244A	
	1382			
001.244	1383	STPRTN	EQU *	
001.244 366 020	1384	DRI	C8.SSI	DISABLE SINGLE STEP INTERRUPTION
001.246 323 360	1385	OUT	OP.CTL	TURN OFF SINGLE STEP ENABLE
040.011	1386	SET	CTLFLG	
001.250 022	1387	STAX	D	
001.251 346 040	1388	ANI	C8.MTL	SEE IF IN MONITOR MODE
001.253 302 344 000	1389	JNZ	MTR	
001.256 303 042 040	1390	JMP	UIVEC+3	TRANSFER TO USER'S ROUTINE

1393	**	NBOOT	-	NORMAL BOOT
1394	*			
1395	*	NBOOT IS ENTERED WHEN USER TYPE "BOOT" COMMAND FROM MONITOR.		
1396	*	IT WILL ACCEPT THE BOOT DEVICE AS WELL AS THE UNIT NUMBER FROM		
1397	*	CONSOLE AND GO TO THE BOOT CODE.		
1398	*			
1399	*	ENTRY: NONE		
1400	*			
1401	*	EXIT:	(AIO.UNI) = UNIT NUMBER TO BOOT	
1402	*	(PRIM)	= PORT ADDRESS OF THE BOOT DEVICE	
1403	*	(TMFG)	= DEVICE TYPE, -1 IS Z47; -0 IS H17	
1404	*			
1405	*	USED:	ALL	
1406				
001.261	257	1407	NBOOT XRA A	SET Z FLAG TO PRIMARY DEVICE
001.262	315 273 002	1408	NBOOTO CALL DEVICE	READ SWITCH TO DETERMINE BOOT DEVICE
001.265	315 262 003	1409	START1 CALL RCC	INPUT FROM KB
001.270	376 015	1410	CPI A.CR	IF INPUT IS CR
001.272	050 043	1411	JR Z,BOOT0.	THEN TAKE IT AS DRIVE 0
001.274	315 133 016	1412	CALL BOOT7	
001.277	070 007	1413	JR C,WRONG	
001.301	270	1414	CMP B	
001.302	070 044	1415	JR C,BOOT5	IF WITHIN THE RANGE, BOOT IT!
001.304	010	1416	DB MI.EXAF	SAVE INPUT, CHECK PRIM OR SEC?
001.305	050 010	1417	JR Z,NB7	IF PRIMARY, CHECK 'S'
001.307	010	1418	DB MI.EXAF	RESTORE (Z) FLAG
001.310		1419	WRONG EQU *	
001.310	076 007	1420	MVI A,A,BEL	NOT THE CASES, BEEP!
001.312	315 302 003	1421	CALL HCC	
001.315	030 346	1422	JR START1	AND TRY AGAIN
	1423			
001.317	010	1424	NB7 DB MI.EXAF	RESTORE INPUT & PRIM, SEC FLAG
001.320	346 137	1425	ANI 01011111B	MASK TO UPPER CASE LETTER
001.322	376 123	1426	CPI "S"	CHECK THE USER LIKE TO BOOT FROM
001.324	040 362	1427	JR NZ,WRONG	BOOT SECONDARY DEVICE
	1428			
	1429	*	USER WISHES TO BOOT FROM SECONDARY DEVICE	
	1430			
001.326		1431	BSEC EQU *	
001.326	041 042 014	1432	LXI H,BSMSG	PRINT BOOT SECONDARY MESSAGE
001.331	315 100 006	1433	CALL TYPMSG	
001.334	074	1434	INR A	SET (Z)=0 FOR SECONDARY DEVICE
001.335	030 323	1435	JR NBOOTO	
	1436			
	1437	*	SAVE THE AIO.UNI, CHECK IF THERE IS THE BOOT DEVICE AND GO!	
	1438			
001.337	315 370 005	1439	BOOTO. CALL WCR.	PRINT CR FOR GOOD LOOKS
	1440			
001.342	257	1441	BOOTO XRA A	TAKE CR OR AUTO BOOT AS DRIVE 0
001.343	061 200 042	1442	LXI SP,42200A	SET STACK FOR NO COMMAND LINE
001.346	030 010	1443	JR BOOT6	
	1444			
001.350	315 302 003	1445	BOOT5 CALL HCC	PRINT UNIT NUMBER
001.353	326 060	1446	SUI "0"	MAKE IT BINARY
001.355	303 263 013	1447	JMP CCL	CHECK FOR COMMAND LINE
001.360	062 061 041	1448	BOOT6 STA AIO.UNI	STORE THE UNIT #

MTR90-1 - H/Z-89 MONITOR
NORMAL BOOT

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 35
10:41:29 17-FEB-82

001.363	174	1449	MOV	A,H	CHECK IF NO DEVICE AT ADDR. PORT
001.364	247	1450	ANA	A	INSURE INTERRUPTS READY
001.365	373	1451	EI		NO DEVICE
001.366	312 171 002	1452	JZ	NODEV	JMP TO THE EXECUTION ROUTINE
001.371	351	1453	PCHL		

MTR90-1 - H/Z-89 MONITOR
BOOT Z-47 DISK DRIVE

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:41:30 17-FEB-82

Page 36

1456	**	Z47	-	BOOT FROM Z47 DISK DRIVE
1457	*			
1458	*	Z47 WILL LOAD DATA FROM DISK TRACK 0 SECTOR 0 THRU 9 TO		
1459	*	USER FIRST AVAILABLE RAM LOCATION. IF THE BOOT IS SUCCED,		
1460	*	CONTROL PASS TO THAT LOCATION.		
1461	*			
1462	*	ENTRY: (AIO.UNI) = UNIT NUMBER TO BOOT		
1463	*			
1464	*	EXIT: NONE		
1465	*			
1466	*	USE: ALL		
1467				
001.372	1468	Z47	EQU	*
001.372	355	163	LD	(STK),SP
001.374	124	041	D8	355Q,163Q
				SAVE STACK POINTER FOR RE-BOOT
	1471		DW	STK
	1472			
001.376	1473	Z47A	EQU	*
001.376	373	1474	EI	
001.377	072	061	LDA	AIO.UNI
002.002	007	1475	AIQ.UNI	GET UNIT NUMBER
002.003	007	1476	RLC	SET TO SIDE/UNIT/SECTOR FORMAT
002.004	007	1477	RLC	
002.005	007	1478	RLC	
002.006	007	1479	RLC	
002.007	074	1480	RLC	
002.010	117	1481	INR	A
		1482	MOV	C,A
		1483		SET TO SECTOR 1
000.001		1484	RESET	IF .DEBUG
		1485	XRA	A
		1486	STA	DBFLG
		1487	ENDIF	
		1488		
002.011	076	002	MVI	A,W.RES
002.013	315	000	CALL	Z47X
				DO Z47 EXTENSION
		1491		
		1492	*	READ BOOT CODE FROM Z47
		1493		
002.016	041	200	LXI	H,USERFHA
		1494		BOOT DESTINATION
000.001		1495		
		1496	IF	.DEBUG
		1497	MVI	A,10
		1498	STA	DBFLG
		1499	ENDIF	MEMORY LOCATION FOR DEBUGGING
		1500		
002.021	315	111	CALL	RDBLCK
		1501		READ A SECTOR FROM DISK
		1502		
000.001		1503	IF	.DEBUG
		1504	PUSH	PSW
		1505	MVI	A,11
		1506	STA	DBFLG
		1507	POP	PSW
		1508	ENDIF	
		1509		
002.024	332	171	JC	NODEV
		1510		IF READ ERROR
		1511		

MTR90-1 - H/Z-89 MONITOR
BOOT Z-47 DISK DRIVE

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 37
10:41:30 17-FEB-82

002.027	052	124	041	1512	LHLD	STK	
002.032	371			1513	SPHL		RESTORE STACK
				1514			
002.033	303	201	016	1515	JMP	EUC	SET CLOCK AND ENTER USER CODE

1517	**	RETRY	-	RE-BOOT Z47				
1518	*							
1519	*	RETRY IS ENTERED WHEN 3.5 SECONDS TIME OUT & BOOT Z47						
1520	*	STILL NOT SUCCEED. IT RESTORE STACK & JUMP TO BOOT Z47 ROUTINE						
1521	*							
1522	*	ENTRY: NONE						
1523	*							
1524	*	EXIT: (HL) = (SP)						
1525	*							
1526	*	USE:	HL, SP					
1527								
002.036	052	124	041	1528	RETRY	LHLD	STK	GET OLD STACK ADDRESS
002.041	371			1529		SPHL		SET TO STACK POINTER
002.042	030	332		1530		JR	Z47A	RE-BOOT

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-JUL-80
10:41:31 17-FEB-82

Page 38

50

Monitor MTR-90

1533 ** R.SDP - SET DEVICE PARAMETER, ALLOW TO SET DRIVE 0, 1, AND 2.
1534 * (MORE INFORMATION CAN BE FOUND IN H17 ROM CODE 36062A)
1535
002.044 1536 R.SDP EQU *
002.044 076 012 1537 MVI A,ERPTCNT
002.046 062 264 040 1538 STA D.OECNT SET MAX ERROR COUNT FOR OPERATION
002.051 072 061 041 1539 LDA AIO.UNI LOAD DRIVE NUMBER
002.054 365 1540 PUSH PSH SAVE IT
002.055 376 002 1541 CPI 2 IS IT DRIVE 2?
002.057 070 002 1542 JR C,R.SDP1 IF NOT JMP TO H17 ROM ROUTINE
002.061 076 003 1543 MVI A,3
002.063 303 073 036 1544 R.SDP1 JMP SDP3

1546 ** VIEW2 - CONTINUE *VIEW* COMMAND

1547 *

1548

002.066 176 1549 VIEW2 MOV A,M A = BYTE
002.067 315 077 015 1550 CALL TOB
002.072 076 040 1551 MVI A,*' ' SPACE BETWEEN
002.074 315 302 003 1552 CALL WCC
002.077 315 363 007 1553 CALL VIEW4 CHECK FOR END
002.102 312 355 003 1554 JZ VIEW9 IF ALL DONE
002.105 315 340 003 1555 CALL VIEW3. CHECK FOR END OF LINE
002.110 303 000 006 1556 JMP VIEW3
1557
002.113 151 145 167 1558 MSG.VEW DB 'iew ',0

MTR90-1 - H/Z-89 MONITOR
MAKE NOISE ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 39

10:41:32 17-FEB-82

000.016	1561	ERRMI	2136A-*	
002.136	1562	ORG	2136A	
	1563	**	HORN - MAKE NOISE.	
	1564	*		
	1565	*	ENTRY (A) = (MILLISECOND COUNT)/2	
	1566	*	EXIT NONE	
	1567	*	USES A,F	
	1568			
000.000	1569	ERRNZ	*-2136A	
	1570			
002.136	1571	ALARM	EQU *	
002.136 030 026	1572	JR	ALARMB	BRANCH TO A JUMP TO NOISE TO DING BELL
	1573			
000.000	1574	ERRNZ	*-2140A	
	1575			
002.140 365	1576	HORN	PUSH PSW	
002.141 076 200	1577		MVI A,CB,SPK	TURN ON SPEAKER
	1578			
002.143 343	1579	HRNO	XTHL	SAVE (HL), (H) = COUNT
002.144 325	1580		PUSH D	SAVE (DE)
002.145 353	1581		XCHG	(D) = LOOP COUNT
002.146 041 011 040	1582	LXI	H,CTLFLG	
002.151 256	1583	XRA	H	
002.152 136	1584	MOV	E,M	(E) = OLD CTLFLG VALUE
002.153 167	1585	MOV	H,A	TURN ON HORN
002.154 056 033	1586	MVI	L,#TICCNT	
	1587			
002.156 172	1588	MOV	A,D	(A) = CYCLE COUNT
002.157 206	1589	ADD	H	
002.160 276	1590	HRN2	CMP H	WAIT REQUIRED TICCOUNTS
002.161 040 375	1591	JR	NZ,HRN2	
	1592			
002.163 303 045 006	1593	JMP	HRNX	JUMP TO AN EXTENSION OF HORN SO ROOM
	1594	*		CAN BE MADE FOR A JUMP TO NOISE
	1595			
	1596			
002.166 303 053 006	1597	ALARMB	JMP	NOISE SEND A BELL TO THE CONSOLE

MTR90-1 - H/Z-89 MONITOR
NO DEVICE INSTALLED

#09.02.01.

Unix H8ASH V1.4.1 5-Jul-80 Page 40
10:41:33 17-FEB-82

52

Monitor MTR-90

1600	**	NODEV	- NO DEVICE AT THE UNIT USER INDICATE
1601	*		
1602	*	NODEV IS ENTERED WHEN:	1. 15 SECONDS TIME OUT
1603	*		OR 2. NO DEVICE IS INDICATED ON SWITCH
1604	*		OR 3. USER HIT <DELETE> TO ABORT BOOT
1605	*		OR 4. BOOT ERROR
1606	*	IT WILL EXIT TO 'ERROR' ROUTINE AND MONITOR LOOP	
1607	*		
1608	*	ENTRY:	NONE
1609	*		
1610	*	EXIT:	(A) = 0
1611	*		
1612	*	USE:	AF, HL
1613			
002.171	1614	NODEV EQU *	
002.171	041 046 014	1615 LXI H,ERRMSG	PRINT ERROR MESSAGE
002.174	315 100 006	1616 CALL TYPMSG	
002.177	062 010 040	1617 NODEV1 STA .MFLAG	STOP TIMER
002.202	323 177	1618 OUT DP,DC	OFF DISK
002.204	303 322 000	1619 JMP ERROR	BACK TO MONITOR LOOP

MTR90-1 - H/Z-89 MONITOR
BOOT H-17 DISK DRIVE

#09.02.01.

Unix HBASH V1.4.1 5-Jul-80 Page 41
10:41:33 17-FEB-82

1622	**	H17	-	BOOT FROM H17 DISK SYSTEM
1623	*			(THIS IS THE MODIFICATION OF THE H17 BOOT ROUTINE,
1624	*			MORE INFORMATION CAN BE FOUND ON H17 BOOT ROM 30000A)
1625	*			
1626	*			ENTRY: (AIO.UNI) = THE UNIT TO BOOT
1627	*			
1628	*			EXIT: NONE
1629	*			
1630	*			USE: ALL
1631				
002.207		1632	H17	EQU *
002.207	001 130 000	1633	LXI	B,BOOTAL
002.212	021 132 037	1634	LXI	D,BOOTA
002.215	041 110 040	1635	LXI	H,D,CON
002.220	315 252 030	1636	CALL	\$MOVE
1637				
1638	**			SET ADDRESS FOR "SET DEVICE PARAMETER" ROUTINE
1639	*			TO HANDLE DISK DRIVE 0, 1, AND 2.
1640				
002.223	041 044 002	1641	LXI	H,R,SDP
002.226	042 206 040	1642	SHLD	D,SDP
002.231	373	1643	EI	
1644				RESTORE INTERRUPT
1645	*			WAIT TILL USER INSERT THE DISK AND CLOSE THE DOOR
1646	*			(TIMER INTERRUPT IS AFFECTED NOW)
1647				
002.232	006 012	1648	MVI	B,10
002.234	315 044 002	1649	CALL	R,SDP
002.237	315 271 036	1650	H17A	CALL WNH
002.242	315 235 036	1651	CALL	WHD
002.245	020 370	1652	DJNZ	H17A
1653				
1654	*			READ BOOT CODE
1655				
002.247	315 024 017	1656	CALL	H17X
002.252	021 200 042	1657	LXI	D,USERFWA
002.255	001 000 011	1658	LXI	B,9*256
002.260	041 000 000	1659	LXI	H,O
002.263	315 077 034	1660	CALL	R,READ
002.266	070 301	1661	JR	C,NODEV
002.270	303 215 016	1662	JMP	EUC.
				H17 Extension Routine
				SET THE LOAD LOCATION
				LOAD 9 SECTORS
				LOAD FROM TRACK 0 SECTOR 1
				READ DISK BOOT CODE
				ERROR ON BOOT, BACK TO "H:"
				VECTORS ALREADY IN

	1665	***	DEVICE	-	DETERMINE BOOT WHICH DEVICE AT WHICH PORT
	1666	*			
	1667	*	ENTRY:	Z FLAG (Z=1 FOR PRIMARY, Z=0 FOR SECONDARY)	
	1668	*			
	1669	*	EXIT:	HL = DEVICE BOOT EXECUTION ADDRESS	
	1670	*		REG B = PRIMARY MAXI. DRIVE NUMBER	
	1671	*		IF Z47 = '4';H17 = '3';H37 = '4';H67 = '4'	
	1672	*		(PRIM) = PRIMARY DEVICE PORT ADDRESS	
	1673	*		(TMFG) = SET UP FROM TABLE	
	1674	*			
	1675	*	USE:	ALL	
	1676				
002.273	1677	DEVICE	EQU	*	
002.273 010	1678	DB	MI.EXAF		SAVE Z FLAG
	1679				
	1680	*	INITIAL VARIABLES		
	1681				
002.274 363	1682	DI			NO INTERRUPT
002.275 041 240 040	1683	LXI	H,D.RAM		CLEAR H17 WORK RAM AREA
002.300 006 037	1684	MVI	B,D.RAM		LENGTH TO CLEAR
002.302 315 212 031	1685	CALL	\$ZERO		
002.305 323 177	1686	OUT	DP.DC		OFF DISK
002.307 062 033 040	1687	STA	TICCM		O TIMER COUNTER
002.312 062 122 041	1688	STA	MYCNT		0.5 SECOND TIMER = 0
	1689				
002.315 074	1690	INR	A		(A)=1
000.000	1691	ERRNZ	UO.CLK-1		TIMER INTERRUPT MUST = 1
002.316 062 010 040	1692	STA	.MFLAG		ALLOW TIMER INTERRUPT
002.321 041 037 040	1693	LXI	H,UIVEC		SET ALL VECTOR TO EI/RET PROCESS
002.324 066 303	1694	BOOT2	MVI		M,MI.JMP
002.326 043	1695	INX	H		
002.327 066 027	1696	MVI	M,#EIXIT		STORE LS BYTE
002.331 043	1697	INX	H		
002.332 066 034	1698	MVI	M,EIXIT/256		STORE MS BYTE
002.334 043	1699	INX	H		
002.335 207	1700	ADD	A		
002.336 362 324 002	1701	JP	BOOT2		
	1702				
002.341 041 304 004	1703	LXI	H,TMOUT		SET TIMER INTERRUPT VECTOR
002.344 042 040 040	1704	SHLD	UIVEC+1		
	1705				
	1706	*	DETERMINE BOOT DEVICE AND ITS INFORMATION		
	1707				
002.347 333 362	1708	IN	H88.SH		READ SWITCH DATA
002.351 346 020	1709	ANI	H88S.DV		DETERMINE WHICH TABLE IS PRIMARY
002.353 050 012	1710	JR	Z,DEV174		IF PORT 174 IS PRIMARY
	1711				
	1712	*	PRIMARY DEVICE IS AT 170q		
	1713				
002.355 333 362	1714	DEV170	IN	H88.SH	GET DEVICE SWITCHES
	1715				
002.357 010	1716	DB	MI.EXAF		GET 'SD' FLAG
002.360 041 103 017	1717	LXI	H,BT174		ASSUME PORT 174
002.363 040 021	1718	JR	NZ,DEV2		IF WAS 174
	1719				
002.365 030 010	1720	JR	DEV1.		DO PORT 170 STUFF

1721
 1722 * DEVICE IS AT 1740
 1723
 002.367 333 362 1724 DEV174 IN H88.SW GET DEVICE DIPS
 1725
 002.371 010 1726 DB MI.EXAF SAVE DIPS, RESTORE 'SD' FLAG
 002.372 041 103 017 1727 LXI H,BT174 ASSUME PRIMARY
 002.375 050 007 1728 JR Z,DEV2
 1729
 002.377 010 1730 DEV1. DB MI.EXAF GET SWITCHES BACK
 003.000 017 1731 RRC
 003.001 017 1732 RRC MOVE BITS DOWN
 003.002 010 1733 DB MI.EXAF AND SAVE AGAIN
 003.003 041 124 017 1734 LXI H,BT170 WAS PORT 170
 1735 * JR DEV2
 000.000 1736 ERKNZ *-DEV2
 1737
 1738 * HL = ADDRESS OF FWA OF PROPER TABLE
 1739
 003.006 176 1740 DEV2 MOV A,M FIRST BYTE IS PORT NUMBER
 003.007 062 120 041 1741 STA PRIM (A) = DEVICE ADDRESS
 1742
 003.012 010 1743 DB MI.EXAF (A) = DEVICE SPECIFIC FLAG
 003.013 346 003 1744 ANI H88S.4 MASK OFF UNIT BITS
 003.015 207 1745 ADD A
 003.016 207 1746 ADD A 4 BYTE ENTRIES
 003.017 043 1747 INX H HL = FWA OF TABLE ENTRIES
 003.020 137 1748 MOV E,A
 003.021 026 000 1749 MVI D,O DE = OFFSET
 003.023 031 1750 DAD D HL = ADDRESS OF DEVICE ENTRY
 1751
 003.024 176 1752 MOV A,M
 003.025 062 121 041 1753 STA TMFG 1ST ENTRY IS TIME-OUT FLAG
 1754
 003.030 043 1755 INX H
 003.031 106 1756 MOV B,M 2ND ENTRY IS UNIT NUMBER
 1757
 003.032 043 1758 INX H
 003.033 136 1759 MOV E,M
 003.034 043 1760 INX H 3RD ENTRY IS BOOT ROUTINE ADDRESS
 003.035 126 1761 MOV D,M
 003.036 353 1762 XCHG MOVE IT INTO HL
 003.037 311 1763 RET

MTR90-1 - H/Z-89 MONITOR
SUPPORT Routines

#09.02.01.

Unix H8ASH V1.4.1 5-Jul-80
10:41:37 17-FEB-82

Page 44

000.007	1766	ERRMI	3047A-*	
003.047	1767	ORG	3047A	
	1768	**	LRA - LOCATE REGISTER ADDRESS.	
	1769	*		
	1770	*	ENTRY NONE.	
	1771	*	EXIT (A) = REGISTER INDEX	
	1772	*	(H,L) = STORAGE ADDRESS	
	1773	*	(D,E) = (0,A)	
	1774	*	USES A,D,E,H,L,F	
	1775			
	1776			
000.000	1777	ERRNZ	*-3047A	
	1778			
003.047 072 005 040	1779	LRA	LDA REGI	
003.052 137	1780	LRA.	MOV E,A	
003.053 026 000	1781	MVI	D,O	
003.055 052 035 040	1782	LHLD	REGPTR	
003.060 031	1783	DAD	D (DE) = (REGPTR)+(REGI)	
003.061 311	1784	RET		
	1786	**	IOA - INPUT OCTAL ADDRESS.	
	1787	*		
	1788	*	ENTRY (H,L) = ADDRESS OF RECEPTION DOUBLE BYTE.	
	1789	*	(D) = TERMINATING CHARACTER	
	1790	*	EXIT NONE	
	1791	*	USES A,D,E,H,L,F	
	1792			
	1793			
000.000	1794	ERRNZ	*-3062A	
	1795			
003.062 303 166 005	1796	IOAO	JMP IOA1	
003.065 000	1797	NDP	RETAIN H8 ORG	
	1799	**	IOB - INPUT OCTAL BYTE.	
	1800	*		
	1801	*	READ ONE OCTAL BYTE FROM THE KEYSET.	
	1802	*		
	1803	*	ENTRY (H,L) = ADDRESS OF BYTE TO HOLD VALUE	
	1804	*	'C' SET IF FIRST DIGIT IN (A)	
	1805	*	EXIT NONE	
	1806	*	USES A,D,E,H,L,F	
	1807			
	1808			
000.000	1809	ERRNZ	*-3066A	
	1810			
003.066 066 000	1811	1080	MVI M,O	ZERO OUT OLD VALUE
003.070 324 262 003	1812	IO81	CNC RCC	READ CONSOLE CHARACTER
	1813			
	1814	*	SEE IF CHARACTER IS A VALID OCTAL VALUE	
	1815	*		

003.073	376 060	1816	CPI	'0'	LESS THAN ZERO?
003.075	332 135 003	1817	JC	I0B2	IF (A) < 0, SEE IF A TERMINATING CHARACTER
003.100	376 070	1818	CPI	'8'	GREATER THAN 7?
003.102	322 070 003	1819	JNC	I0B1	IF TOO LARGE, TRY AGAIN
		1820			
		1821	*	HAVE AN OCTAL DIGIT	
		1822	*		
003.105	315 302 003	1823	CALL	WCC	ECHO CHARACTER
003.110	346 007	1824	ANI	00000111B	MASK FOR BINARY VALUE
003.112	137	1825	MOV	E,A	(E) = VALUE
003.113	176	1826	MOV	A,M	GET OLD VALUE
003.114	007	1827	RLC		SHIFT 3
003.115	007	1828	RLC		
003.116	007	1829	RLC		
003.117	303 126 003	1830	JMP	I0B1.5	JUMP AROUND AN H88/H89 TO H8 FAKE ROUTINE
		1831			
		1832	**	FAKE OUT ROUTINE FOR CALLERS OF *DOD* FROM THE H8 FRONT PANEL	
		1833			
		1834			
000.000		1835	ERRNZ	*-3122A	
		1836			
003.122	043	1837	D00	INX	H
003.123	043	1838	INX	H	
003.124	043	1839	INX	H	
003.125	311	1840	RET		
		1841			
		1842			
		1843	*	CONTINUE	
		1844			
003.126	346 370	1845	I0B1.5	ANI	11111000B TOSS OLD LSB DIGIT
003.130	263	1846		ORA	E REPLACE WITH NEW VALUE
003.131	167	1847		MOV	M,A
003.132	303 070 003	1848	JMP	I0B1	INPUT ANOTHER CHARACTER
		1849			
		1850	*	CHECK FOR A CARRIAGE RETURN TO TERMINATE BYTE	
		1851	*		
003.135	376 015	1852	I0B2	CPI	A.CR CARRIAGE RETURN?
003.137	310	1853	RZ		RETURN IF CARRIAGE RETURN /JHT 790507/
003.140	257	1854	XRA	A	CLEAR CARRY /JHT 790507/
003.141	030 325	1855	JR	I0B1	GET A NEW CHARACTER /JHT 790507/

	1858	**	DYASC - DYNAMIC RAM ASCII OUTPUT TO CONSOLE	
	1859	*		
	1860	*	ENTRY (A) = CHARACTER TO OUTPUT	
	1861	*	(IY) = RETURN ADDRESS	
	1862	*	EXIT TO (IY)	
	1863	*	USES A,C,F	
	1864			
003.143	1865	DYASC	EQU *	
	1866	*	EX AF,AF ¹	
003.143 010	1867	DB	MI.EXAF	
003.144 333 355	1868	DYASCI	IN SC.ACE+UR.LSR	TERMINAL READY?
003.146 346 040	1869	ANI	UC.THE	
003.150 312 144 003	1870	JZ	DYASCI	NOT YET.
	1871			
	1872	*	EX AF,AF ¹	
003.153 010	1873	DB	MI.EXAF	
003.154 323 350	1874	OUT	SC.ACE+UR.THR	
	1875	*	JP (IY)	RETURN TO CALLER
003.156 375 351	1876	DB	MI.JIYA,MI.JIYB	
	1878	**	DYBYT - DYNAMIC RAM BYTE OUTPUT	
	1879	*		
	1880	*	ENTRY (A) = BYTE TO OUTPUT AS OCTAL	
	1881	*	(IX) = RETURN ADDRESS	
	1882	*	EXIT TO (IX)	
	1883	*	USES A,C,IY,F	
	1884			
003.160 303 240 016	1885	DYBYT	JMP DYBYTX	
003.163 366 060	1886	DYBYT.	I ORI '0'	MAKE ASCII
	1887			
	1888	*	LD IY,DYBYT.2	
003.165 375 041	1889	DB	MI.LDYA,MI.LDYB	
003.167 174 003	1890	DW	DYBYT.2	
	1891			
003.171 303 143 003	1892	JMP	DYASC	
	1893			
003.174 171	1894	DYBYT.2	MOV A,C	
003.175 346 070	1895	ANI	00111000B	
003.177 017	1896	RRC		
003.200 017	1897	RRC		
003.201 017	1898	RRC		
003.202 366 060	1899	ORI	'0'	
	1900			
	1901	*	LD IY,DYBYT.4	
003.204 375 041	1902	DB	MI.LDYA,MI.LDYB	
003.206 213 003	1903	DW	DYBYT.4	
	1904			
003.210 303 143 003	1905	JMP	DYASC	
	1906			
003.213 171	1907	DYBYT.4	MOV A,C	
003.214 346 007	1908	ANI	00000111B	
003.216 366 060	1909	ORI	'0'	
	1910			
	1911	*	LD IY,DYBYT.6	

MTR90-1 - H/Z-89 MONITOR
RAM TEST ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:41:40 17-FEB-82

Page 47

003.220	375 041	1912	DB	MI.LDYA,MI.LDYB
003.222	227 003	1913	DW	DYBYT.6
		1914		
003.224	303 143 003	1915	JMP	DYASC
		1916		
003.227		1917	DYBYT.6 EQU	*
		1918	*	JP (IX)
003.227	335 351	1919	DB	MI.JIXA,MI.JIXB

		1921	**	MSG.PAS - PASS MESSAGE FOR DYNAMIC RAM TEST
		1922	*	
		1923		
003.231	015 012 012	1924	MSG.PAS DB	A.CR,A.LF,A.LF
003.234	011 040 120	1925	DB	11Q," Pass =",11Q," "
003.250	000	1926	DB	0

MTR90-1 - H/Z-89 MONITOR
RCK - READ CONSOLE KEYPAD

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 48
10:41:41 17-FEB-82

000.007	1929	ERRMI	3260A-*
003.260	1930	ORG	3260A
	1931 **	RCK - READ CONSOLE KEYPAD	
	1932 *		
	1933 *	RCK IS CALLED TO READ A KEYSTROKE FROM THE CONSOLE FRONT PANEL KEYPAD.	
	1934 *	SINCE THE H88/89 DOES NOT HAVE A FRONT PANEL, THIS ROUTINE IS PROVIDED	
	1935 *	ONLY TO MAINTAIN COMPATIBILITY WITH PAM-8.	
	1936 *	RCK WILL IMMEDIATELY RETURN WITH A VALUE OF 0 (ZERO) IN THE ACCUMULATOR.	
	1937 *		
	1938 *	ENTRY	NONE
	1939 *	EXIT	(A) = 0
	1940 *	USES	A,F
	1941 *		
	1942 *	RCK MUST HAVE SAME ENTRY AS RCK IN PAM-8	
000.000	1943	ERRNZ	*-3260A
	1944		
003.260	1945	RCK	EQU *
	1946		
003.260 257	1947	XRA	A
003.261 311	1948	RET	
	1949		

10:41:41 17-FEB-82

	1953	**	RCC - READ CONSOLE CHARACTER.	
	1954	*		
	1955	*	RCC IS CALLED TO READ A KEYSTROKE FROM THE CONSOLE.	
	1956	*	IF A RUBOUT/DELETE IS RECEIVED, EXIT IS TO *ERROR*.	
	1957	*		
	1958	*	ENTRY NONE	
	1959	*	EXIT TO ERROR - IF A DELETE OR RUBOUT IS ENCOUNTERED	
	1960	*	TO CALLER - WHEN A KEY IS HIT	
	1961	*	(A) = ASCII KEY VALUE	
	1962	*	USES A,F	
	1963			
	1964			
	1965			
003.262	1966	RCC	EQU *	
	1967			
003.262	333 355	1968	RCC1	IN SC.ACE+UR.LSR INPUT ACE LINE STATUS REGISTER
003.264	346 001	1969	ANI UC.DR SEE IF THERE IS A DATA READY	
003.266	050 372	1970	JR Z,RCC1	
	1971			
003.270	333 350	1972	RCC2	IN SC.ACE+UR.RBR ELSE, INPUT CHARACTER
003.272	346 177	1973	ANI 0111111B TOSS ANY PARITY	
003.274	376 177	1974	CPI A.DEL	
003.276	312 322 000	1975	JZ ERROR	IF RUBOUT, EXIT TO ERROR
	1976			
003.301	311	1977	RET	ELSE, EXIT TO CALLER
	1978			
	1979	**	WCC - WRITE CONSOLE CHARACTER	
	1980	*		
	1981	*	WRITE A CHARACTER TO THE CONSOLE UART PORT	
	1982	*		
	1983	*	ENTRY (A) = ASCII CHARACTER TO OUTPUT	
	1984	*	EXIT NONE	
	1985	*	USES NONE	
	1986			
	1987			
003.302	365	1988	WCC	PUSH PSW SAVE CHARACTER
003.303	333 355	1989	WCC1	IN SC.ACE+UR.LSR INPUT ACE STATUS
003.305	346 040	1990	ANI UC.THE SEE IF TRANSMITTER HOLDING REGISTER IS EMPTY	
003.307	050 372	1991	JR Z,WCC1	
	1992			
003.311	361	1993	POP PSW	GET CHARACTER
003.312	323 350	1994	OUT SC.ACE+UR.THR	OUTPUT TO CONSOLE
003.314	311	1995	RET	

MTR90-1 - H/Z-89 MONITOR
CONSOLE CHARACTER ROUTINES.

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 50

10:41:42 17-FEB-82

	1997	**	THE FOLLOWING IS ONLY A PORTION OF THE DYNAMIC RAM TEST!!!		
	1998	*			
003.315	353	1999	DY9.5	XCHG	SAVE ERROR ADDRESS
003.316	041 341 007	2000	LXI	H,MSG.EQ	OUTPUT " " "
	2001				
	2002	*	LD	IX,DY9.8	RETURN ADDRESS
003.321	335 041	2003	DB	MI.LDXA,MI.LDXB	
003.323	330 003	2004	DW	DY9.8	
	2005				
003.325	303 265 007	2006	JMP	DYMSG	OUTPUT STRING
	2007				
003.330	032	2008	DY9.8	LDAX	D OUTPUT RAM CONTENTS
	2009				
	2010	*	LD	IX,DYMEM10	RETURN ADDRESS
003.331	335 041	2011	DB	MI.LDXA,MI.LDXB	
003.333	252 013	2012	DW	DYMEM10	
	2013				
003.335	303 160 003	2014	JMP	DYBYT	

	2016	**	VIEW3. - CONTINUATION OF *VIEW*		
	2017	*			
	2018	*	SEE IF END OF BYTES		
	2019	*			
	2020				
003.340	043	2021	VIEW3.	INX	H BUMP POINTER
003.341	315 112 015	2022		CALL	CHKRAD GET RADIX
003.344	076 360	2023		MVI	A,11110008 ASSUME HEX
003.346	040 002	2024		JR	NZ,VIEW3.A IF WAS HEX
003.350	076 370	2025		MVI	A,111110008
003.352	245	2026	VIEW3.A	ANA	L (A) = MASKED ADDR LSB
003.353	275	2027		CMP	L SAME?
003.354	311	2028		RET	LET CALLER DECIDE

	2030	**	VIEW9 - DO THE ASCII		
	2031	*			
	2032				
003.355	052 067 040	2033	VIEW9	LHLD	BLKICW RESTORE REGISTERS
003.360	303 171 010	2034		JMP	VIEW5

2037	**	IO ROUTINES TO BE COPIED INTO AND USED IN RAM.		
2038	*			
2039	*	MUST CONTINUE TO 3777A FOR PROPER COPY.		
2040	*	THE TABLE MUST ALSO BE BACKWARDS TO THE FINAL RAM		
2041				
000.006	2042	ERRMI	4000A-7-*	
003.371	2043	ORG	4000A-7	
	2044			
003.371	2045	PRSR0M	EQU	*
003.371 001	2046	DB	1	REFIND
003.372 000	2047	DB	0	CTLFLG
003.373 000	2048	DB	0	.MFLAG
003.374 000	2049	DB	0	DSPMOD
003.375 000	2050	DB	0	DSPROT
003.376 012	2051	DB	10	REGI
003.377 311	2052	DB	MI.RET	
	2053			
000.000	2054	ERRNZ	*-4000A	
	2055			

	2058	***	INITOX	EXTENSION OF INITO TO SUPPORT H88	
	2059				
004.000	076 002	2060	INITOX MVI	A,H88B.CK	
004.002	323 362	2061	OUT	H88.CTL	
		2062			
		2063	*	SET UP ACE FOR CONSOLE COMMUNICATIONS	
		2064	*		
004.004	076 200	2065	MVI	A,UC.DLA	SET DIVISOR LATCH ACCESS BIT
004.006	323 353	2066	OUT	SC.ACE+UR.LCR	
004.010	041 101 004	2067	LXI	H,BRTAB	(H,L) = BEGINNING OF BAUD RATE TABLE
004.013	333 362	2068	IN	H88.SW	INPUT SWITCHES FOR DESIRED BAUD RATE
004.015	346 100	2069	ANI	H88S.BR	MASK FOR BAUD RATE SWITCHES ONLY
004.017	017	2070	RRC		SHIFT FOR A #2 FOR TABLE
004.020	017	2071	RRC		
004.021	017	2072	RRC		
004.022	017	2073	RRC		
004.023	017	2074	RRC		
004.024	205	2075	ADD	L	ADD DISPLACEMENT FROM BEGINNING OF TABLE
004.025	157	2076	MOV	L,A	
004.026	176	2077	MOV	A,M	GET MSB OF DIVISOR
004.027	323 351	2078	OUT	SC.ACE+UR.DLM	
004.031	043	2079	INX	H	GET LSB
004.032	176	2080	MOV	A,M	
004.033	323 350	2081	OUT	SC.ACE+UR.DLL	
004.035	076 003	2082	MVI	A,UC.8BW	SET 8 BITS, 1 STOP BIT, NO PARITY
004.037	323 353	2083	OUT	SC.ACE+UR.LCR	
004.041	076 000	2084	MVI	A,0	SET NO INTERRUPTS
004.043	323 351	2085	OUT	SC.ACE+UR.IER	
		2086			
		2087	*	WAIT A WHILE TO ALLOW THE CONSOLE RESET TO FINISH SO IT CAN	
		2088	*	ACCEPT THE FIRST PROMPT	
		2089	*		
004.045	303 113 016	2090	JMP	INTOXO	DO OTHER STUFF FIRST
004.050	015	2091	INITOXI DCR	C	
004.051	040 375	2092	JR	NZ,INITOXI	
		2093			
004.053	020 373	2094	DJNZ	INITOXI	
		2095			
		2096	*	INPUT SWITCH TO SEE IF TO BEGIN OPERATION OR MEMORY TEST	
		2097	*		
004.055	333 362	2098	IN	H88.SW	GET SWITCHES
004.057	346 040	2099	ANI	H88S.M	MASK FOR MEMORY TEST ONLY
004.061	312 032 016	2100	JZ	MEMORY.	IF TO PERFORM MEMORY TESTS
		2101			
		2102	*	REPLACE WHAT WAS ORIGINALLY AT THE JUMP WHICH GOT US HERE	
		2103	*		
004.064	021 371 003	2104	LXI	D,PRSROM	(DE) = ROM COPY OF PRS CODE
004.067	257	2105	XRA	A	
004.070	062 123 041	2106	STA	AUTOB	INITIAL AUTO BOOT FLAG
004.073	062 066 040	2107	STA	DATA	INITIAL 3620 PORT DATA SAVE BYTE
004.076	303 003 000	2108	JMP	INITO.O	RETURN TO ORIGINAL CODE

	2110	**	BRTAB - BAUD RATE DIVISOR TABLE	
	2111	*		
004.101	2112	BRTAB	EQU *	
	2113			
004.101 000 014	2114	BR96	DB 0,12	9600 BAUD
004.103 000 006	2115	BR19.2	DB 0,6	19,200 BAUD
	2116	*BR38.4	DB 0,3	38,400 BAUD
	2117	*BR56.0	DB 0,2	56,000 BAUD
	2118			
000.004	2119	*	SET */256	
000.000	2120	EKRNZ	BRTAB/256-.	TABLE MUST BE IN ONE PAGE

	2122	***	SAVALLX - SAVALL EXTENSION TO MAKE ROOM FOR A JUMP TO THE NMI HANDLER	
	2123			
004.105	2124	SAVALLX	EQU *	REPLACE OLD CODE
004.105 345	2125	PUSH	H	SET ON STACK AS 'REGISTER'
004.106 325	2126	PUSH	D	SET RETURN ADDRESS
004.107 021 011 040	2127	LXI	D,CTLFLG	
004.112 032	2128	LDAX	D	
004.113 303 151 000	2129	JMP	SAVALLR	RETURN TO OLD CODE

```

2132 **** NMI - NON MASKABLE INTERRUPT
2133 *
2134 * NMI IS USED AS THE TRAP FOR ALL ILLEGAL PORT REQUESTS
2135 *
2136 * PORT ADDRESSES TRAPPED ARE:
2137 *
2138 * IN 360Q FRONT PANEL KEYBOARD INPUT
2139 * OUT 360Q FRONT PANEL CONTROL
2140 * OUT 361Q FRONT PANEL DISPLAY CONTROL
2141 * IN/OUT 372Q CONSOLE DATA FOR AN 8251A
2142 * OUT 373Q CONSOLE CONTROL FOR AN 8251A
2143 *
2144 *
2145 * THESE PORT REQUESTS ARE RESPONDED TO AS FOLLOWS:
2146 *
2147 * IN 360Q RETURNS WITH (A) = 3770 TO SHOW THAT
2148 * NO FRONT PANEL SWITCHES ARE PRESSED
2149 *
2150 * OUT 360Q MOVES BIT 6 (CB.CLI) TO BIT 1, AND
2151 * BIT 4 (CB.SSI) INVERTED, TO BIT 0, AND
2152 * OUTPUTS THESE BITS TO PORT 362Q TO
2153 * CONTROL THE CLOCK AND SINGLE STEP INTERRUPTS
2154 *
2155 * OUTPUTS TO 361Q, 372Q, AND 373Q JUST RETURN
2156 *
2157 * INPUTS FROM 361Q, 372Q, AND 373Q RETURN WITH (A) = 0
2158 * TO INDICATE AN EMPTY BUSS
2159 *
2160 *
2161 * ENTRY NONE
2162 *
2163 * EXIT NONE
2164 *
2165 * USES (A) ONLY IF "FAKING" AN INPUT
2166 *
2167
004.116 343 2168 NMI XTHL GET RETURN ADDRESS FROM STACK
004.117 042 064 040 2169 SHLD NMIRET SAVE FOR LATER USE
004.122 343 2170 XTHL PUT RETURN ADDRESS BACK ON STACK
2171
004.123 345 2172 PUSH H SAVE REGISTERS
004.124 305 2173 PUSH B
004.125 365 2174 PUSH PSW
004.126 107 2175 MOV B,A SAVE (A) PRIOR TO I/O
004.127 052 064 040 2176 LHLD NMIRET GET RETURN ADDRESS
004.132 053 2177 DCX H BACK UP TO PORT # WHICH GOT US HERE
004.133 176 2178 MOV A,M GET PORT #
2179
004.134 376 360 2180 CPI 360Q PORT 360?
004.136 050 033 2181 JR Z,NMII1 IF PORT WAS 360Q
2182
2183 * PORT REFERENCED WAS 361Q, 372Q, OR 373Q
2184 *
004.140 376 361 2185 CPI 361Q MAKE SURE PORT IS LEGAL
004.142 050 010 2186 JR Z,NMII0.5 IF LEGAL
2187

```

004.144	376 372	2188	CPI	372Q	
004.146	050 004	2189	JR	Z,NMIO.5	
		2190			
004.150	376 373	2191	CPI	373Q	
004.152	040 062	2192	JR	NZ,NMI2.5	IF NONE OF THE ABOVE, EXIT
		2193			
004.154	053	2194	NMIO.5	DCX H	POINT TO IN/OUT INSTRUCTION
004.155	176	2195	MOV	A,M	SEE IF INPUT OR OUTPUT
004.156	376 323	2196	CPI	MI.OUT	
004.160	050 054	2197	JR	Z,NMI2.5	IF OUTPUT, JUST EXIT
		2198			
004.162	376 333	2199	CPI	MI.IN	
004.164	040 050	2200	JR	NZ,NMI2.5	IF NOT INPUT EITHER, ILLEGAL SO EXIT
		2201			
004.166	361	2202	POP	PSW	RESTORE FLAGS
004.167	076 000	2203	MVI	A,0	ELSE, RETURN LIKE AN EMPTY BUSS
004.171	030 044	2204	JR	NMI3	EXIT
		2205			
004.173	053	2206	NMII1	DCX H	POINT TO IN/OUT INSTRUCTION
004.174	176	2207	MOV	A,M	GET I/O INSTRUCTION
004.175	376 333	2208	CPI	MI.IN	INPUT?
004.177	040 005	2209	JR	NZ,NMI1.5	IF NOT "IN"
		2210			
004.201	361	2211	POP	PSW	RESTORE FLAGS
004.202	076 377	2212	MVI	A,11111111B	SHOW "NO KEYS PRESSED"
004.204	030 031	2213	JR	NMI3	EXIT
		2214			
004.206	376 323	2215	NMII1.5	CPI MI.OUT	MAKE SURE INSTRUCTION IS AN "OUT"
004.210	040 024	2216	JR	NZ,NMI2.5	IF NOT
		2217			
004.212	170	2218	NMII2	MOV A,B	GET OUTPUT DATA AGAIN
004.213	346 120	2219	ANI	CB.CLI+CB.SSI	MOVE CLOCK INFO TO BIT 1
004.215	017	2220	RRC		
004.216	017	2221	RRC		
004.217	017	2222	RRC		
004.220	017	2223	RRC		
004.221	017	2224	RRC		
004.222	070 001	2225	JR	C,NMI2.2	
004.224	074	2226	IMR	A	
004.225	041 066 040	2227	NMI2.2	LXI H,DATA	OK WITH THE BYTE IN RAM
004.230	266	2228	ORA	M	BEFORE OUTPUT IT
004.231	323 362	2229	OUT	H88.CTL	SET IN HARDWARE
004.233	346 374	2230	ANI	1111100B	
004.235	167	2231	MOV	H,A	
		2232			
004.236	361	2233	NMI2.5	POP PSW	RESTORE (A,F)
		2234			
004.237	301	2235	NMI3	POP B	
004.240	341	2236	POP	H	
		2237 *	RETN		Z80 RETURN FROM NMI
004.241	355 105	2238	D8	3550,1050	

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES & BOOT DEVICE ROUTINE

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:41:48 17-FEB-82

Page 56

	2242	**	ATB	- AUTO BOOT ROUTINE CONTINUE
	2243			
004.243	167	2244	ATB	MOV M,A SET AUTO BOOT FLAG
004.244	076 012	2245	MVI	A,10 SET TO AUTO BOOT ROUTINE
004.246	315 052 003	2246	CALL	LRA.
004.251	021 205 001	2247	LXI	D,AUTOBO SET AUTO BOOT ROUTINE
004.254	030 017	2248	JR	BOOTX

	000.000	2250	ERRNI	4256A-*
	004.256	2251	OKG	4256A
		2252	**	BOOT H-17 OR Z47 ENTRY POINT FOR H88
		2253	*	
		2254	*	ENTRY NONE
		2255	*	
		2256	*	EXIT (DE) = NORMAL BOOT ROUTINE ADDRESS
		2257	*	
		2258	*	USES ALL
		2259		
004.256	041 234 006	2260	BOOT	LXI H,MSG.BT COMPLETE BOOT MESSAGE
004.261	315 100 006	2261	CALL	TYPMSG
004.264	363	2262	DI	
004.265	076 012	2263	MVI	A,10
004.267	315 052 003	2264	CALL	LRA.
004.272	021 261 001	2265	LXI	D,NBOOT GET LOCATION OF USER PC
004.275	163	2266	BOOTX	MOV M,E SET ITS VALUE TO THE NORMAL BOOT ROUTINE
004.276	043	2267	INX	H
004.277	162	2268	MOV	M,D
004.300	373	2269	EI	
004.301	303 063 000	2270	JMP	GO.
				DO IT

```

2273 ** TMOUT - BOOT CODE TIME OUT ROUTINE
2274 *
2275 * TMOUT IS ENTERED FROM TIMER INTERRUPT EVER 100 MS. AND IT WILL
2276 * EXIT: IF BOOT SUCCESS THEN TIMER OFF.
2277 * IF 15 SECONDS TIME OUT AND BOOT IS NOT SUCCESS YES
2278 * THEN ABORT BOOT Z47 & TO MONITOR LOOP
2279 * IF < 15S & 3.5S THEN RE-BOOT
2280 *
2281 * NOTE: Because the H37 and H67 run with interrupts disabled
2282 * during portions of the code, they handle their own
2283 * time outs.
2284 *
2285 * ENTRY: (TMFG) = 1 IF THE TIME OUT IS FOR Z47
2286 * = 0 IF THE TIME OUT IS FOR H17
2287 * EXIT: NONE
2288 *
2289 * USE: ALL (WHEN RETURN, ALL REGISTERS ARE RESTORED)
2290
004.304 2291 TMOUT EQU *
004.304 333 355 2292 IN SC.ACE+UR.LSR INPUT ACE LINE STATUS REGISTER
004.306 346 001 2293 ANI UC.DR SEE IF THERE IS A DATA READY
004.310 050 011 2294 JR Z,TMOUT4 CHECK IF IT IS <DELETE>
2295
004.312 333 350 2296 IN SC.ACE+UR.RBR INPUT DATA FROM KB
004.314 346 177 2297 ANI 0111111B IS IT <DEL>?
004.316 376 177 2298 CPI A.DEL
004.320 312 171 002 2299 JZ NODEV IF IT, ABORT THE BOOT
2300 * ELSE IGNORE THE INPUT
004.323 041 121 041 2301 TMOUT4 LXI H,TMFG
004.326 176 2302 MOV A,M
004.327 247 2303 ANA A
004.330 010 2304 DB MI.EXAF SAVE Z FLAG
004.331 072 033 040 2305 LDA TICNT GET LOW ORDER COUNTER
004.334 247 2306 ANA A SET ZERO FLAG
004.335 040 024 2307 JR NZ,TMOUT2 NOT IN 0.5 SECOND
004.337 043 2308 INX H SET TO MYCNT
000.000 2309 ERRNZ MYCNT-TMFG-1 MYCNT MUST FOLLOW TMFG
004.340 064 2310 INR M INCREASE THE COUNT FOR 0.5 SECOND
004.341 176 2311 MOV A,M
004.342 376 036 2312 CPI 30 CHECK IF MORE THAN 15 SECONDS
004.344 322 171 002 2313 JNC NODEV NO DEVICE ?
004.347 336 007 2314 TMOUT1 SBI 7 IS IT 3.5 SECONDS?
004.351 070 010 2315 JR C,TMOUT2 IF NOT, WAIT
004.353 040 372 2316 JR NZ,TMOUT1 CHECK MORE
004.355 010 2317 DB MI.EXAF
004.356 302 036 002 2318 JNZ RETRY IF IT IS Z47, THEN RE-BOOT
004.361 030 002 2319 JR TMOUT3 IT IS H-17, CONTINUE IT CLOCK ROUTINE
004.363 010 2320 TMOUT2 DB MI.EXAF CHECK IT IS Z47 OR H17
004.364 300 2321 RNZ Z47, THEN RETURN
004.365 303 031 034 2322 TMOUT3 JMP CLOCK17 CONTINUE H17 CLOCK ROUTINE

```

000.000	2325	ERRMI	4370A-*		
004.370	2326	ORG	4370A		
	2327	**	SUBM - SUBSTITUTE MEMORY		
	2328	*			
	2329	*	SUBM INPUTS A MEMORY ADDRESS FROM THE CONSOLE AND THEN DISPLAYS		
	2330	*	THAT ADDRESS AND ITS CONTENTS. IF A CARRIAGE RETURN IS THEN TYPED,		
	2331	*	CONTROL RETURNS TO THE MONITOR. IF A SPACE IS TYPED, THE NEXT		
	2332	*	MEMORY LOCATION AND CONTENTS ARE DISPLAYED. IF A MINUS SIGN IS		
	2333	*	TYPED, THE PREVIOUS MEMORY LOCATION AND CONTENTS ARE DISPLAYED.		
	2334	*	IF AN OCTAL CHARACTER IS TYPED, A BYTE IS ENTERED AND PLACED AT THE		
	2335	*	CURRENT MEMORY LOCATION.		
	2336	*			
	2337	*			
	2338	*	ENTRY NONE		
	2339	*	EXIT NONE		
	2340	*	USES A,E,H,L,F		
	2341				
	2342				
004.370	041 201 006	2343	SUBM	LXI H,MSG.SUB	COMPLETE SUBSTITUTE MESSAGE
004.373	315 100 006	2344	CALL	TYPMSG	
004.376	315 012 015	2345	CALL	IROC	INPUT FIRST CHARACTER
005.001	320	2346	RNC		IF A RETURN, EXIT
	2347				
005.002	041 003 040	2348	LXI	H,IOWRK+1	ELSE, INPUT STARTING ADDRESS
005.005	026 015	2349	MVI	D,A.CR	ENDING WITH A RETURN
005.007	315 023 015	2350	CALL	IOA	
005.012	353	2351	XCHG		(H,L) = INPUT ADDRESS
	2352				
005.013	315 064 015	2353	SUBM1	CALL TOA	TYPE CRLF, ADDRESS, AND A SPACE
005.016	176	2354	MOV	A,M	GET MEMORY CONTENTS FOR DISPLAY
005.017	315 077 015	2355	CALL	TOB	
005.022	076 040	2356	MVI	A," "	SPACE
005.024	315 302 003	2357	CALL	WCC	
	2358				
005.027	315 051 015	2359	SUBM2	CALL IDC	INPUT FIRST CHARACTER
005.032	322 075 005	2360	JNC	SUBM7	IF FIRST CHARACTER IS OCTAL
	2361				
005.035	376 040	2362	CPI	" "	SPACE?
005.037	302 046 005	2363	JNZ	SUBM4	IF NOT A SPACE
	2364				
005.042	043	2365	SUBM3	INX H	POINT TO NEXT ADDRESS
005.043	303 013 005	2366	JMP	SUBM1	DISPLAY NEXT
	2367				
005.046	376 055	2368	SUBM4	CPI " "	MINUS?
005.050	302 062 005	2369	JNZ	SUBM6	IF NOT
	2370				
005.053	315 302 003	2371	SUBM5	CALL HCC	ECHO HYPHEN
005.056	053	2372	DCX	H	POINT TO PREVIOUS ADDRESS
005.057	303 013 005	2373	JMP	SUBM1	DISPLAY PREVIOUS
	2374				
005.062	376 015	2375	SUBM6	CPI A.CR	RETURN?
005.064	310	2376	RZ		IF RETURN, EXIT
	2377				
005.065	076 007	2378	MVI	A,A.BEL	ELSE, DING BELL
005.067	315 302 003	2379	CALL	WCC	
005.072	303 027 005	2380	JMP	SUBM2	TRY AGAIN

		2381			
005.075	066 000	2382	SUBM7	MVI	M,0
		2383			ZERO BYTE TO BE BUILT
005.077	315 302 003	2384	SUBM8	CALL	WCC
005.102	315 352 014	2385		CALL	SUBM10
005.105	315 051 015	2386	SUBM9	CALL	I0C
005.110	322 077 005	2387		JNC	SUBM8
		2388			INPUT NEXT CHARACTER
005.113	376 040	2389	CPI	" "	IF OCTAL
005.115	312 042 005	2390	JZ	SUBM3	SPACE?
		2391			IF SPACE, DISPLAY NEXT BYTE
005.120	376 055	2392	CPI	"-"	MINUS?
005.122	312 053 005	2393	JZ	SUBM5	IF MINUS, DISPLAY PREVIOUS
		2394			
005.125	376 015	2395	CPI	A,CR	RETURN?
005.127	310	2396	RZ		IF RETURN, EXIT
		2397			
005.130	076 007	2398	MVI	A,A,BEL	ELSE, DING BELL
005.132	315 302 003	2399	CALL	WCC	
005.135	303 105 005	2400	JMP	SUBM9	TRY AGAIN

		2403	**	IROC - INPUT A RETURN OR AN OCTAL CHARACTER	
		2404	*		
		2405	*	IROC INPUTS A CHARACTER FROM THE CONSOLE AND WAITS UNTIL IT	
		2406	*	RECEIVES EITHER A VALID OCTAL CHARACTER OR A CARRIAGE RETURN	
		2407	*		
		2408	*	ENTRY	NONE
		2409	*	EXIT	(A) = INPUT CHARACTER
		2410	*		'C' = SET IF CHARACTER IS OCTAL
		2411	*	USES	A,F
		2412			
		2413			
005.140	315 262 003	2414	IROCO	CALL	RCC
005.143	376 015	2415	CPI	A,CR	INPUT CHARACTER
005.145	310	2416	RZ		RETURN?
		2417			IF A CR
005.146	376 060	2418	CPI	"0"	< 0?
005.150	332 156 005	2419	JC	IROC1	IF < OCTAL
		2420			
005.153	376 070	2421	CPI	"8"	> 8?
005.155	330	2422	RC		IF OCTAL
		2423			
005.156	076 007	2424	IROC1	MVI	A,A,BEL
005.160	315 302 003	2425	CALL	WCC	ELSE, RING BELL
005.163	303 012 015	2426	JMP	IROC	TRY AGAIN

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 60

10:41:55 17-FEB-82

2428	**	IOA1	- INPUT OCTAL ADDRESS	
2429	*			
2430	*	IOA1	IS A CONTINUATION OF *IOA* AND INPUTS A SPLIT OCTAL ADDRESS	
2431	*		WITHOUT REQUIRING LEADING ZEROS	
2432	*			
2433	*	ENTRY	(H,L) = ADDRESS + 1 WHERE INPUT ADDRESS IS TO BE PLACED	
2434	*		(A) = FIRST OCTAL CHARACTER IF 'C' IS SET	
2435	*	EXIT	(D,E) = INPUT ADDRESS	
2436	*		(A) = LAST INPUT CHARACTER	
2437	*	USES	A,D,E,H,L,F	
2438				
2439				
005.166	305	2440	IUAI	PUSH B SAVE (B,C)
005.167	102	2441	MOV	B,D (B) = TERMINATION CHARACTER
005.170	036 000	2442	MVI	E,0 CLEAR PSEUDO FLAGS
005.172	345	2443	PUSH	H SAVE ADDRESS WHERE INPUT IS TO BE PLACED
005.173	041 000 000	2444	LXI	H,0 SET NEW VALUE TO ZERO
005.176	324 262 003	2445	I0A2	CNC RCC IF CARRY SET, FIRST CHARACTER IS IN ACC
005.201	315 271 005	2446	CALL	I0C CHECK VALIDITY
005.204	332 230 005	2447	JC	I0A3 IF < OCTAL
		2448		
005.207	315 302 003	2449	CALL	HCC ECHO OCTAL CHARACTER
005.212	346 007	2450	ANI	00000111B GET BINARY VALUE
005.214	365	2451	PUSH	PSW SAVE NEW CHARACTER VALUE
005.215	051	2452	DAD	H SHIFT THREE TO MAKE ROOM FOR NEW CHARACTER
005.216	051	2453	DAD	H
005.217	051	2454	DAD	H
005.220	365	2455	PUSH	PSW SAVE CARRY FROM DAD
005.221	321	2456	POP	D SAVE FLAG RESULT IN E
005.222	361	2457	POP	PSW RETURN NEW CHARACTER VALUE TO (A)
005.223	205	2458	ADD	L
005.224	157	2459	MOV	L,A
005.225	303 176 005	2460	JMP	I0A2 SEE IF MORE CHARACTERS
		2461		
005.230	270	2462	I0A3	CMP B TERMINATING CHARACTER?
005.231	312 245 005	2463	JZ	I0A4 IF EQUAL
		2464		
005.234	076 007	2465		
005.236	315 302 003	2466	MVI	A,A,BEL ELSE, DING BELL
005.241	247	2467	CALL	HCC
005.242	303 176 005	2468	ANA	A CLEAR CARRY
		2469	JMP	I0A2
		2470		
		2471	*	END OF INPUT, PUT VALUE IN MEMORY AND EXIT
		2472		
005.245	315 302 003	2473	I0A4	CALL HCC ECHO CHARACTER
005.250	127	2474	MOV	D,A LAST CHARACTER TO D
005.251	325	2475	PUSH	D
005.252	361	2476	POP	PSW (PSW) = RESULT OF DAD
005.253	174	2477	MOV	A,H MAKE (H) INTO SPLIT OCTAL
005.254	037	2478	RAR	
005.255	147	2479	MOV	H,A RESTORE LAST INPUT CHARACTER
005.256	172	2480	MOV	A,D (D,E) = INPUT ADDRESS
005.257	353	2481	XCHG	
005.260	341	2482	POP	H (H,L) = LOCATION TO PLACE THIS ADDRESS
005.261	162	2483	MOV	M,D

10:41:56 17-FEB-82

005.262	053	2484	DCX	H
005.263	163	2485	MOV	M,E
005.264	301	2486	POP	B
005.265	311	2487	RET	RESTORE (B,C)

2489 ** IOC - INPUT OCTAL CHARACTER

2490 *
 2491 *
 2492 * ENTRY NONE
 2493 * EXIT (A) = INPUT CHARACTER
 2494 * 'C' = SET IF CHARACTER NOT OCTAL
 2495 * USES A,F

2496

2497

005.266	315 262 003	2498	IODO	CALL	RCC	INPUT CHARACTER
005.271	376 060	2499	IOC.	CPI	"0"	
005.273	330	2500	RC			IF CHARACTER < OCTAL
	2501					
005.274	376 070	2502	CPI	"8"		CHARACTER > OCTAL?
005.276	077	2503	CMC			'C' IF GREATER THAN
005.277	311	2504	RET			

2506 ** TOA - TYPE OCTAL ADDRESS

2507 *
 2508 * TOA OUTPUTS TO THE CONSOLE A CRLF, THE SPCECIFIED ADDRESS AND A SPACE
 2509 *
 2510 * ENTRY (H,L) = ADDRESS TO BE DISPLAYED
 2511 * EXIT NONE
 2512 * USES A,B,C,F

2513

2514

005.300	076 015	2515	TOAO	MVI	A,A,CR	CRLF
005.302	315 370 005	2516		CALL	WCR.	
	2517					
005.305	174	2518	TOA.	MOV	A,H	ADDRESS
005.306	315 322 005,	2519		CALL	TOBO	
005.311	175	2520		MOV	A,L	
005.312	315 322 005	2521		CALL	TOBO	
	2522					
005.315	076 040	2523		MVI	A," "	SPACE
005.317	303 302 003	2524		JMP	WCC	

		2526	**	TOB - TYPE OCTAL BYTE	
		2527	*		
		2528	*	TOB OUTPUTS TO THE CONSOLE IN OCTAL, THE BYTE IN A	
		2529	*		
		2530	*	ENTRY (A) = BYTE TO BE OUTPUT	
		2531	*	EXIT NONE	
		2532	*	USES A,F	
		2533			
		2534			
005.322	305	2535	TOB0	PUSH B	
005.323	006 002	2536		MVI B,2	NUMBER OF CHARACTERS - 1
005.325	117	2537		MOV C,A	SAVE ORIGINAL BYTE
005.326	247	2538		ANA A	CLEAR CARRY
005.327	037	2539		RAR	
005.330	037	2540		RAR	SHIFT TOP BYTE TO LSB
005.331	037	2541		RAR	
005.332	037	2542	TOB1	RAR	SHIFT MIDDLE BYTE TO LSB
005.333	037	2543		RAR	
005.334	037	2544		RAR	
005.335	346 007	2545		ANI 00000111B	MASK FOR HALF ASCII
005.337	366 060	2546		ORI 00110000B	MAKE WHOLE ASCII
005.341	315 302 003	2547		CALL WCC	OUTPUT TO CONSOLE
005.344	171	2548		MOV A,C	GET ORIGINAL BYTE
005.345	005	2549		DCR B	
005.346	302 332 005	2550		JNZ TOB1	IF SECOND BYTE STILL NEEDS TO BE OUTPUT
		2551			
005.351	346 007	2552		ANI 00000111B	ELSE, OUTPUT LAST CHARACTER
005.353	366 060	2553		ORI 00110000B	
005.355	301	2554		POP B	
005.356	303 302 003	2555		JMP WCC	

		2557	**	WCR - WAIT FOR A CARRIAGE RETURN	
		2558	*		
		2559	*	WCR INPUTS CHARACTERS FROM THE CONSOLE UNTIL A CARRIAGE RETURN	
		2560	*	IS RECEIVED AND THEN ECHOS A CRLF	
		2561	*		
		2562	*		
		2563	*	ENTRY NONE	
		2564	*	EXIT NONE	
		2565	*	USES A,F	
		2566			
		2567			
005.361	315 262 003	2568	WCR	CALL RCC	INPUT CHARACTER
005.364	376 015	2569		CPI A,CR	
005.366	040 371	2570		JR NZ,WCR	IF NOT A CR
		2571			
005.370	315 302 003	2572	WCR.	CALL WCC	ELSE, ECHO CR
005.373	076 012	2573		MVI A,A,LF	LINE FEED
005.375	303 302 003	2574		JMP WCC	

2576 ** VIEW3 - *VIEW* CONTINUATION

2577 *

2578

006.000	302	066	002	2579	VIEW3	JNZ	VIEW2	IF NOT END OF LINE
006.003	315	355	003	2580		CALL	VIEW9	END OF LINE, RESTORE ADDRESS
006.006	076	015		2581		MVI	A,A.CR	
006.010	303	355	007	2582		JMP	VIEW3A.	DO ASCII STUFF
000.010				2583		ERRMI	6023A-*	
006.023				2584		ORG	6023A	

2586 *** DAT - DATA BYTE OUTPUT TO Z-47

2587 *

2588 * ENTRY: (A) = BYTE TO OUTPUT

2589 *

2590 * EXIT: (A) = BYTE TO OUTPUT

2591 * (D) = S.DTR

2592 *

2593 * USE: AF, D

2594

006.023				2595	DAT	EQU	*	
006.023	026	200		2596		MVI	D,S.DTR	SET MATCH CONDITION TO DATA TRANSFER
006.025	030	002		2597		JR	COM1	REQUEST BIT
000.000				2598		ERRMI	6027A-*	
006.027				2599		ORG	6027A	

2601 *** COM - OUTPUT COMMAND BYTE TO Z-47

2602 *

2603 * ENTRY: (A) = COMMAND BYTE

2604 *

2605 * EXIT: (A) = COMMAND BYTE

2606 * (D) = S.DON

2607 *

2608 * USE: AF, D

2609

006.027				2610	COM	EQU	*	
006.027	026	040		2611		MVI	D,S.DON	SET MATCH CONDITION TO DONE BIT
006.031	365			2612	COM1	PUSH	PSW	
006.032	315	170	006	2613	WTDON1	CALL	IN.	READ CONTROLLER STATUS REGISTER
006.035	242			2614		ANA	D	GET MATCH BIT ONLY
006.036	050	372		2615		JR	Z,WTDON1	IF NO MATCH, WAIT
006.040	361			2616		POP	PSW	
006.041	303	156	010	2617		JMP	COM2	CONTINUE *COM* ROUTINE

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:41:59 17-FEB-82

Page 64

000.001	2619	ERRMI	6045A-*	
006.045	2620	ORG	6045A	
	2621	**	HRNX - HORN EXTENSION ROUTINE	
	2622	*		
	2623	*	THIS IS AN EXTENSION TO *HORN* TO MAKE ROOM FOR A JUMP	
006.045 056 011	2624			
006.047 163	2625	HRNX	MVI	L,#CTLFLG
006.050 321	2626		MOV	H,E
	2627		POP	D
006.051 341	2628		POP	H
006.052 311	2629		RET	
	2631	**	NOISE - DING BELL ON CONSOLE	
	2632	*		
	2633	*	THIS IS A MODIFICATION TO ALLOW THE H88/H89 TO USE THE CONSOLE BELL	
	2634			
006.053 076 007	2635	NOISE	MVI	A,A.BEL
006.055 315 302 003	2636		CALL	HCC
006.060 303 140 002	2637		JMP	HORN
				CONTINUE WITH NORMAL HORN DELAY
	2639	**	OUT.	- OUTPUT BYTE TO Z-47
	2640	*		
	2641	*	ENTRY:	(A) = OUTPUT BYTE
	2642	*		
	2643	*	EXIT:	NONE
	2644	*		
	2645	*	USE:	NONE
	2646			
006.063	2647	OUT.	EQU	*
006.063 305	2648		PUSH	B
006.064 107	2649		MOV	B,A
006.065 072 120 041	2650		LDA	PRIM
006.070 117	2651	OUT.1	MOV	C,A
006.071 170	2652		MOV	A,B
	2653	*	OUT	(C),A
006.072 355 171	2654		DB	355Q,171Q
006.074 301	2655		POP	B
006.075 311	2656		RET	
	2658			
000.002	2658	ERRMI	6100A-*	
006.100	2659	ORG	6100A	
	2660	**	TYPMSG - TYPE MESSAGE TO CONSOLE	
	2661	*		
	2662	*	TYPMSG OUTPUTS AN ASCII MESSAGE FROM MEMORY TO THE CONSOLE	
	2663	*	UNTIL A NULL IS SENSED	
	2664	*		
	2665	*	ENTRY (H,L) = ADDRESS OF MESSAGE	

	2666	*	EXIT	NONE	
	2667	*	USES	A,H,L,F	
	2668				
	2669				
006.100	176	2670	TYPMSG	MOV A,M	GET CHARACTER
006.101	267	2671	ORA A		SEE IF A NULL
006.102	310	2672	RZ		IF NULL, EXIT
	2673				
006.103	315 302 003	2674	CALL NCC		ELSE OUTPUT CHARACTER TO CONSOLE
006.106	043	2675	INX H		POINT TO NEXT CHARACTER
006.107	030 367	2676	JR TYPMSG		OUTPUT IT

	2678	**	RDBLCK	- INPUT A BLOCK FROM Z-47	
	2679	*			
	2680	*	RDBLCK	READS IN A BLOCK FROM THE DISK CONTROLLER	
	2681	*			
	2682	*	ENTRY:	HL = LOAD ADDRESS	
	2683	*		C = SIDE/UNIT/SECTOR	
	2684	*			
	2685	*	EXIT:	BLOCK IN READ IN MEMORY	
	2686	*			
	2687	*	USES:	ALL	
	2688	*			
	2689				
006.111	076 007	2690	RDBLCK	MVI A,DD.REAB	
006.113	315 027 006	2691	CALL	COM	SEND THE COMMAND
006.116	257	2692	XRA A		FOR TRACK 0
006.117	315 023 006	2693	CALL	DAT	SEND IT TO DISK
006.122	171	2694	MOV A,C		LOAD SIDE/UNIT/SECTOR
006.123	315 023 006	2695	CALL	DAT	SEND IT TO DISK
	2696				
006.126	315 067 001	2697	RD2	CALL PIN	GET STATUS
006.131	332 104 010	2698	JC	HDM	'C' SET IF S.DON
	2699				
006.134	167	2700	MOV M,A		
006.135	043	2701	INX H		
006.136	030 366	2702	JR RD2		CONTINUE TRANSFER

	2704	**	OUT1.	- OUTPUT BYTE TO PORT (PRIM+1)	
	2705	*			
	2706	*	ENTRY:	(A) = OUTPUT PORT	
	2707	*			
	2708	*	EXIT:	NONE	
	2709	*			
	2710	*	USE:	NONE	
	2711				
006.140		2712	OUT1.	EQU *	
006.140	305	2713	PUSH B		
006.141	107	2714	MOV B,A		SAVE THE OUTPUT DATA
006.142	072 120 041	2715	LDA PRIM		GET PORT ADDRESS

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:42:00 17-FEB-82

Page 66

006.145 074	2716	INR	A	SET TO (PRIM+1)
006.146 030 320	2717	JR	OUT.1	GO TO OUTPUT ROUTINE

2719 **	IN1.	- INPUT BYTE FROM (PRIM+1) PORT	
2720 *			
2721 *	ENTRY:	NONE	
2722 *			
2723 *	EXIT:	(A) = INPUT BYTE	
2724 *			
2725 *	USE:	A	
2726			
006.150	2727 IN1.	EQU *	
006.150 305	2728 PUSH B		
006.151 072 120 041	2729 LDA PRIM		GET PORT ADDRESS
006.154 074	2730 INR A		SET TO (PRIM+1)
006.155 247	2731 ANA A		
006.156 030 014	2732 JR IN.1		GO TO INPUT ROUTINE

000.005	2734	ERRM	6165A-*
006.165	2735	ORG	6165A
	2736 **	MSG.GO - (G)D	
	2737 *		
	2738 *	"GO"	
	2739		
006.165 157 040 000	2740 MSG.GO DB	'o ',0	

2742 **	IN.	- INPUT BYTE FROM PORT (PRIM)	
2743 *			
2744 *	ENTRY:	NONE	
2745 *			
2746 *	EXIT:	(A) = INPUT BYTE	
2747 *			
2748 *	USE:	A	
2749			
006.170	2750 IN.	EQU *	
006.170 305	2751 PUSH B		
006.171 072 120 041	2752 LDA PRIM		GET PORT ADDRESS
006.174 117	2753 IN.1 MOV C,A		SET ADDR. TO REG C
006.175 355 170	2754 * IN A,(C)		
006.177 301	2755 DB 3550,1700		INPUT BYTE
006.200 311	2756 POP B		
	2757 RET		

MTR90-1 - H/Z-89 MONITOR
SUPPORT ROUTINES

#09.02.01.

MSG.SUB

Unix H8ASM V1.4.1 5-Jul-80
10:42:01 17-FEB-82

Page 67

000.000 2759 ERRMI 6201A-*
006.201 2760 ORG 6201A
2761 ** MSG.SUB - (S)UBSTITUTE
2762 *
2763 * "SUBSTITUTE"
2764
006.201 165 142 163 2765 MSG.SUB DB "ubstitute ",0

2767 ** MSG.PC - (P)ROGRAM COUNTER
2768 *
2769 * "PROGRAM COUNTER"
2770
006.214 162 157 147 2771 MSG.PC DB "rogram Counter ",0

2773 ** MSG.BT - (B)OOT
2774 *
2775 * "BOOT"
2776
006.234 157 157 164 2777 MSG.BT DB "oot",0

2780 *** SPEED - ROTATIONAL SPEED TEST FOR 5.25 INCH DISK DRIVE
2781 *
2782 * *SPEED* IS USED ONLY FOR GROSS ADJUSTMENT OF DRIVE ROTATIONAL
2783 * SPEED IF THE FIRST READ/WRITE TEST OF THE UNIT FAILS DURING SET UP.
2784 *
2785 * USE OF *SPEED* IS AS FOLLOWS:
2786 *
2787 * 1. ENTER "GO AND THE ENTRY ADDRESS OF *SPEED*
2788 * 2. ADJUST DRIVE SPEED UNTIL DATA AT DISPLAYED
2789 * EQUALS 200
2790 * A. IF SPEED < 200, TURN ADJUSTMENT CLOCKWISE
2791 * B. IF SPEED > 200, TURN COUNTERCLOCKWISE
2792 *
2793 * THE ABOVE TEST ADJUSTS SY0:. TO ADJUST SY1:, USE HOOS

2795 ** LABLE EQUIVALENCES
2796 *
2797 * I/O PORTS
000.177 2798 OP.DC EQU 177Q DRIVE CONTROL OUTPUT PORT
000.177 2799 IP.DS EQU 177Q DRIVE STATUS INPUT PORT

2801 * MASKS
2802 *
000.001 2803 DS.HOLE EQU 00000001B DRIVE STATUS SECTOR/INDEX HOLE

2805 * CONSTANTS
2806 *
000.022 2807 ONDRO EQU 022Q TURN ON SY0:

006.240	041 371 006	2809	SPEED	LXI	H,MSG.SPD	OUTPUT SPEED MESSAGE
006.243	315 100 006	2810		CALL	TYPMSG	
006.246	076 000	2811		MVI	A,0	SET FLAG AT IOWRK FOR "WORKING" MESSAGE
006.250	062 002 040	2812		STA	IOWRK	
006.253	076 022	2813		MVI	A,ONDRO	TURN ON DRIVE ZERO
006.255	323 177	2814		OUT	OP,DC	
006.257	052 033 040	2815	SPEED1	LHLD	TICCNT	GET TICK COUNTER
006.262	174	2816		MOV	A,H	FORM TWO'S COMPLEMENT OF TICK COUNTER
006.263	057	2817		CMA		
006.264	127	2818		MOV	D,A	(D,E) = NEGATIVE TICK COUNTER
006.265	175	2819		MOV	A,L	
006.266	057	2820		CMA		
006.267	074	2821		INR	A	
006.270	137	2822		MOV	E,A	
006.271	322 275 006	2823		JNC	SPEED2	IF NO CARRY FROM LSB
		2824				
006.274	024	2825		INR	D	ELSE, INCREMENT MSB
006.275	001 000 000	2826	SPEED2	LXI	B,0	ZERO REV COUNTERS
006.300	333 177	2827	SPEED3	IN	IP.DS	INPUT DISK STATUS
006.302	346 001	2828		ANI	DS.HOLE	MASK FOR SECTOR/INDEX PULSES
006.304	312 300 006	2829		JZ	SPEED3	IF NO HOLE PRESENT
		2830				
		2831	*	HOLE PRESENT, WAIT FOR IT TO LEAVE		
		2832	*			
006.307	333 177	2833	SPEED4	IN	IP.DS	GET DISK STATUS
006.311	346 001	2834		ANI	DS.HOLE	GET HOLE PULSES
006.313	302 307 006	2835		JNZ	SPEED4	WAIT UNTIL HOLE IS GONE AND WE HAVE MEDIA
		2836				
006.316	004	2837		INR	B	INCREMENT HOLE COUNTER
006.317	170	2838		MOV	A,B	TEST FOR FIVE REVOLUTIONS
006.320	376 070	2839		CPI	56	
006.322	302 300 006	2840		JNZ	SPEED3	NOT FIVE, WAIT FOR MORE HOLES
		2841				
		2842	*	HAVE FIVE REVS, DISPLAY DIFFERENCE OF TICK COUNTER AND EXPECTED TIME DIF		
		2843	*			
006.325	052 033 040	2844		LHLD	TICCNT	GET CURRENT TICK VALUE
006.330	031	2845		DAD	D	SUBTRACT START VALUE
006.331	021 214 376	2846		LXI	D,377377A-500+1+2000	SUBTRACT 500 FOR REVS, +2000 FOR OFFSET
006.334	031	2847		DAD	D	(H,L) = OFFSET RESULT
006.335	345	2848		PUSH	H	SAVE RESULT
006.336	041 062 007	2849		LXI	H,MSG.WRK	POINT TO "WORKING" MESSAGE
006.341	072 002 040	2850		LDA	IOWRK	GET "WORKING" FLAG
006.344	356 001	2851		XRI	1	INVERT LOWER BIT
006.346	062 002 040	2852		STA	IOWRK	SAVE NEW VALUE
006.351	302 357 006	2853		JNZ	SPEED5	IF TO DISPLAY "WORKING"
		2854				
006.354	041 100 007	2855		LXI	H,MSG.HSS	POINT TO "HOME", "SPACES", AND SPEED MSG
006.357	315 100 006	2856	SPEED5	CALL	TYPMSG	OUTPUT MESSAGE
006.362	341	2857		POP	H	GET TEST RESULT
006.363	315 305 005	2858		CALL	TOA.	OUTPUT RESULT TO CONSOLE
006.366	303 257 006	2859		JMP	SPEED1	PERFORM ANOTHER SAMPLE

MTR90-1 - H/Z-89 MONITOR \$09.02.01.
 SPEED - ROTATIONAL SPEED TEST FOR H89 DISK DRIVE

MSG.SPD

Unix H8ASM V1.4.1 5-Jul-80
 10:42:06 17-FEB-82

Page 70

	2861	**	MSG.SPD - SPEED TEST MESSAGE	
	2862	*		
	2863	*	" Disk drive rotational speed test.	
	2864	*		
	2865	*		
	2866	*	Drive speed = "	
	2867			
006.371	033	105	012	2868 MSG.SPD DB A.ESC,"E",A.LF
006.374	011	104	151	2869 DB "
007.041	011	011	104	2870 DB " Drive speed = "
007.061	000			2871 DB 0

	2873	**	MSG.WRK - "WORKING" MESSAGE FOR SPEED TEST	
	2874	*		
	2875	*	DISPLAYS "WORKING" AT HOME POSITION AND RETURNS CURSOR TO SPEED =	
	2876			
007.062	033	110	2877 MSG.WRK DB A.ESC,"H"	CURSOR HOME
007.064	127	157	2878 DB "Working"	
007.073	033	131	2879 DB A.ESC,"Y#>"	CURSOR ADDRESS OF SPEED = VALUE
007.077	000		2880 DB 0	END MESSAGE

	2882	**	MSG.HSS - BLANKS "WORKING" MESSAGE	
	2883	*		
	2884			
007.100	033	110	2885 MSG.HSS DB A.ESC,"H"	CURSOR HOME
007.102	040	040	2886 DB "	BLANKS
007.111	033	131	2887 DB A.ESC,"Y#>"	CURSOR ADDRESS OF SPEED = VALUE
007.115	000		2888 DB 0	END MESSAGE

```

2891 ** DYMEM - DYNAMIC MEMORY TEST
2892 *
2893 * DYMEM TESTS THE DYNAMIC MEMORY IN THE H88/H89 BY PLACING
2894 * A KNOWN PATTERN IN EACH DYNAMIC MEMORY CELL AND THEN
2895 * PERFORMING A READ, INCREMENT, READ SEQUENCE WITH A DELAY
2896 * BETWEEN EACH PASS OF THE TEST
2897 *
2898 *
2899 * ENTRY NONE
2900 *
2901 * EXIT ON RESET
2902 *
2903 * USES A,B,C,D,E,H,L,F,A*,F*,IX,IY
2904
2905
007.116 076 000 2906 DYMEM MVI A,0 MAKE SURE CLOCK AND SINGLE STEP ARE OFF
007.120 323 362 2907 OUT H88.CTL
2908
2909 * DETERMINE END OF MEMORY
2910 *
2911
007.122 041 000 040 2912 DYMEM1 LXI H,START
007.125 076 001 2913 MVI A,1
007.127 066 000 2914 DYMEM2 MVI H,0 SET RAM TO ZERO
007.131 064 2915 INR H SET MEMORY TO ONE
007.132 276 2916 CMP M SEE IF (A) = (H,L)
007.133 040 003 2917 JR NZ,DYMEM3 IF NOT EQUAL, THE END OF RAM HAS BEEN REACHED
2918
007.135 043 2919 INX H ELSE, POINT TO NEXT LOCATION IN RAM
007.136 030 367 2920 JR DYMEM2
2921
2922
007.140 053 2923 DYMEM3 DCX H POINT TO LAST GOOD LOCATION
007.141 353 2924 XCHG PUT ENDING ADDRESS IN D,E
007.142 041 303 007 2925 LXI H,MSG.RAM OUTPUT ENDING ADDRESS
2926
2927 * LD IX,DY3.3 RETURN ADDRESS
007.145 335 041 2928 DB MI.LDXA,MI.LDXB
007.147 201 011 2929 DW DY3.3
2930
007.151 030 112 2931 JR DYMSG
007.153 023 2932 DY3.7 INX D (D,E) = LAST BYTE OF RAM + 1
2933
2934 * TEST MEMORY
2935 *
007.154 006 001 2936 MVI B,1 (B) = CONTENTS OF RAM AFTER SIZING
007.156 041 231 003 2937 LXI H,MSG.PAS OUTPUT PASS MESSAGE
2938
2939 * LD IX,DYMEM4 RETURN ADDRESS
007.161 335 041 2940 DB MI.LDXA,MI.LDXB
007.163 167 007 2941 DW DYMEM4
2942
007.165 030 076 2943 JR DYMSG
2944
007.167 041 000 040 2945 DYMEM4 LXI H,START
007.172 176 2946 DYMEM5 MOV A,M READ CURRENT CONTENTS

```

MTR90-1 - H/Z-89 MONITOR
DYMEM - DYNAMIC MEMORY TEST

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:42:13 17-FEB-82

Page 72

007.173	270	2947	CMP	B	SEE IF CORRECT CONTENTS STILL REMAIN
007.174	302 307 000	2948	JNZ	DYMEM9	FAILURE, SEE IF AT END OF RAM
	2949				
007.177	074	2950	INR	A	
007.200	167	2951	MOV	H,A	INCREMENT RAM
007.201	276	2952	CMP	H	SEE IF WRITE WAS SUCCESSFUL
007.202	302 307 000	2953	JNZ	DYMEM9	
	2954				
007.205	043	2955	INX	H	
007.206	175	2956	MOV	A,L	GET LSB AND TEST FOR REACHING END OF RAM
007.207	273	2957	CMP	E	
007.210	040 360	2958	JR	NZ,DYMEM5	IF LSB NOT EQUAL
	2959				
007.212	174	2960	MOV	A,H	CHECK LSB
007.213	272	2961	CMP	D	
007.214	040 354	2962	JR	NZ,DYMEM5	
	2963				
	2964 *				HAVE REACHED END OF MEMORY!
	2965 *				OUTPUT LAST VALUE TESTED
	2966 *				
	2967				
007.216	303 336 016	2968	JMP	DYMEM5	HOW MANY TO BACK SPACE?
	2969				
007.221		2970	DYMEM5.5	EQU	*
	2971				
	2972 *		LD	IY,DY5.53	RETURN ADDRESS
007.221	375 041	2973	DB	MI.LDYA,MI.LDYB	
007.223	230 007	2974	DW	DY5.53	
	2975				
007.225	303 143 003	2976	JMP	DYASC	
	2977				
007.230	045	2978	DY5.53	DCR	H
007.231	040 366	2979	JR	NZ,DYMEM5.5	
	2980				
007.233	004	2981	INR	B	SHOW NEXT PASS VALUE
007.234	170	2982	MOV	A,B	VALUE TESTED
	2983				
	2984 *		LD	IX,DYMEM6	RETURN ADDRESS
007.235	335 041	2985	DB	MI.LDXA,MI.LDXB	
007.237	273 000	2986	DW	DYMEM6	
	2987				
007.241	303 160 003	2988	JMP	DYBYT	
	2989				
	2990				
007.244	041 000 000	2995	DY10.5	LXI	H,O
007.247	006 002	2996	MVI	B,2	DELAY AND DING BELL AGAIN 2 LOOPS
007.251	045	2997	DYMEM11	DCR	H
007.252	040 375	2998	JR	NZ,DYMEM11	
	2999				
007.254	055	3000	DCR	L	
007.255	040 372	3001	JR	NZ,DYMEM11	
	3002				

MTR90-1 - H/Z-89 MONITOR
DYMEM - DYNAMIC MEMORY TEST

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 73
10:42:16 17-FEB-82

007.257 005	3003	DCR	B
007.260 040 367	3004	JR	NZ,DYMEM11
	3005		
007.262 303 252 013	3006	JMP	DYMEM10 AGAIN

3008 ** DYMSG - DYNAMIC RAM TEST MESSAGE OUTPUT ROUTINE
3009 *
3010 * ENTRY (H,L) = MESSAGE ADDRESS
3011 * (IX) = RETURN ADDRESS
3012 *
3013 * EXIT TO (IX)
3014 *
3015 * USES A,H,L,F,IY
3016
3017

007.265 176 3018 DYMSG MOV A,M GET MESSAGE BYTE

3019

007.266 375 041 3020 * LD IY,DYMSG.5 RETURN ADDRESS

3021 DB MI.LDYA,MI.LDYB

007.270 275 007 3022 DW DYMSG.5

3023

007.272 303 143 003 3024 JMP OYASC OUTPUT ASCII

3025

007.275 267 3026 DYMSG.5 ORA A SEE IF NULL TO END STRING

007.276 043 3027 INX H POINT TO NEXT CHARACTER

007.277 040 364 3028 JR NZ,DYMSG IF NOT DONE YET

3029

007.301 335 351 3030 * JP (IX) RETURN TO CALLER

3031 DB MI.JIXA,MI.JIXB

3033 ** MSG.RAM - RAM TEST MESSAGE

3034 *

3035

007.303 033 105 3036 MSG.RAM DB A.ESC,'E'

007.305 104 171 156 3037 DB 'Dynamic RAM test'

007.325 015 012 012 3038 DB A.CR,A.LF,A.LF

007.330 011 040 114 3039 DB ' LHA = '

007.340 000 3040 DB 0

3042 ** MSG.EQ - EQUALS MESSAGE

3043 *

3044

007.341 040 075 040 3045 MSG.EQ DB ' = '

007.344 000 3046 DB 0

3047

007.345 107 101 103 3048 DB 'GAC.'

		3050	**	VIEW3A - *VIEW* CONTINUED		
		3051	*			
		3052				
007.351	315 032 011	3053	VIEW3A	CALL	VIEW8	GET BOUNDRIES
007.354	353	3054		XCHG		
007.355	315 111 011	3055	VIEW3A.	CALL	VIEW12	PRINT CRLF AND ADDRESS
007.360	303 055 001	3056		JMP	VIEW1	AND START NEXT LINE
		3057				
007.363	174	3058	VIEW4	MOV	A,H	
007.364	270	3059		CMP	B	COMPARE BC AND DE
007.365	300	3060		RNZ		
007.366	175	3061		MOV	A,L	
007.367	271	3062		CMP	C	
007.370	311	3063		RET		

	3066	**	ENTRY POINT FOR FLOPPY DISK ROTATIONAL SPEED TEST		
	3067	*			
000.001	3068	ERRMI	10000A-6-*	MUST BE SIX BYTES BEFORE END	
007.372	3069	ORG	10000A-6		
	3070				
007.372	303 240 006	3071	ESPEED	JMP	SPEED

	3073	**	ENTRY POINT FOR DYNAMIC MEMORY TEST		
	3074	*			
000.000	3075	ERRNZ	10000A-3-*	MUST BE THREE BYTES BEFORE END	
	3076				
007.375	303 032 016	3077	EDYMEM	JMP	MEMORY.

	3079	**	Z47X - EXTENSION TO Z47 ROUTINE		
	3080	*			
	3081				
010.000	315 063 006	3082	Z47X	CALL	OUT.
				SEND RESET COMMAND	
	3083				
010.003	315 104 010	3084		CALL	WON
				WAIT FOR HIM TO WAKE UP	
010.006	332 171 002	3085		JC	NODEV
				ERROR WAITING FOR DONE	
	3086				
000.001		3087		IF	.DEBUG
		3088		MVI	A,1
				FLAG PAST THE RESET	
		3089		STA	DBFLG
		3090		ENDIF	
		3091			
010.011	315 142 010	3092	Z47X.	CALL	RRDY
010.014	332 171 002	3093		JC	NODEV
010.017	315 142 010	3094		CALL	RRDY
010.022	332 171 002	3095		JC	NODEV
	3096				
000.001		3097		IF	.DEBUG
		3098		MVI	A,2
		3099		STA	DBFLG
		3100		ENDIF	FLAG THRU RRDY
		3101			
010.025	072 061 041	3102		LDA	AIO.UNI
		3103		MOV	B,A
010.031	257	3104		XRA	A
010.032	315 155 012	3105		CALL	BITS
010.035	245	3106		ANA	L
010.036	040 351	3107		JR	SET UNIT BIT MASK
	3108				CHECK AGAINST READY FLAGS
000.001		3109		IF	.DEBUG
		3110		MVI	A,8
		3111		STA	DBFLG
		3112		ENDIF	FLAG PAST READ
		3113			
010.040	076 002	3114		MVI	A,DD.RAS
010.042	315 027 006	3115		CALL	COM
				READ AUX STAT	

010.045	171	3116	MOV	A,C
010.046	315 023 006	3117	CALL	DAT
010.051	315 067 001	3118	CALL	PIN
010.054	332 171 002	3119	JC	NODEV
		3120		PREMATURE DONE
000.001		3121	IF	.DEBUG
		3122	MVI	A,9
		3123	STA	DBFLG
		3124	ENDIF	FLAG PAST RAS
		3125		
		3126	*	SET TRANSFER COUNT TO 9 SECTORS
		3127		
010.057	076 003	3128	MVI	A,DD.LSC
010.061	315 027 006	3129	CALL	COM
		3130		SEND "LOAD COUNT"
010.064	257	3131	XRA	A
010.065	315 023 006	3132	CALL	DAT
		3133		SEND HIGH ORDER BYTE
010.070	076 012	3134	MVI	A,10
010.072	315 023 006	3135	CALL	DAT
		3136		SEND LOW ORDER BYTE
010.075	315 104 010	3137	CALL	WDN
010.100	332 171 002	3138	JC	NODEV
		3139		WAIT FOR DONE, THEN EXIT
010.103	311	3140	RET	

3142	**	WDN	-	WAIT FOR DONE
3143	*			
3144	*			WDN waits for the done bit to be set.
3145	*			
3146	*			time-out is in effect at this point
3147	*			
3148	*			ENTRY: NONE
3149	*			
3150	*		PSW	"C" SET IF ERROR
3151	*			"C" CLEAR IF DONE
3152	*			
3153	*		USES:	PSW
3154	*			
3155				
010.104	363	3156	DI	
010.105	305	3157	PUSH	B
010.106	001 000 175	3158	LXI	B,WDNA
		3159		
010.111	013	3160	WDN1	DCX B
010.112	170	3161	MOV	A,B
010.113	261	3162	ORA	C
010.114	067	3163	STC	
010.115	050 020	3164	JR	Z,WDN2
		3165		
010.117	315 170 006	3166	CALL	IN.
010.122	346 040	3167	ANI	S.DON
010.124	050 363	3168	JR	Z,WDN1
				IF NOT DONE YET

		3169				
010.126	315 170 006	3170	CALL	IN.	S.ERR	VALID ONLY IF S.DON SET
010.131	346 001	3171	ANI	S.ERR		
010.133	067	3172	STC			
010.134	040 001	3173	JR	NZ,WDN2		IF ERROR BIT SET
		3174				
010.136	247	3175	ANA	A		CLEAR CARRY
		3176				
010.137	301	3177	WDN2	POP	8	
010.140	373	3178		EI		
010.141	311	3179	RET			ALL OK.
		3180				
175.000		3181	WDNA	EQU	32000	TIME OUT COUNTER

		3183	**	RRDY	- CHECK DEVICE READY	
		3184	*			
		3185	*	RRDY	RETURNS THE DEVICE READY BITS IN	
		3186	*		THE L REGISTER. BITS 'ON' INDICATE	
		3187	*		UNIT NOT READY.	
		3188	*			
		3189				
010.142	076 020	3190	RRDY	MVI	A,DD.RRDY	
010.144	315 027 006	3191	CALL	COM		
		3192				
010.147	315 067 001	3193	CALL	PIN		
		3194				
000.001		3195	IF	.DEBUG		
		3196	MVI	A,3	FLAG PAST PIN	
		3197	STA	DBFLG		
		3198	ENDIF			
		3199				
010.152	157	3200	MOV	L,A		
010.153	303 104 010	3201	JMP	WDN		

		3203	**	COM2 - *COM* ROUTINE CONTINUATION		
		3204	*			
		3205	*	OUTPUT COMMAND TO 47 AND THEN DELAY		
		3206	*			
		3207				
010.156	315 140 006	3208	COM2	CALL	OUT1.	SEND COMMAND BYTE
010.161	076 040	3209		MVI	A,400	
010.163	247	3210		ANA	A	CLEAR "Z"
		3211				
010.164	075	3212	COM3	DCR	A	
010.165	302 164 010	3213		JNZ	COM3	SHORT DELAY
		3214				
010.170	311	3215		RET		

		3217 **	VIEW5 - *VIEW* CONTINUED	
		3218 *		
		3219 *	VIEW5 DOES THE ASCII PORTION OF THE *VIEW* ROUTINE	
		3220 *		
		3221		
010.171	315 316 010	3222	VIEW5 CALL PCFA	PUSITION CURSOR FOR ASCII
010.174	176	3223	VIEH5A MOV A,M	GET A BYTE
010.175	247	3224	ANA A	CHECK PARITY
010.176	372 241 010	3225	JM VIEW7	
010.201	376 177	3226	CPI 1770	
010.203	312 212 010	3227	JZ VIEW5.	IF DELETE
010.206	376 040	3228	CPI "	PRINTABLE?
010.210	060 012	3229	JR NC,VIEH6	YES
010.212	345	3230	VIEW5. PUSH H	
010.213	041 024 011	3231	LXI H,VIEH.NPC	NON-PRINTABLE CHARACTER
010.216	315 100 006	3232	CALL TYPMSG	
010.221	341	3233	POP H	
010.222	030 003	3234	JR VIEW6.	
010.224	315 302 003	3235	VIEW6 CALL WCC	PRINT IT
010.227	315 363 007	3236	VIEW6. CALL VIEW4	
010.232	310	3237	RZ	IF LAST BYTE DONE
010.233	315 340 003	3238	CALL VIEW3.	CHECK FOR END
010.236	040 334	3239	JR NZ,VIEH5A	NO, DO MORE
010.240	311	3240	RET	
		3241		
010.241	346 177	3242	VIEW7 ANI 1770	STRIP PARITY
010.243	365	3243	PUSH PSH	SAVE IT
010.244	076 033	3244	MVI A,33Q	
010.246	315 302 003	3245	CALL WCC	
010.251	076 160	3246	MVI A,'p'	
010.253	315 302 003	3247	CALL WCC	GO TO REVERSE VIDEO
010.256	361	3248	POP PSW	
010.257	376 177	3249	CPI 1770	
010.261	312 270 010	3250	JZ VIEW7A	
010.264	376 040	3251	CPI "	
010.266	060 012	3252	JR NC,VIEW7.	
010.270	345	3253	VIEW7A PUSH H	
010.271	041 024 011	3254	LXI H,VIEH.NPC	
010.274	315 100 006	3255	CALL TYPMSG	
010.277	341	3256	POP H	
010.300	030 003	3257	JR VIEH7..	
010.302	315 302 003	3258	VIEW7. CALL WCC	PRINT IT
010.305	076 033	3259	VIEH7.. MVI A,33Q	
010.307	315 302 003	3260	CALL WCC	
010.312	076 161	3261	MVI A,'q'	EXIT REVERSE VIDEO
010.314	030 306	3262	JR VIEH6	AND FINISH UP
		3263		
010.316	345	3264	PCFA PUSH H	
010.317	315 112 015	3265	CALL CHKRAD	
010.322	041 017 011	3266	LXI H,PCF.MO	ASSUME OCTAL
010.325	312 333 010	3267	JZ PCFAA	
010.330	041 012 011	3268	LXI H,PCF.MH	WAS HEX
010.333	315 100 006	3269	PCFAA CALL TYPMSG	
010.336	341	3270	POP H	
010.337	076 001	3271	MVI A,1	Skip 1 space per letter
		3272		

010.341	345	3273	PCFA.	PUSH	H
010.342	305	3274		PUSH	B
010.343	107	3275		MOV	B,A
					B=SKIP COUNT
010.344	315 112 015	3276		CALL	CHKRAD
010.347	312 357 010	3277		JZ	PCFA1
		3278			
010.352	076 360	3279		MVI	A,1111000B MASK FOR HEX
010.354	303 361 010	3280		JMP	PCFA2
		3281			
010.357	076 370	3282	PCFA1	MVI	A,11111000B MASK FOR OCTAL
		3283			
010.361	245	3284	PCFA2	ANA	L MASK LOW ORDER, RESULT IN A
		3285			
010.362	275	3286	PCFA3	CMP	L
010.363	312 007 011	3287		JZ	PCFA4 IF A=L, DONE
010.366	055	3288		DCR	L
010.367	365	3289		PUSH	PSW
010.370	305	3290		PUSH	B
010.371	076 040	3291	PCFA3.	MVI	A, " "
010.373	315 302 003	3292		CALL	WCC
010.376	005	3293		DCR	B
010.377	302 371 010	3294		JNZ	PCFA3.
		3295			
011.002	301	3296		POP	B
011.003	361	3297		POP	PSW
011.004	303 362 010	3298		JMP	PCFA3 PRINT (B) SPACES AND CHECK AGAIN
		3299			
011.007	301	3300	PCFA4	POP	B
011.010	341	3301		POP	H
011.011	311	3302		RET	
		3303			
011.012	033 131 001	3304	PCF.MH	D8	33Q,"Y",1,54+31,0 Hex Version
011.017	033 131 001	3305	PCF.MO	D8	33Q,"Y",1,40+31,0 Octal Version
		3306			
011.024	033 106 136	3307	VIEW.NPC	D8	33Q,"F",33Q,"G",0 ESC,GRAPHICS,i,ESC,NO-Graphics

		3309	**	VIEW8 - GET BOUNDRIES	
		3310	*		
		3311	*	VIEW8 GETS THE BOUNDRIES OF THE *VIEW* COMMAND	
		3312	*		
		3313			
011.032	315 012 015	3314	VIEW8	CALL	IROC GET CHARACTER OR RETURN
011.035	040 012	3315		JR	NZ,VIEW8A
		3316			
011.037	052 072 040	3317		LHLD	VEWHLD GET LAST ON
011.042	043	3318		INX	H START AT NEXT ONE
011.043	353	3319		XCHG	
011.044	001 000 000	3320		LXI	B,0 SET LENGTH TO 0
011.047	030 003	3321		JR	VIEW8B
		3322			
011.051	315 073 016	3323	VIEW8A	CALL	GET8ND. "C" IS SET, FIRST CHARACTER IN A
		3324			
011.054	151	3325	VIEW8B	MOV	L,C

MTR90-1 - H/Z-89 MONITOR
ENTRY POINTS FOR HARDWARE TESTS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 80
10:42:40 17-FEB-82

011.055	140	3326	MOV	H,B	
011.056	042 072 040	3327	SHLD	VEWHLD	SAVE LAST
		3328			
011.061	170	3329	MOV	A,B	
011.062	261	3330	DRA	C	LAST = 0
011.063	300	3331	RNZ		ND, OK
011.064	041 177 000	3332	LXI	H,200Q-1	ADD 177Q TO VALUE
011.067	031	3333	DAD	D	HL = DE + 177Q
		3334			
011.070	315 112 015	3335	CALL	CHKRAD	
011.073	050 006	3336	JR	Z,VIEW8.	
		3337			
011.075	325	3338	PUSH	D	
011.076	021 200 000	3339	LXI	D,200Q	
011.101	031	3340	DAD	D	ADD IN ANOTHER
011.102	321	3341	POP	D	
		3342			
011.103	042 072 040	3343	VIEW8.	SHLD	VEWHLD UPDATE END ADDRESS
011.106	115	3344	MOV	C,L	
011.107	104	3345	MOV	B,H	
011.110	311	3346	RET		

		3348	##	VIEW12 - Print address and position cursor	
		3349	*		
		3350			
011.111		3351	VIEW12	EQU *	
011.111	315 064 015	3352	CALL	TOA	
011.114	315 112 015	3353	CALL	CHKRAD	
011.117	312 127 011	3354	JZ	VIEW3B	
011.122	076 003	3355	MVI	A,3	NUMBER OF ASCII FOR BYTES
011.124	303 131 011	3356	JMP	VIEW3C	
011.127	076 004	3357	VIEW3B	MVI A,4	
011.131	315 341 010	3358	VIEW3C	CALL PCFA.	SKIP TO START ON SCREEN
011.134	311	3359	RET		

		3361	##	CKAUTO - CHECK FOR AUTO BOOT	
		3362	*		
		3363	*	CKAUTO IS ENTERED DURING THE MONITOR LOOP TO CHECK	
		3364	*	IF THE AUTO BOOT SWITCH IS SET.	
		3365	*		
		3366	*		
		3367	*	THIS ROUTINE WAS MOVED FROM UP FRONT TO MAKE ROOM	
		3368	*		
		3369			
011.135	333 362	3370	CKAUTO	IN H88.SW	
011.137	346 200	3371	ANI	H88S.AT	CHECK SWITCH
011.141	050 007	3372	JR	Z,CHAT2	NOT AUTO BOOT
011.143	041 123 041	3373	LXI	H,AUTO8	
011.146	276	3374	CMP	M	HAVE WE BEEN HERE BEFORE?
011.147	302 243 004	3375	JNZ	ATB	NO, DO AUTO BOOT

3376

011.152	041	062	014	3377	CHAT2	LXI	H,MSG.PR
011.155	303	354	000	3378	JMP	MTR.15	

RETURN TO MONITOR LOOP

3380 ** DYMEM EXTENSION

3381	*				
011.160	353	3382	DY9.3	XCHG	
011.161	174	3383	MOV	A,H	
		3384	*	LD	IX,DY9.4
011.162	335	041	3385	DB	MI.LDXA,MI.LDXB
011.164	171	011	3386	DW	DY9.4
		3387			

011.166	303	160	003	3388	JMP	DYBYT
			3389			

011.171	175	3390	DY9.4	MOV	A,L
		3391			
		3392	*	LD	IX,DY9.5
011.172	335	041	3393	DB	MI.LDXA,MI.LDXB
011.174	315	003	3394	DW	DY9.5
		3395			

011.176	303	160	003	3396	JMP	DYBYT
			3397			

		3398	*	ANOTHER EXTENSION!	
		3399			

011.201	172	3400	DY3.3	MOV	A,D
		3401	*	LD	IX,DY3.5
011.202	335	041	3402	DB	MI.LDXA,MI.LDXB
011.204	211	011	3403	DW	DY3.5
		3404			

011.206	303	160	003	3405	JMP	DYBYT
			3406			

011.211	173	3407	DY3.5	MOV	A,E	
		3408	*	LD	IX,DY3.7	
011.212	335	041	3409	DB	MI.LDXA,MI.LDXB	
011.214	153	007	3410	DW	DY3.7	
011.216	303	160	003	3411	JMP	DYBYT

3413 ** H37 - ENTRY POINT TO BOOT FROM H37

3414	*					
3415						
011.221	257	3416	H37	XRA	A	
011.222	323	171	3417	OUT	DK.INT	
			3418		SET FLIP LATCH	
011.224	076	320	3419	MVI	A,FDC.FI	
011.226	323	172	3420	OUT	FD.CMD	
			3421		SET NOT BUSY	
011.230	076	001	3422	MVI	A,1	
011.232	315	053	000	3423	CALL	DLY
			3424		DLY 2 MILLISECONDS	
011.235	333	172	3425	IN	FD.STAT	
					CLEAR INTERRUPTS	

			3426			
011.237	041 145 012	3427	LXI	H,MYINT		
011.242	042 051 040	3428	SHLD	UIVEC+9+1	SET INTERRUPT RUTINE	
011.245	076 303	3429	MVI	A,MI.JMP		
011.247	062 050 040	3430	STA	UIVEC+9		
		3431				
011.252	072 061 041	3432	LDA	AIO.UNI		
011.255	306 004	3433	ADI	4		
011.257	107	3434	MOV	B,A		
011.260	257	3435	XRA	A		
011.261	315 155 012	3436	CALL	BITS	GET DEVICE CODE	
		3437				
011.264	366 015	3438	ORI	CON.MO+CON.EI+CON.MFM		
011.266	323 170	3439	OUT	DK.CON		
011.270	107	3440	MOV	B,A		
011.271	305	3441	PUSH	B		
		3442				
011.272	373	3443	EI		insure interrupts on	
		3444				
011.273	076 226	3445	MVI	A,150	300MS ON DELAY	
011.275	315 053 000	3446	CALL	DLY		
		3447				
011.300	041 335 011	3448	LXI	H,H371		
011.303	042 067 040	3449	SHLD	BLKICW	SET RETURN ADDRESS	
011.306	076 003	3450	MVI	A,FDC.RST+FDF.S30		
011.310	323 172	3451	OUT	FD.CMD		
		3452				
011.312	001 377 377	3453	LXI	B,-1	ABOUT 5 SECONDS	
011.315	026 004	3454	MVI	D,4	DOUBLED.	
011.317	013	3455	H37.	DCX	B	
011.320	170	3456	MOV	A,B		
011.321	261	3457	ORA	C		
011.322	040 373	3458	JR	NZ,H37.	IF BC>0	
		3459				
011.324	025	3460	DCR	D		
011.325	040 370	3461	JR	NZ,H37.	IF D>0	
		3462				
011.327	076 320	3463	MVI	A,FDC.F1		
011.331	323 172	3464	OUT	FD.CMD		
		3465				
011.333	030 132	3466	JR	H373	TIMED OUT	
		3467				
011.335	041 356 011	3468	H371	LXI	H,H371B	
011.340	042 067 040	3469	SHLD	BLKICW	LOOP RETURN ADDRESS	
011.343	076 012	3470	MVI	A,10	NUMBER OF TRACKS TO STEP	
011.345	323 173	3471	OUT	FD.DAT	SET TRACK NUMBER TO 10	
011.347	076 023	3472	MVI	A,FDC.SEK+FDF.S30		
011.351	323 172	3473	OUT	FD.CMD		
011.353	303 353 011	3474	JMP	*	Wait for interrupt	
		3475				
		3476	*		Return here after doing seek	
		3477				
011.356	041 373 011	3478	H371B	LXI	H,H371C	
011.361	042 067 040	3479	SHLD	BLKICW		
011.364	076 003	3480	MVI	A,FDC.RST+FDF.S30		
011.366	323 172	3481	OUT	FD.CMD		

011.370	303 370 011	3482	JMP	*	
		3483			
		3484	*	Here after final RESTORE	
		3485			
011.373	346 004	3486	H371C	ANI FDS.TKO	Be sure track zero switch on
011.375	050 070	3487	JR	Z,H373	If not there
		3488			
		3489	*	Over track zero, Wait for head to settle	
		3490			
011.377	001 200 014	3491	LXI	B,3200	40 ms DELAY
012.002	013	3492	H371.	DCX	B
012.003	170	3493	MOV	A,B	
012.004	261	3494	ORA	C	
012.005	040 373	3495	JR	NZ,H371.	ALLOW HEAD SETTLE TIME
		3496			
012.007	301	3497	POP	B	
012.010	170	3498	MOV	A,B	(A) = Device Control Bits
012.011	366 002	3499	ORI	CON.DRQ	Turn on DRQ interrupt
012.013	107	3500	MOV	B,A	
012.014	305	3501	PUSH	B	save device control bits
012.015	323 170	3502	OUT	DK.CON	READY FOR TRANSFERS
		3503			
012.017	315 075 012	3504	CALL	READT	Read a track
012.022	301	3505	POP	B	
012.023	365	3506	PUSH	PSW	SAVE RETURN STATUS
012.024	170	3507	MOV	A,B	
012.025	346 373	3508	ANI	3770-CON.MFM	OFF DBL DENSITY
012.027	107	3509	MOV	B,A	
012.030	361	3510	POP	PSW	
012.031	040 012	3511	JR	NZ,H372	IF READ FAILURE
		3512			
012.033	041 200 335	3513	LXI	H,-USERFHA	
012.036	031	3514	DAD	D	HL = Bytes Read
012.037	174	3515	MOV	A,H	
012.040	376 011	3516	CPI	2048+256/256	See if 2.25K
012.042	322 201 016	3517	JNC	EUC	If got it all
		3518			
012.045	170	3519	H372	MOV	A,B
012.046	323 170	3520	OUT	DK.CON	
		3521			
012.050	315 075 012	3522	CALL	READT	TRY SINGLE DENSITY
012.053	040 012	3523	JR	NZ,H373	IF FAILURE
		3524			
012.055	041 200 335	3525	LXI	H,-USERFHA	
012.060	031	3526	DAD	D	HL = Bytes Read
012.061	174	3527	MOV	A,H	
012.062	376 011	3528	CPI	2048+2 ⁶ /256	See if 2.25K
012.064	322 201 016	3529	JNC	EUC	More than 2.25K read, is ok
		3530			
012.067	257	3531	H373	XRA	A
012.070	323 170	3532	OUT	DK.CON	TURN OFF DEVICE
012.072	303 171 002	3533	JMP	NODEV	
		3534			
012.075	076 001	3535	READT	MVI	A,CON.ST
012.077	323 171	3536	OUT	DK.INT	
012.101	323 172	3537	OUT	FD.SEC	

MTR90-1 - H/Z-89 MONITOR
ENTRY POINTS FOR HARDWARE TESTS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 84
10:42:50 17-FEB-82

000.000	3538	ERRNZ	CON.ST-1
012.103 257	3539	XRA	A
012.104 323 171	3540	OUT	DK.INT
000.000	3541	ERRNZ	CON.CD
	3542		
012.106 041 134 012	3543	LXI	H,READT2
012.111 042 067 040	3544	SHLD	BLKICW SET RETURN ADDRESS
012.114 041 126 012	3545	LXI	H,READT1
012.117 021 200 042	3546	LXI	D,USERFWA
012.122 076 234	3547	MVI	A,FDC.RDS+FDF.DLF+FDF.MRF+FDF.SLF
012.124 323 172	3548	OUT	FD.CMD
	3549		
012.126 166	3550	READT1	HLT
012.127 333 173	3551	IN	FD.DAT *TIME DEPENDENT*
012.131 022	3552	STAX	D
012.132 023	3553	INX	D
012.133 351	3554	PCHL	
	3555		
012.134 365	3556	READT2	PUSH PSW
012.135 076 010	3557	MVI	A,CON.MD
012.137 323 170	3558	OUT	DK.CON
012.141 361	3559	POP	PSW
012.142 346 254	3560	ANI	FDS.NRD+FDS.LDT+FDS.CRC+FDS.RTE
012.144 311	3561	RET	
	3562		
	3563	***	MYINT - H37 Interrupt Routine
	3564	*	
	3565	*	This routine is entered when a level 4 interrupt
	3566	*	is received from the H37 Hardware.
	3567	*	
	3568	*	Control is passed to the address in BLKICW
	3569	*	
	3570	*	ENTRY: NONE (From disk routine via level 4 interrupt)
	3571	*	
	3572	*	EXIT: PSW = Status byte from controller
	3573	*	HL = Return address to routine
	3574	*	
	3575		
012.145 333 172	3576	MYINT	IN FDSTAT
012.147 341	3577	POP	H
012.150 052 067 040	3578	LHLD	BLKICW
012.153 373	3579	EI	
012.154 351	3580	PCHL	
012.155	3581	XTEXT	BITS

3583X ** BITS - BIT SET

3584X *

3585X * BITS SETS THE SPECIFIED BIT IN THE ACCUMULATOR.

3586X *

3587X * ENTRY: A = ORIGINAL A

3588X * B = NUMBER OF BIT TO SET (7=HIGH,...,0=LOW)

3589X *

3590X * EXIT: A = ORIGINAL A WITH BIT(B) SET

		3591X *	
		3592X *	USES: PSW
		3593X *	
		3594X	
012.155	305	3595X BITS	PUSH 8
		3596X	
012.156	365	3597X	PUSH PSW
012.157	076 200	3598X	MVI A,100000008
012.161	004	3599X	INR B
012.162	007	3600X BITS1	RLC
012.163	005	3601X	DCR 8
012.164	302 162 012	3602X	JNZ BITS1
		3603X	
012.167	117	3604X	MOV C,A
012.170	361	3605X	POP PSW
012.171	261	3606X	ORA C
		3607X	
012.172	301	3608X	POP BC
012.173	311	3609X	RET
		3610 **	H67 - BOOT H67
		3611 *	
		3612 *	The section of this code most likely to "HANG" because
		3613 *	of no controller is timed using the BC register pair
		3614 *	for approximately 3 seconds.
		3615 *	
012.174	076 020	3616	
012.176	315 140 006	3617 H67	MVI A,BC.RST
		3618	CALL OUT1.
		3619	RESET THE CONTROLLER
012.201	076 004	3620	MVI A,4
012.203	315 053 000	3621	CALL DLY
		3622	
012.206	041 062 041	3623	LXI H,AIO.DIR
012.211	066 000	3624	MVI M,D.TDR
012.213	016 005	3625	MVI C,5
012.215	043	3626 H671	INX H
012.216	066 000	3627	MVI H,0
012.220	015	3628	DCR C
012.221	040 372	3629	JR NZ,H671
		3630	
012.223	315 365 012	3631	CALL H67UNI
012.226	062 063 041	3632	STA AIO.DIR+1
		3633	SET THE LUM
012.231	315 376 012	3634 H671.	CALL GETCON
012.234	060 012	3635 JR	NC,H672
		3636	CHECK READY IF DRIVE IS READY
012.236	312 171 002	3637	JZ NODEV
		3638	IF WAS TIME-OUT PROBLEM
012.241	076 377	3639	MVI A,3770
012.243	315 053 000	3640	CALL DLY
012.246	030 361	3641	JR H671.
		3642	
012.250	041 062 041	3643 H672	LXI H,AIO.DIR
012.253	066 001	3644	MVI M,D.REC
		3645	RECAL THE DRIVE
012.255	315 376 012	3646 CALL	GETCON
			DO THE RECAL

MTR90-1 - H/Z-89 MONITOR
ENTRY POINTS FOR HARDWARE TESTS

#09.02.01.

BITS

Unix H8ASM V1.4.1 5-Jul-80
10:43:02 17-FEB-82

Page 86

					ERROR IN RECAL
012.260	332 171 002	3647	JC	NODEV	
		3648			
		3649 *			Now cause the drive to step out 10 tracks
		3650			
012.263	072 061 041	3651	LDA	AIO.UNI	Only for the hard disk
012.266	247	3652	ANA	A	
012.267	302 330 012	3653	JNZ	H673	If unit = 1, is 8" floppy
		3654			
012.272	041 062 041	3655	LXI	H,AIO.DIR	
012.275	066 013	3656	MVI	H,D.SEK	
012.277	043	3657	INX	H	HL over logical address 0
012.300	043	3658	INX	H	
012.301	066 007	3659	MVI	H,7	Seek block (7*256)
		3660			
012.303	315 376 012	3661	CALL	GETCON	Do the seek
012.306	332 171 002	3662	JC	NODEV	If error doing Seek
		3663			
012.311	041 062 041	3664	LXI	H,AIO.DIR	
012.314	066 001	3665	MVI	H,D.REC	
012.316	043	3666	INX	H	
012.317	043	3667	INX	H	
012.320	066 000	3668	MVI	H,0	Do another Recal
012.322	315 376 012	3669	CALL	GETCON	
012.325	332 171 002	3670	JC	NODEV	
		3671			
012.330	041 062 041	3672	H673	LXI	H,AIO.DIR
012.333	066 010	3673	MVI	H,D,REA	SET UP READ COMMAND
012.335	043	3674	INX	H	
012.336	043	3675	INX	H	HL = LUN
012.337	043	3676	INX	H	
012.340	043	3677	INX	H	
012.341	066 012	3678	MVI	H,10	SET 10 SECTOR READ
012.343	043	3679	INX	H	
012.344	066 200	3680	MVI	H,080H	CONTROL BYTE
		3681			
012.346	315 365 012	3682	CALL	H67UNI	
012.351	062 063 041	3683	STA	AIO.DIR+1	SET LUN TO READ
		3684			
012.354	315 376 012	3685	CALL	GETCON	
012.357	332 171 002	3686	JC	NODEV	IF READ ERROR
012.362	303 201 016	3687	JMP	EUC	ENTER USER CODE
		3688			
012.365	072 061 041	3689	H67UNI	LDA	AIO.UNI
012.370	017	3690		RKC	(A)=UNIT NUMBER
012.371	017	3691		RRC	
012.372	017	3692		RRC	MOVE IT INTO PLACE
012.373	346 140	3693	ANI	ST.LUN	
012.375	311	3694		RET	
		3695			
012.376	363	3696	GETCON	DI	GET CONTROLLER ATTENTION
		3697			
012.377	001 377 377	3698	LXI	B,65535	ABOUT 5 SECONDS FOR RESPONSE
013.002	026 002	3699	MVI	D,2	3 BYTE COUNTER (D,B,C)
		3700			
013.004	315 150 006	3701	GTCN	CALL	IN1.
013.007	346 010	3702	AMI		BS.BSY

013.011	050 012	3703	JR	Z,GTCON1	WAIT FOR BUSY TO LEAVE
		3704			
013.013	013	3705	DCX	B	COUNT DOWN
013.014	170	3706	MOV	A,B	
013.015	261	3707	ORA	C	
013.016	040 364	3708	JR	NZ,GTCON	NO TIMEOUT YET
		3709			
013.020	025	3710	DCR	D	
013.021	040 361	3711	JR	NZ,GTCON	DEC 3RD BYTE
		3712			
013.023	067	3713	STC		INDICATE ERROR
013.024	311	3714	RET		
		3715			
013.025	076 100	3716	GTCON1	MVI A,BC.SEL	
013.027	315 140 006	3717	CALL	OUT1.	OUTPUT TO (PRIM)
		3718			
013.032	315 150 006	3719	CBUSY	CALL IN1.	
013.035	346 010	3720	ANI	BS.BSY	
013.037	040 007	3721	JR	NZ,CBUSY1	WAIT FOR CONTROLLER
		3722			
013.041	013	3723	DCX	B	CONTINUE COUNTING
013.042	170	3724	MOV	A,B	
013.043	261	3725	ORA	C	
013.044	040 364	3726	JR	NZ,CBUSY	
013.046	067	3727	STC		
013.047	311	3728	RET		TIMED OUT
		3729			
013.050	076 002	3730	CBUSY1	MVI A,BC.EDT	
013.052	315 140 006	3731	CALL	OUT1.	
		3732	*		
		3733	*	HAVE CONTROLLER, SEND HIM COMMAND	
		3734	*		
013.055	041 062 041	3735	OUTCOM	LXI H,AIO.DIR	FWD OF COMMAND BUFFER
		3736			
013.060	315 150 006	3737	COMREQ	CALL IN1.	
013.063	117	3738	MOV	C,A	
013.064	247	3739	ANA	A	
013.065	362 060 013	3740	JP	COMREQ	
000.000		3741	ERRNZ	2000-BS.REQ	WAIT FOR REQUEST BIT
		3742			
013.070	346 020	3743	ANI	BS.COM	
013.072	050 077	3744	JR	Z,TFDATA	COMMAND DONE, SEND DATA
		3745			
013.074	171	3746	MOV	A,C	(A)=BUSS STATUS BYTE
013.075	346 100	3747	ANI	BS.DTD	CHECK DIRECTION
013.077	050 007	3748	JR	Z,GETST	IF DONE, GET STATUS
		3749			
013.101	176	3750	MOV	A,M	(A)=COMMAND BYTE
013.102	315 063 006	3751	CALL	OUT.	SEND OUT DATA
013.105	043	3752	INX	H	BUMP POINTER
013.106	030 350	3753	JR	COMREQ	CONTINUE SENDING BYTES
		3754	*		
		3755	*	GET STATUS - COMPLETION BYTE SHOULD BE ZEROS AND	
		3756	*	STATUS BYTE SHOULD BE ZERO IN 2 LS BITS	
		3757	*		
013.110	315 150 006	3758	GETST	CALL IN1.	

MTR90-1 - H/Z-89 MONITOR #09.02.01.
ENTRY POINTS FOR HARDWARE TESTS

BITS

Unix H8ASM V1.4.1 5-Jul-80
10:43:14 17-FEB-82

Page 88

013.113	346	320	3759	ANI	BS.REQ+BS.DTD+BS.COM	
013.115	376	220	3760	CPI	BS.REQ+BS.COM	
013.117	040	367	3761	JR	NZ,GETST	WAIT FOR CONTROLLER
			3762			
013.121	315	170 006	3763	CALL	IN.	/2.1b/
013.124	117		3764	MOV	C,A	
013.125	062	070 041	3765	STA	AIO.DIR+6	
			3766			
013.130	315	150 006	3767	GETCPT	CALL	IN1.
013.133	107		3768	MOV	B,A	
013.134	062	071 041	3769	STA	AIO.DIR+7	
			3770			
013.137	346	340	3771	ANI	BS.REQ+BS.DTD+BS.MTY+BS.COM	
013.141	376	240	3772	CPI	BS.REQ+BS.MTY+BS.COM	
013.143	040	363	3773	JR	NZ,GETCPT	WAIT FOR MESSAGE
013.145	062	072 041	3774	STA	AIO.DIR+8	SAVE BYTES FOR DEBUG
			3775			
013.150	373		3776	EI		
			3777			
013.151	315	170 006	3778	CALL	IN.	(A)=COMPLETION BYTE
013.154	267		3779	ORA	A	CHECK COMPLETION
013.155	067		3780	STC		
013.156	300		3781	RNZ		SHOULD BE ZERO
			3782			
013.157	171		3783	MOV	A,C	
013.160	346	003	3784	ANI	00000011B	CHECK FOR ERRORS
013.162	067		3785	STC		
013.163	300		3786	RNZ		IF A BIT IS SET
			3787			
013.164	170		3788	MOV	A,B	
013.165	346	002	3789	ANI	00000010B	
013.167	067		3790	STC		
013.170	300		3791	RNZ		IF INTERFACE ERROR
			3792			
013.171	257		3793	XRA	A	CLEAR CARRY
013.172	311		3794	RET		
			3795			
013.173	041	200 042	3796	TFDATA	LXI	H,USERFWA HL = LOAD ADDRESS
			3797			
013.176	315	150 006	3798	TFREQ	CALL	IN1.
013.201	117		3799	MOV	C,A	
013.202	346	200	3800	ANI	BS.REQ	
013.204	050	370	3801	JR	Z,TFREQ	WAIT FOR REQUEST
			3802			
013.206	171		3803	MOV	A,C	
013.207	346	020	3804	ANI	BS.COM	
013.211	040	275	3805	JR	NZ,GETST	IF DONE, CHECK STATUS
			3806			
013.213	315	170 006	3807	CALL	IN.	GET DATA BYTE
013.216	167		3808	MOV	M,A	
013.217	043		3809	INX	H	
013.220	030	354	3810	JR	TFREQ	CONTINUE UNTIL DONE

MTR90-1 - H/Z-89 MONITOR #09.02.01.
ENTRY POINTS FOR HARDWARE TESTS

Unix H8ASM V1.4.1 5-Jul-80 Page 89
10:43:16 17-FEB-82

3812 ** FEDEV - FUTURE EXPANSION DEVICE
3813 *
3814 * CURRENTLY, FEDEV JUST PRINTS "UNKNOWN DEVICE"
3815 *
3816
013.222 041 233 013 3817 FEDEV LXI H,MSG.FE
013.225 315 100 006 3818 CALL TYPMSG
013.230 303 177 002 3819 JMP NODEVI ENTER COMMON RECOVERY CODE
3820
013.233 077 125 156 3821 MSG.FE DB "?Unknown Device",0

3823 ** DYMEM10 - DYNAMIC RAM TEST CONTINUED
3824 *
3825
013.252 076 007 3826 DYMEM10 MVI A,A.BEL
013.254 375 041 3827 DB MI.LDYA,MI.LDYB
013.256 244 007 3828 DW DY10.5
3829
013.260 303 143 003 3830 JMP DYASC

3832 ** CCL - CHECK COMMAND LINE
3833 *
3834 * CCL CHECKS TO SEE IF THE USER WISHES TO PASS A COMMAND
TO THE BOOT ROUTINE. IF THE USER SIMPLY TYPES A CARRIAGE
RETURN, THEN NO COMMAND LINE IS PRESENT AND (SP) = 42.200
3836 * RETURN, THEN NO COMMAND LINE IS PRESENT AND (SP) = 42.200
3837 * OTHERWISE THE COMMAND LINE IS PUSHED ONTO THE STACK ALA HDOS
3838 * AND THE BOOT ROUTINES CAN DO WITH AS THEY SEE FIT.
3839 *
3840 * ENTRY: NONE
3841 *
3842 * EXIT: (SP) = 42.200
3843 * NO COMMAND LINE
3844 * (SP) <> 42.200
3845 * COMMAND ON STACK TERMINATED WITH 0000
3846 *
3847 * USES: SP
3848 *
3849
013.263 062 000 040 3850 CCL STA START SAVE UNIT NUMBER
013.266 042 002 040 3851 SHLD IOWRK SAVE DEVICE ADDRESS
013.271 061 200 042 3852 LXI SP,42200A SET STACK
3853
013.274 041 062 041 3854 LXI H,AIO,DIR
013.277 016 035 3855 MVI C,PRIM-AIO,DIR-1 (C) = MAXIMUM ALLOWABLE LENGTH
3856
3857 * GET 1ST CHARACTER
3858
013.301 315 262 003 3859 CCL1 CALL RCC READ KEYBOARD
013.304 376 015 3860 CPI A,CR IS HE DONE?
013.306 050 017 3861 JK Z,CCL3

MTR90-1 - H/Z-89 MONITOR
ENTRY POINTS FOR HARDWARE TESTS

#09.02.01.

CCL

Unix H8ASM V1.4.1 5-Jul-80
10:43:18 17-FEB-82

Page 90

013.310	376 072	3862	CPI	": "	COMMAND LINE FOLLOWS
013.312	050 027	3863	JR	Z,CCL4	
013.314	376 040	3864	CPI	" "	ALLOW A SPACE
013.316	050 002	3865	JR	Z,CCL2	
013.320	076 007	3866	MVI	A,A,BEL	
013.322	315 302 003	3867	CCL2	CALL WCC	ECHO CHARACTER
013.325	030 352	3868	JR	CCL1	
		3869			
		3870	*	JUST A CARRIAGE RETURN, NO COMMAND	
		3871			
013.327	315 370 005	3872	CCL3	CALL WCR.	ECHO CRLF
013.332	052 002 040	3873	CCL3	LHLD IOWRK	
013.335	072 000 040	3874	LDA	START	RESTORE REGISTERS
013.340	303 360 001	3875	JMP	BOOT6	RETURN TO CALLER
		3876			
		3877	*	HAD ":", COMMAND LINE FOLLOWS	
		3878			
013.343	315 302 003	3879	CCL4	CALL WCC	ECHO THE CHARACTER
013.346	315 262 003	3880	CCL5	CALL RCC	GET NEXT
013.351	376 015	3881	CPI	A,CR	
013.353	050 013	3882	JR	Z,CCL6	IF END OF LINE
013.355	167	3883	MOV	H,A	SAVE CHARACTER
013.356	043	3884	INX	H	
013.357	015	3885	DCR	C	
013.360	040 361	3886	JR	NZ,CCL4	IF NOT TOO MANY
013.362	014	3887	INR	C	RESET COUNTER
013.363	053	3888	DCX	H	IGNORE IT
013.364	076 007	3889	MVI	A,A,BEL	BEEP
013.366	030 353	3890	JR	CCL4	
		3891			
		3892	*	END OF COMMAND LINE	
		3893			
013.370	315 370 005	3894	CCL6	CALL WCR.	
013.373	066 000	3895	MVI	H,O	NUL TERMINATOR
013.375	353	3896	XCHG		(DE)=LWA OF COMMAND
013.376	041 000 000	3897	LXI	H,O	
014.001	071	3898	DAD	SP	HL = STACK
014.002	053	3899	DCX	H	HL = LWA OF COMMAND LINE (NULL BYTE)
		3900			
		3901	*	MOVE COMMAND INTO STACK AREA	
		3902			
014.003	363	3903	DI		NO CLOCK INTERRUPTS
		3904			
014.004	032	3905	CCL7	LDAX D	DE = COMMAND BYTE
014.005	167	3906	MOV	H,A	MOVE IT IN
014.006	053	3907	DCX	H	
014.007	033	3908	DCX	D	BUMP POINTERS
014.010	042 067 040	3909	SHLD	BLKICW	SAVE FOR A SECOND
014.013	041 061 041	3910	LXI	H,AIO.DIR-1	AM I DONE?
014.016	174	3911	MOV	A,H	
014.017	272	3912	CMP	D	
014.020	040 004	3913	JR	NZ,CCL8	NO
014.022	175	3914	MOV	A,L	
014.023	273	3915	CMP	E	
014.024	050 005	3916	JR	Z,CCL9	YES, FINISH UP
		3917			

MTR 90-1 - H/Z-89 MONITOR
ENTRY POINTS FOR HARDWARE TESTS

#09.02.01.

CCL

Unix H8ASM V1.4.1 5-JUL-80 Page 91
10:43:21 17-FEB-82

014.026	052	067	040	3918	CCL8	LHLD	BLKICW
014.031	030	351		3919		JR	CCL7
				3920			
				3921	*	FINISHED WITH COMMAND LINE, (BLKICW)=FHA-1	
				3922			
014.033	052	067	040	3923	CCL9	LHLD	BLKICW
014.036	043			3924		INX	H
014.037	371			3925		SPHL	
014.040	030	270		3926		JR	CCL3.
							AND GO BACK

				3928	**	BSMSG - BOOT SECONDARY MESSAGE	
				3929	*		
				3930			
014.042	040	123	104	3931	BSMSG	DB	" SD",0

				3933	**	ERRMSG - GENERAL ERROR MESSAGE	
				3934			
014.046	077	102	157	3935	ERRMSG	DB	"?Boot Error",0

				3937	**	MSG.PR - Prompt Message	
				3938	*		
014.062	015	012	040	3939	MSG.PR	DB	A.CR,A.LF," H: ",0

MTR90-1 - H/Z-89 MONITOR
RADIX

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 92
10:43:21 17-FEB-82

		3942	**	RADIX - ASSIGN DEFAULT RADIX	
		3943	*		
		3944	*	RADIX SETS THE SYSTEM RADIX TO OCTAL OR HEX	
		3945	*		
		3946			
014.072	041 203 014	3947	RADIX	LXI	H,MSG.RAD
014.075	315 100 006	3948		CALL	TYPMSG
		3949			COMPLETE NAME
014.100	315 262 003	3950	RADIX1	CALL	RCC
		3951		CALL	MCU
014.103	315 223 015	3952		CPI	"0"
014.106	376 117	3953		JR	Z,RADIX2
014.110	050 017	3954		CPI	"H"
014.112	376 110	3955		JR	Z,RADIX3
014.114	050 026	3956		CPI	A,CR
014.116	376 015	3957		JR	Z,RADIX4
014.120	050 036	3958		MVI	A,A,BEL
014.122	076 007	3959		CALL	WCC
014.124	315 302 003	3960		JR	RADIX1
014.127	030 347	3961			
		3962	*	SET OCTAL RADIX	
		3963			
014.131	041 211 014	3964	RADIX2	LXI	H,RAD.OCT
014.134	315 100 006	3965		CALL	TYPMSG
014.137	257	3966		XRA	A
014.140	062 071 040	3967		STA	RADFLG
014.143	311	3968		RET	SET FLAG
		3969			
		3970	*	SET	HEX RADIX
		3971			
014.144	041 217 014	3972	RADIX3	LXI	H,RAD.HEX
014.147	315 100 006	3973		CALL	TYPMSG
014.152	076 001	3974		MVI	A,1
014.154	062 071 040	3975		STA	RADFLG
014.157	311	3976		RET	
		3977			
		3978	*	SHOW CURRENT SETTING	
		3979			
014.160	041 211 014	3980	RADIX4	LXI	H,RAD.OCT
014.163	315 112 015	3981		CALL	CHKRAD
014.166	050 003	3982		JR	Z,RADIX5
014.170	041 217 014	3983		LXI	H,RAD.HEX
		3984			
014.173	076 015	3985	RADIX5	MVI	A,A,CR
014.175	315 370 005	3986		CALL	WCR.
014.200	303 100 006	3987		JMP	TYPMSG
		3988			PRINT CRLF
		3989	*	MESSAGES	
		3990			
014.203	141 144 151	3991	MSG.RAD DB		"adix ",0
014.211	117 143 164	3992	RAD.DCT DB		"Octal",0
014.217	110 145 170	3993	RAD.HEX DB		"Hexadecimal",0

		3996	**	INPUT - PORT INPUT	
		3997	*		
		3998	*	INPUT INPUTS THE VALUE FROM THE SPECIFIED	
		3999	*	PORT NUMBER. THIS VALUE IS THEN PRINTED	
		4000	*		
		4001			
014.233	041 327 014	4002	INPUT	LXI H,MSG.INP	
014.236	315 100 006	4003		CALL TYPMSG	FINISH COMMAND
		4004			
		4005	*	GET DESIRED PORT NUMBER	
		4006			
014.241	041 120 041	4007		LXI H,PRIM	
014.244	247	4008		ANA A	CLEAR CARRY
014.245	315 036 015	4009		CALL IOB	GET PORT
		4010			
		4011	*	READ DATA FROM THAT PORT	
		4012			
014.250	315 170 006	4013		CALL IN.	GET DATA AT (PRIM)
		4014			
		4015	*	NOW PRINT RESULT	
		4016			
014.253	365	4017		PUSH PSW	
014.254	076 015	4018		MVI A,A.CR	
014.256	315 370 005	4019		CALL HCR.	PRINT CRLF
014.261	361	4020		POP PSW	
014.262	303 077 015	4021		JMP TDB	TYPE THE BYTE

		4023	**	OUTPUT - PORT OUTPUT	
		4024	*		
		4025	*	OUTPUT SENDS DATA OUT THE DESIRED PORT	
		4026	*	IN KEEPING WITH THE TAPE LOAD/DUMP ROUTINES, THE	
		4027	*	PORT NUMBER IS SPECIFIED FIRST, FOLLOWED BY A HYPHEN	
		4028	*	AND FOLLOWED BY DATA:	
		4029	*		
		4030	*	OUTPUT AAA,BBB<CR>	
		4031	*		
		4032			
014.265	041 332 014	4033	OUTPUT	LXI H,MSG.OUT	
014.270	315 100 006	4034		CALL TYPMSG	
		4035			
014.273	041 003 040	4036		LXI H,IOWRK+1	STORE INFO IN IOWRK
014.276	026 054	4037		MVI D," "	TERMINATE PORT BY HYPHEN
014.300	247	4038		ANA A	CLEAR CARRY
		4039			
014.301	315 023 015	4040	3100	CALL IOA	INPUT ADDRESS
		4041			
014.304	072 002 040	4042		LDA IOWRK	(A)=PORT NUMBER
014.307	062 120 041	4043		STA PRIM	SAVE IT
		4044			
014.312	247	4045		ANA A	
014.313	041 002 040	4046		LXI H,IOWRK	GET DATA
014.316	315 036 015	4047		CALL IOB	GET BYTE AND <CR>
		4048			

MTR90-1 - H/Z-89 MONITOR
PORT INPUT/OUTPUT

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 94
10:43:26 17-FEB-82

014.321 072 002 040 4049	LDA	IOWRK	GET DATA IN (A)
		4050	
014.324 303.063 006 4051	JMP	OUT.	OUT (PRIM) WITH (A)

4053 ** MSG.XXX - INPUT/OUTPUT MESSAGES

4054 *

4055

014.327 156 040 000 4056	MSG.INP DB	'n ',0
014.332 165 164 040 4057	MSG.DUT DB	'ut ',0
014.336 015 012 012 4058	MSG.ERR DB	A.CR,A.LF,A.LF,'Error a ',0

4060 ** SUBM10 - SUBSTITUTE PREFIX

4061 *

4062

014.352 315 112 015 4063	SUBM10 CALL	CHKRAD	
014.355 040 014 4064	JR	NZ,SUBM11	
014.357 346 007 4065	ANI	00000111B	GET BINARY VALUE
014.361 137 4066	MOV	E,A	SAVE PARTIAL
014.362 176 4067	MOV	A,M	GET CURRENT
014.363 007 4068	RLC		MAKE ROOM FOR NEW CHARACTER
014.364 007 4069	RLC		
014.365 007 4070	RLC		
014.366 346 370 4071	ANI	11111000B	TOSS PREVIOUS LSB
014.370 263 4072	SUBM10. ORA	E	ADD NEW
014.371 167 4073	MOV	H,A	SAVE NEW TOTAL
014.372 311 4074	RET		
014.373 315 234 015 4075	SUBM11 CALL	CHC	CONVERT IT TO HEX
014.376 346 017 4076	ANI	00001111B	
015.000 137 4077	MOV	E,A	
015.001 176 4078	MOV	A,M	
015.002 007 4079	RLC		
015.003 007 4080	RLC		
015.004 007 4081	RLC		
015.005 007 4082	RLC		
015.006 346 360 4083	ANI	11110000B	
015.010 030 356 4084	JR	SUBM10.	

4087 ** PREFIXES

4088 *

4089 * THESE ROUTINES ARE PREFIXES TO THE IOA, IOB
4090 * TOA, AND TOB ROUTINES. THESE PREFIXES DETERMINE
4091 * THE PROPER BASE TO USE, AND TRANSFER CONTROL

4092 * TO THE NEEDED ROUTINES

4093 *

4094

015.012 315 112 015 4095 IROC CALL CHKRAD
015.015 312 140 005 4096 JZ IROCO
015.020 303 326 015 4097 JMP IROCH

4098

015.023 365 4099 IOA PUSH PSW
015.024 315 112 015 4100 CALL CHKRAD CHECK RADIX
015.027 302 244 015 4101 JNZ IHA
015.032 361 4102 POP PSW SAVE CARRY FLAG
015.033 303 062 003 4103 JMP IOAO

4104

015.036 365 4105 IOB PUSH PSW
015.037 315 112 015 4106 CALL CHKRAD
015.042 302 123 015 4107 JNZ IH8
015.045 361 4108 POP PSW
015.046 303 066 003 4109 JMP IOBO

4110

015.051 365 4111 IOC PUSH PSW
015.052 315 112 015 4112 CALL CHKRAD
015.055 302 214 015 4113 JNZ IHC
015.060 361 4114 POP PSW
015.061 303 266 005 4115 JMP IOCO

4116

015.064 365 4117 TOA PUSH PSW
015.065 315 112 015 4118 CALL CHKRAD
015.070 302 001 016 4119 JNZ THA
015.073 361 4120 POP PSW
015.074 303 300 005 4121 JMP TOAO

4122

015.077 365 4123 TOB PUSH PSW
015.100 315 112 015 4124 CALL CHKRAD
015.103 302 350 015 4125 JNZ THB
015.106 361 4126 POP PSW
015.107 303 322 005 4127 JMP TOBO

4128

4129 * CHECK CURRENT RADIX

4130

015.112 305 4131 CHKRAD PUSH B
015.113 107 4132 MOV B,A
015.114 072 071 040 4133 LDA RADFLG
015.117 247 4134 ANA A
015.120 170 4135 MOV A,B
015.121 301 4136 POP B
015.122 311 4137 RET

```

4139 ** HEX ROUTINES
4140 *
4141 * THESE ROUTINES ARE THE HEX EQUIVELANT OF THE
4142 * OCTAL ROUTINES PREFIXED ABOVE
4143 *
4144 * NOTE: THESE ROUTINES ARE ENTERED WITH PSW ON THE STACK
4145 *
4146
4147
015.123 066 000 4148 IH8 MVI M,0 CLEAR RESULT
015.125 361 4149 POP PSW
015.126 324 262 003 4150 IH81 CNC RCC
4151
4152 * CHECK FOR VALIDITY
4153
015.131 315 173 015 4154 CALL CCH CHECK CHARACTER FOR VALID HEX
015.134 060 013 4155 JR NC,IH82
015.136 376 015 4156 CPI A.CR RETURN?
015.140 310 4157 RZ YES, DONE
015.141 247 4158 ANA A INSURE CARRY OFF
015.142 076 007 4159 MVI A,A.BEL
015.144 315 302 003 4160 CALL HCC
015.147 030 355 4161 JR IH81
4162
4163 * HAVE A VALID HEX CHARACTER
4164
015.151 315 302 003 4165 IH82 CALL HCC
015.154 315 234 015 4166 CALL CHC CONVERT HEX CHARACTER
015.157 137 4167 MOV E,A
015.160 176 4168 MOV A,M GET VALUE SO FAR
015.161 007 4169 RLC
015.162 007 4170 RLC MOVE UP NIBBLE
015.163 007 4171 RLC
015.164 007 4172 RLC
015.165 346 360 4173 ANI 111100008 THROW AWAY LAST
015.167 263 4174 DRA E
015.170 167 4175 MOV M,A SET NEW NIBBLE
015.171 030 333 4176 JR IH81
4177 ** CHECK FOR VALID HEX CHARACTER
4178 *
4179 * CCH CHECKS (A) FOR HEX VALIDITY
4180 * 'C' IS SET IF INVALID
4181 *
4182
015.173 315 223 015 4183 CCH CALL MCU MAP TO UPPER
015.176 376 060 4184 CPI "0"
015.200 330 4185 RC IF LESS THAN ZERO
015.201 376 072 4186 CPI "9"+1
015.203 077 4187 CMC
015.204 320 4188 RNC BETWEEN 0 AND 9
015.205 376 101 4189 CPI "A"
015.207 330 4190 RC LOWER CASE IS NOT VALID
015.210 376 107 4191 CPI "F"+1
015.212 077 4192 CMC
015.213 311 4193 RET

```

MTR90-1 - H/Z-89 MONITOR #09.02.01.
IOA, IOB, TOA, TOB, IROC PREFIXES

Unix H8ASM V1.4.1 5-Jul-80 Page 97
10:43:34 17-FEB-82

4195 ** IHC - INPUT HEX CHARACTER

4196 *

4197

015.214	361	4198	IHC	POP	PSW	GET CHARACTER
015.215	315 262 003	4199	CALL	RCC		CHECK FOR VALID HEX
015.220	303 173 015	4200	JMP	CCH		

4202 ** MCU - MAP CASE TO UPPER

4203 *

4204

015.223	376 141	4205	MCU	CPI	"a"	LESS THAN "A"
015.225	330	4206		RC		
015.226	376 173	4207		CPI	"z"+1	
015.230	320	4208		RNC		
015.231	346 137	4209		ANI	01011111B	
015.233	311	4210		RET		

MTR90-1 - H/Z-89 MONITOR

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

10:43:35 17-FEB-82

Page 98

```

4213 ** CONVERT HEX TO BINARY
4214 *
4215 * CHC CONVERTS THE ASCII CHARACTER IN (A) INTO
4216 * IT'S 4BIT HEX EQUIVELANT
4217 *

4218
015.234 326 060 4219 CHC SUI '0'
015.236 376 012 4220 CPI 9+1
015.240 330 4221 RC IF DONE
015.241 326 007 4222 SUI 7
015.243 311 4223 RET CONVERT A - F
4224
4225 * INPUT HEX ADDRESS
4226
015.244 361 4227 IHA POP PSW
015.245 305 4228 IHA. PUSH B
015.246 102 4229 MOV B,D
015.247 345 4230 PUSH H B = DELIMITER
015.250 041 000 000 4231 LXI H,0
015.253 324 262 003 4232 IHAI CNC RCC
015.256 315 173 015 4233 CALL CCH CHECK FOR HEX
015.261 070 016 4234 JR C,IHA3 IF NOT, CHECK DELIMITER
015.263 315 302 003 4235 CALL WCC
015.266 315 234 015 4236 CALL CHC CONVERT IT
015.271 051 4237 DAD H
015.272 051 4238 DAD H
015.273 051 4239 DAD H
015.274 051 4240 DAD H HL = HL # 16
015.275 205 4241 ADD L
015.276 157 4242 MOV L,A MOVE IN NEW NIBBLE
015.277 030 352 4243 JR IHAI
4244
015.301 270 4245 IHAI CMP B
015.302 050 010 4246 JR Z,IHA4 IF VALID DELIMITER
015.304 076 007 4247 MVI A,A,BEL
015.306 315 302 003 4248 CALL WCC
015.311 247 4249 ANA A
015.312 030 337 4250 JR IHAI
4251
4252 * END OF INPUT
4253
015.314 315 302 003 4254 IHAI CALL WCC PRINT DELIMITER
015.317 353 4255 XCHG
4256
015.320 341 4257 POP H
015.321 162 4258 MOV M,D
015.322 053 4259 DCX H
015.323 163 4260 MOV M,E
015.324 301 4261 POP B
015.325 311 4262 RET
4263 * IROC REPLACEMENT
4264
015.326 315 262 003 4265 IROCH CALL RCC
015.331 376 015 4266 CPI A,CR
015.333 310 4267 RZ IF CARRIAGE RETURN
4268

```

10:43:36 17-FEB-82

015.334	315	173	015	4269	CALL	CCH
015.337	077			4270	CNC	
015.340	330			4271	RC	IF VALID
				4272		
015.341	076	007		4273	MVI	A,A,BEL
015.343	315	302	003	4274	CALL	HCC
015.346	030	356		4275	JR	IROCH
				4276		
				4277	*	TYPE BYTE REPLACEMENT
				4278		
015.350	361			4279	THB	POP PSW
015.351	365			4280	THB1	PUSH PSW
015.352	346	360		4281	ANI	11110000B
015.354	017			4282	RRC	
015.355	017			4283	RRC	
015.356	017			4284	RRC	
015.357	017			4285	RRC	DO HIGH NIBBLE FIRST
015.360	315	366	015	4286	CALL	THB2
015.363	361			4287	POP	PSW
015.364	346	017		4288	ANI	00001111B
				4289		
				4290	*	THB1 - TYPE NIBBLE
				4291		
015.366	306	060		4292	THB2	ADI '0'
015.370	376	072		4293	CPI	'9'+1
015.372	070	002		4294	JR	C,THB3
015.374	306	007		4295	ADI	7
015.376	303	302	003	4296	THB3	JMP HCC
				4297	*	THA - TYPE HEX ADDRESS
				4298		
016.001	361			4299	THA	POP PSW
016.002	076	015		4300	MVI	A,A,CR
016.004	315	370	005	4301	CALL	HCR.
				4302		
016.007	174			4303	THA1	MOV A,H
016.010	315	351	015	4304	CALL	THB1
016.013	175			4305	MOV	A,L
016.014	315	351	015	4306	CALL	THB1
016.017	076	040		4307	MVI	A,' '
016.021	303	302	003	4308	JMP	HCC
				4310	**	MEMORY - MEMORY DIAGNOSTIC
				4311	*	
				4312	*	MEMORY IS THE PREFACE TO THE MEMORY
				4313	*	DIAGNOSTIC UTILITY
				4314	*	
016.024	041	043	016	4315	MEMORY	LXI H,MSG,HEM
016.027	315	100	006	4316	CALL	TYPMSG
016.032	072	071	040	4317	MEMORY	LDA KAOFLG
				4318	*	EXX
016.035	331			4319	DB	MI,EXX
016.036	157			4320	MOV	L,A
				4321	*	EXX

MTR90-1 - H/Z-89 MONITOR

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80

Page 100

10:43:38 17-FEB-82

016.037	331	4322	DB	MI.EXX
016.040	303 116 007	4323	JMP	DYMEM
	4324			
016.043	145 163 164	4325	MSG.MEM DB	'est Memory",A,CR,A,LF,O

4327 ** GETBND - GET BOUNDRIES
 4328 *
 4329 * GETBND GETS THREE ADDRESS BOUNDRIES, RETURNING
 4330 * THE FIRST IN HL, THE SECOND IN DE AND THE THIRD
 4331 * IN BC.
 4332 *
 4333

016.060	041 003 040	4334	GETBND	LXI H,IOWRK+1
016.063	026 054	4335	MVI	D,","
016.065	315 023 015	4336	CALL	IDA GET FIRST
	4337			
016.070	052 002 040	4338	LHLD	IOWRK
016.073	345	4339	GETBND. PUSH	H ENTRY POINT FOR DE,BC ONLY
	4340			
016.074	041 003 040	4341	LXI	H,IOWRK+1
016.077	026 054	4342	MVI	D,","
016.101	315 023 015	4343	CALL	IOA
	4344			
016.104	052 002 040	4345	LHLD	IOWRK SAVE SECOND
016.107	345	4346	PUSH	H
016.110	303 024 001	4347	JMP	GETBND1 CONTINUE ELSEWHERE

4349 ** INTOXO - EXTENSION TO INTOX
 4350 *
 4351 * INTOXO CLEANS UP SOME OF THE RAM CELLS
 4352 *

016.113	257	4353	INTOXO	XRA A
016.114	062 071 040	4354	STA	RADFLG
016.117	041 377 377	4355	LXI	H,-1
016.122	042 072 040	4356	SHLD	VEWHLD
016.125	001 200 076	4357	LXI	B,16000
016.130	303 050 004	4358	JMP	INITOXI

4361 ** BOOT7 - EXTENSION TO BOOT ROUTINE
 4362 *
 4363 * THIS ROUTINE HANDLES BOOTING FROM DEVICE
 4364 * ZERO WITH COMMAND LINES
 4365 *

016.133	376 040	4366	BOOT7	CPI "
016.135	050 007	4367	JR	Z,BOOT71 TYPED SPACE, MUST WANT COMMAND LINE

016.137	376 072	4369	CPI	":"	
016.141	050 012	4370	JR	Z,800T72	TYPE :, HERE COMES COMMAND
016.143	376 060	4371	CPI	"0"	
016.145	311	4372	RET		OTHERWISE, MAYBE UNIT NUMBER
016.146	315 302 003	4373	BOOT72	CALL	HCC
016.151	257	4374	XRA	A	ENTER CCL AS UNIT 0
016.152	303 263 013	4375	JMP	CCL	
		4376			
		4377	*	HE ALREADY STARTED THE COMMAND LINE, LETS CATCH UP!	
		4378			
016.155	257	4379	BOOT72	XRA	A
016.156	062 000 040	4380	STA	START	SAVE UNIT NUMBER
016.161	042 002 040	4381	SHLD	IOWRK	SAVE DEVICE ADDRESS
016.164	061 200 042	4382	LXI	SP,42200A	SET UP STACK
016.167	041 062 041	4383	LXI	H,AIO,DIR	
016.172	016 035	4384	MVI	C,PRIM-AIO,DIR-1	
016.174	076 072	4385	MVI	A,":"	ECHO THE COLON
016.176	303 343 013	4386	JMP	CCL4	CONTINUE FROM HERE

		4388	**	EUC - ENTER USER CODE		
		4389	*			
		4390	*	EUC ENTERS THE USER BOOT CODE, AFTER RE-VECTORING		
		4391	*	THE CLOCK INTERRUPT REQUEST VECTORS		
		4392	*			
		4393	*	THE H17 RAM CONSTANTS ETC. ARE ALSO MOVED IN		
		4394	*			
		4395				
016.201	001 130 000	4396	EUC	LXI	B,800TAL	SET THE COUNT TO MOVE IN CONSTANTS AND VECTORS
016.204	021 132 037	4397		LXI	D,BOOTA	SET THE SOURCE ADDRESS
016.207	041 110 040	4398		LXI	H,D,CON	SET THE DESTINATION ADDRESS
016.212	315 252 030	4399		CALL	\$MOVE	MOVE IT
		4400				
		4401	*	ENTRY POINT FROM H17 (CONSTANTS ALREADY MOVED IN)		
		4402				
016.215	363	4403	EUC.	DI		STOP CLOCK
016.216	041 031 034	4404		LXI	H,CLOCK17	LOAD CLOCK ROUTINE ADDRESS
016.221	042 040 040	4405		SHLD	UIVEC+1	SET IT INTO VECTOR LOCATION
016.224	373	4406		EI		
		4407				
		4408	*	Zero out H67 operating system info		
		4409				
000.000		4410		ERRNZ	S,0SZ-S,OSI-2	MUST BE CONTIGUOUS BYTES
016.225	041 126 041	4411		LXI	H,S,OSI	
016.230	006 005	4412		MVI	B,1+1+3	
016.232	315 212 031	4413		CALL	\$ZERO	Zero area
		4414				
016.235	303 200 042	4415	JMP		USERFHA	GOTO BOOT CODE

```

4417 ** DYBYTX
4418 *
4419 * DYBYTX DETERMINES WHETHER TO OUTPUT THE BYTE
4420 * IN HEX OR OCTAL. IF IN OCTAL WE MUST REPLACE
4421 * THE CODE WE PATCHED TO GET US HERE.
4422 *
4423 * ENTRY: (A) = BYTE OF TO OUTPUT
4424 *
4425
016.240 117 4426 DYBYTX MOV C,A SAVE BYTE
4427 * EXX
016.241 331 4428 DB MI.EXX
016.242 175 4429 MOV A,L GET RADIX FLAG
4430 * EXX
016.243 331 4431 DB MI.EXX
016.244 247 4432 ANA A "Z" SET IF OCTAL
016.245 171 4433 MOV A,C RESTORE A
016.246 040 012 4434 JR NZ,DYBYTH IF IN HEX
4435
016.250 117 4436 DYBYTO MOV C,A
016.251 346 300 4437 ANI 11000000B
016.253 007 4438 RLC
016.254 007 4439 RLC
016.255 346 003 4440 ANI 00000011B
016.257 303 163 003 4441 JMP DYBYT.1 FINISH UP OLD OCTAL ROUTINE
4442
4443 * IS HEX
4444
016.262 117 4445 DYBYTH MOV C,A
016.263 346 360 4446 ANI 11110000B
016.265 017 4447 RRC
016.266 017 4448 RRC
016.267 017 4449 RRC
016.270 017 4450 RRC MOVE DOWN HIGH HALF
016.271 346 017 4451 ANI 00001111B
016.273 306 060 4452 ADI "0"
016.275 376 072 4453 CPI "9"+1
016.277 070 002 4454 JR C,DYBYTH1
016.301 306 007 4455 ADI 7
016.303 375 041 4456 DYBYTH1 DB MI.LDYA,MI.LDYB
016.305 312 016 4457 DW DYBYTH2 SET RETURN ADDRESS
016.307 303 143 003 4458 JMP DYASC
4459
016.312 171 4460 DYBYTH2 MOV A,C
016.313 346 017 4461 ANI 00001111B
016.315 306 060 4462 ADI "0"
016.317 376 072 4463 CPI "9"+1
016.321 070 002 4464 JR C,DYBYTH3
016.323 306 007 4465 ADI 7
016.325 375 041 4466 DYBYTH3 DB MI.LDYA,MI.LDYB
016.327 334 016 4467 DW DYBYTH4
016.331 303 143 003 4468 JMP DYASC
4469
4470 * JP (IX)
4471
016.334 335 351 4472 DYBYTH4 DB MI.JIXA,MI.JIXB

```

10:43:43 17-FEB-82

4474 ** DYMMS
 4475 *
 4476 * DETERMINE NUMBER OF BACKSPACES
 4477 * TO TYPE FOR EACH CHARACTER OUTPUT
 4478 *

		4479		
016.336	331	4480	DYMM5	DB MI.EXX
016.337	175	4481	MOV	A,L
016.340	331	4482	DB	MI.EXX
016.341	247	4483	ANA	A
016.342	076 010	4484	MVI	A,A.BKS
016.344	046 003	4485	MVI	H,3
016.346	312 221 007	4486	JZ	DYME5.5
016.351	045	4487	DCR	H
016.352	303 221 007	4488	JMP	DYME5.5

4490 ** CONVERT - BASE CONVERSION
 4491 *
 4492 * CONVERT CONVERTS THE INPUT IN THE OPPOSITE
 4493 * RADIX AND CHANGES IT TO THE CURRENT RADIX
 4494 *
 4495

016.355	041 014 017	4496	CONVERT	LXI H,MSG.CON
016.360	315 100 006	4497	CALL	TYPMSG
016.363	041 003 040	4498	LXI	H,IOWRK+1
016.366	026 015	4499	MVI	D,A.CR
016.370	315 112 015	4500	CALL	CHKRAD
016.373	050 005	4501	JR	Z,CONV.U
		4502		IF OCTAL
016.375	315 062 003	4503	CONV.H	CALL IOAO
017.000	030 003	4504	JR	CONV.E
		4505		
017.002	315 245 015	4506	CONV.O	CALL IHA.
		4507		
017.005	052 002 040	4508	CONV.E	LHLD IOWRK
017.010	353	4509	XCHG	
017.011	303 064 015	4510	JMP	TOA
		4511		
017.014	157 156 166	4512	MSG.CON DB	'convert ',0

MTR90-1 - H/Z-89 MONITOR
H17 Extension routine

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 104
10:43:46 17-FEB-82

4515 *** H17X - H17 Extension routine
4516 *
4517 * H17x is the extension to the H17 Abort command
4518 *
4519
017.024 315 366 033 4520 H17X CALL R.ABORT
4521
4522 * Step the head out 10 tracks
4523
017.027 315 044 002 4524 CALL R.SDP Set up device
017.032 076 012 4525 MVI A,10
017.034 062 240 040 4526 STA D.TT Set target track to 10
017.037 315 166 040 4527 CALL D.SDT Seek Desired track
4528
017.042 303 366 033 4529 JMP R.ABORT Abort and return

	4532	**	MTRA - COMMAND DESCRIPTOR TABLE		
	4533	*			
	4534	*	THIS TABLE CONTAINS THE SINGLE LETTER COMMANDS		
	4535	*	UNDERSTOOD BY MTR90. THE ENTRIES IN THIS TABLE		
	4536	*	CONSIST OF A SINGLE LETTER (THE COMMAND KEY) FOLLOWED		
	4537	*	BY A WORD ADDRESS OF THE ROUTINE.		
	4538	*			
	4539	*	NOTE: THIS TABLE WAS MOVED FROM UP FRONT BECAUSE		
	4540	*	OF SIZE CONSIDERATIONS		
	4541	*			
	4542				
017.045	4543	MTRA	EQU	*	
017.045 107	4544	DB	"G"	*GO*	
017.046 146 001	4545	DW	G088		
	4546				
017.050 123	4547	DB	"S"	*SUBSTITUTE*	
017.051 370 004	4548	DW	SUBM		
	4549				
017.053 120	4550	DB	"P"	*PROGRAM COUNTER*	
017.054 103 001	4551	DW	PCA		
	4552				
017.056 102	4553	DB	"B"	*BOOT*	
017.057 256 004	4554	DW	BOOT		
	4555				
017.061 111	4556	DB	"I"	*INPUT*	
017.062 233 014	4557	DW	INPUT		
	4558				
017.064 117	4559	DB	"O"	*OUTPUT*	
017.065 265 014	4560	DW	OUTPUT		
	4561				
017.067 122	4562	DB	"R"	*RADIX*	
017.070 072 014	4563	DW	RADIX		
	4564				
017.072 124	4565	DB	"T"		
017.073 024 016	4566	DW	MEMORY	*TEST RAM*	
	4567				
017.075 126	4568	DB	"V"	*VIEW*	
017.076 044 001	4569	DW	VIEW		
	4570				
017.100 103	4571	DB	"C"		
017.101 355 016	4572	DW	CONVEKT		
000.012	4573	MTRAL	EQU	*--MTRA/3	NUMBER OF ENTRIES /JHT 790507/

4575	**	BT170, BT174 - BOOT TABLES		
4576	*			
4577	*	THESE TABLES DEFINE DEVICE DEPENDENT INFORMATION USED		
4578	*	TO DETERMINE WHICH DEVICE IS TO BE BOOTTED FROM		
4579	*			
4580	*	THE ORGANIZATION OF THE TWO TABLES IS IDENTICAL:		
4581	*			
4582	*	BYTE 1	-	PORT NUMBER OF THESE DEVICES
4583	*			
4584	*	BYTE 2	-	DEVICE 0 TMFG

		4585	*	BYTE 3	-	MAX UNITS
		4586	*	BYTE 4,5	-	BOOT CODE ADDRESS
		4587	*			
		4588	*	BYTE 6	-	DEVICE 1 TMFG
		4589	*	BYTE 7	-	MAX UNITS
		4590	*	BYTE 8,9	-	BOOT CODE ADDRESS
		4591	*			
		4592	*	etc., etc., etc. THRU DEVICE 3		
		4593	*			
		4594	*	NO END-OF-TABLE CHECK IS MADE, THEREFORE, 4 ENTRIES		
		4595	*	MUST EXIST PER TABLE		
		4596	*			
		4597				
017.103	174	4598	BT174	DB	174Q	PORT ADDRESS
017.104		4599	BT174E	EQU	*	
		4600				
017.104	000	4601	BTH174	DB	0	TMFG = 0
017.105	063	4602		DB	"3"	MAX UNIT = 3
017.106	207 002	4603		DW	H17	BOOT ADDRESS
		4604				
017.110	001	4605	BTH474	DB	1	
017.111	064	4606		DB	"4"	
017.112	372 001	4607		DW	Z47	
		4608				
017.114	000	4609	BTH674	DB	0	
017.115	064	4610		DB	"4"	
017.116	174 012	4611		DW	H67	
		4612				
017.120	000	4613	BTHFE4	DB	0	
017.121	061	4614		DB	"1"	
017.122	222 013	4615		DW	FEDEV	
		4616				
000.004		4617	BT174L	EQU	*-BT174E/4	INSURE ALL ENTRIES FILLED
000.000		4618		ERRNZ	BT174L-4	
		4619				
017.124	170	4620	BT170	DB	170Q	PORT ADDRESS
017.125		4621	BT170E	EQU	*	
		4622				
017.125	000	4623	BTH370	DB	0	
017.126	064	4624		DB	"4"	
017.127	221 011	4625		DW	H37	
		4626				
017.131	001	4627	BTH470	DB	1	
017.132	064	4628		DB	"4"	
017.133	372 001	4629		DW	Z47	
		4630				
017.135	000	4631	BTH670	DB	0	
017.136	064	4632		DB	"4"	
017.137	174 012	4633		DW	H67	
		4634				
017.141	000	4635	BTHFE0	DB	0	
017.142	061	4636		DB	"1"	
017.143	222 013	4637		DW	FEDEV	
		4638				
000.004		4639	BT170L	EQU	*-BT170E/4	
000.000		4640		ERRNZ	BT170L-4	

MTR90-1 - H/Z-89 MONITOR
Command Descriptor table

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 107
10:43:50 17-FEB-82

000.233

4642

ERRMI 20000A--*

MUST NOT EXCEED 4K BYTES

MTR90-1 - H/Z-89 MONITOR
RAM CELLS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80
10:43:50 17-FEB-82

Page 108

	4645	**	THE FOLLOWING ARE CONTROL CELLS AND FLAGS USED BY THE KEYSET		
	4646	*	MONITOR.		
	4647				
040.000	4648	ORG	40000A	8192	
040.000	4649	START	DS	2	DUMP STARTING ADDRESS
040.002	4650	IOWRK	DS	2	IN OR OUT INSTRUCTION
040.004	4651	PRSRAM	EQU	*	FOLLOWING CELLS INITIALIZED FROM ROM
040.004	4652		DS	1	RET
	4653				
040.005	4654	REGI	DS	1	INDEX OF REGISTER UNDER DISPLAY
040.006	4655	DSPROT	DS	1	PERIOD FLAG BYTE
040.007	4656	DSPMOD	DS	1	DISPLAY MODE
	4657				
040.010	4658	.MFLAG	DS	1	USER FLAG OPTIONS
	4659	*			SEE *U0.XXX* BITS DESCRIBED AT FRONT
	4660				
040.011	4661	CTLFLG	DS	1	FRONT PANEL CONTROL BITS
040.012	4662	REFIND	DS	1	REFRESH INDEX (0 TO 7)
000.007	4663	PRSL	EQU	*-PRSRAM	END OF AREA INITIALIZED FROM ROM
	4664				
040.013	4665	FPLEDS	EQU	*	FRONT PANEL LED PATTERNS
040.013	4666	ALEDS	DS	1	ADDR 0
040.014	4667		DS	1	ADDR 1
040.015	4668		DS	1	ADDR 2
	4669				
040.016	4670		DS	1	ADDR 3
040.017	4671		DS	1	ADDR 4
040.020	4672		DS	1	ADDR 5
	4673				
040.021	4674	DLEDS	DS	1	DATA 0
040.022	4675		DS	1	DATA 1
040.023	4676		DS	1	DATA 2
	4677				
040.024	4678	ABUSS	DS	2	ADDRESS BUSS
040.026	4679	RCCA	DS	1	RCC SAVE AREA
040.027	4680	CRCSUM	DS	2	CRC-16 CHECKSUM
040.031	4681	TPERRX	DS	2	TAPE ERROR EXIT ADDRESS
040.033	4682	TICCNT	DS	2	CLOCK TIC COUNTER
	4683				
040.035	4684	REGPTR	DS	2	REGISETR CONTENTS POINTER
	4685				
040.037	4686	UIVEC	DS	0	USER INTERRUPT VECTORS
040.037	4687		DS	3	JUMP TO CLOCK PROCESSOR
040.042	4688		DS	3	JUMP TO SINGLE STEP PROCESSOR
040.045	4689		DS	3	JUMP TO I/O 3
040.050	4690		DS	3	JUMP TO I/O 4
040.053	4691		DS	3	JUMP TO I/O 5
040.056	4692		DS	3	JUMP TO I/O 6
040.061	4693		DS	3	JUMP TO I/O 7
	4694				
	4695	**	H88/H89 RAM USAGE BEYOND THAT OF H8MTRF		
	4696	*			
040.064	4697	NMIRET	DS	2	
040.066	4698	DATA	DS	1	OUTPUT TO 362Q DATA SAVE
040.067	4699	BLKICH	DS	2	H37 INTERRUPT RETURN ADDRESS
040.071	4700	RADFLG	DS	1	RADIX FLAG

MTR90-1 - H/Z-89 MONITOR
RAM CELLS

#09.02.01.

Unix H8ASM V1.4.1 5-Jul-80 Page 109
10:43:53 17-FEB-82

040.072	4701	VEWHLD	DS	2	
000.001	4702	IF	.DEBUG		
	4703	DBFLG	DS	1	FOR DEBUG RESULTS
	4704	ENDIF			
040.074	4705	MEML	EQU	*	
001.024	4706	ERRMI	41120A-MEML		
041.120	4707	ORG	41120A		
041.120	4708	PRIM	DS	1	PRIMARY DEVICE ADDR. PORT
041.121	4709	TMFG	DS	1	TIMER INTERRUPT FLAG, =1 FOR Z47, =0 FOR H17
041.122	4710	MYCNT	DS	1	COUNTER FOR TIMER INTERRUPT
041.123	4711	AUTOB	DS	1	AUTO BOOT FLAG
041.124	4712	STK	DS	2	STACK POINTER FOR RE-BOOT
	4713				
041.126	4714	END			

Assembly complete

4714 statements

0 errors detected

22422 bytes free

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01

XREF V1.2.1

Page 119

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 111

BITS1	012162	3600L	3602									
BLKICW	040067	1249	2033	3449	3469	3479	3544	3578	3909	3918	3923	4699L
BOOT	004256	2260L	4554									
BOOT.P	000001	684E										
BOOT.SY	000002	685E										
BOOTO	001342	1352	1441L									
BOOTO.	001337	1411	1439L									
BOOT2	002324	1694L	1701									
BOOT5	001350	1415	1445L									
BOOT6	001360	1443	1448L	3875								
BOOT7	016133	1412	4367L									
BOOT71	016146	4368	4373L									
BOOT72	016155	4370	4379L									
BOOTA	037132	744E	1634	4397								
BOOTAL	000130	743E	1633	4396								
BOOTX	004275	2248	2266L									
BR19.2	004103	2115L										
BR96	004101	2114L										
BRTAB	004101	2067	2112E	2120								
BS.BSY	000010	482E	3702	3720								
BS.COM	000020	481E	3743	3759	3760	3771	3772	3804				
BS.DAT	000000	480E										
BS.DTD	000100	475E	3747	3759	3771							
BS.HID	000001	485E										
BS.IN	000000	476E										
BS.INT	000004	483E										
BS.LMB	000040	478E										
BS.MTY	000020	479E	3771	3772								
BS.DUT	000100	477E										
BS.PE	000002	484E										
BS.REQ	000200	474E	3741	3759	3760	3771	3772	3800				
BSEC	001326	1431E										
BSMSG	014042	1432	3931L									
BT170	017124	1734	4620L									
BT170E	017125	4621E	4639									
BT170L	000004	4639E	4640									
BT174	017103	1717	1727	4598L								
BT174E	017104	4599E	4617									
BT174L	000004	4617E	4618									
BTH174	017104	4601L										
BTH370	017125	4623L										
BTH470	017131	4627L										
BTH474	017110	4605L										
BTH670	017135	4631L										
BTH674	017114	4609L										
BTHFE0	017141	4635L										
BTHFE4	017120	4613L										
C.DSYN	000375	244E										
CB.CLI	000100	166E	201	.958	1181	2219						
CB.MTL	000040	165E	1051	1104	1181	1388						
CB.SPK	000200	167E	958	1181	1577							
CB.SSI	000020	164E	958	1051	1181	1373	1384	2219				
CBUSY	013032	3719L	3726									
CBUSY1	013050	3721	3730L									
CCH	015173	4154	4183L	4200	4233	4269						
CCL	013263	1447	3850L	4375								
CCL1	013301	3859L	3868									

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 112

CCL2	013322	3865	3867L
CCL3	013327	3861	3872L
CCL3.	013332	3873L	3926
CCL4	013343	3863	3879L 3886 3890 4386
CCL5	013346	3880L	
CCL6	013370	3882	3894L
CCL7	014004	3905L	3919
CCL8	014026	3913	3918L
CCL9	014033	3916	3923L
CDB.H84	000001	627E	
CDB.H85	000000	626E	
CHAT2	011152	3372	3377L
CHC	015234	4075	4166 4219L 4236
CHKRAD	015112	2022	3265 3276 3335 3353 3981 4063 4095 4100 4106 4112 4118
CKAUTO	011135	4124	4131L 4500
CLASS0	000000	1199	3370L
CLASS0	000000	499E	509 510 511 512 513 514 515 516 517 518 519
		520	
CLASS1	000040	500E	524
CLASS6	000300	501E	528
CLASSM	000340	497E	
CLK4	000270	1111	1134E
CLOCK	000201	894	895 1093L
CLOCK17	034031	749E	2322 4404
COM	006027	2610E	2691 3115 3129 3191
COM1	006031	2597	2612L
COM2	010156	2617	3208L
COM3	010164	3212L	3213
COMREQ	013060	3737L	3740 3753
CON.CD	000000	324E	3541
CON.DRQ	000002	313E	3499
CON.DSO	000020	316E	
CON.DS1	000040	317E	
CON.DS2	000100	318E	
CON.DS3	000200	319E	
CON.EI	000001	312E	3438
CON.MFM	000004	314E	3438 3508
CON.MO	000010	315E	3438 3557
CON.ST	000001	325E	3535 3538
CONV.E	017005	4504	4508L
CONV.H	016375	4503L	
CONV.O	017002	4501	4506L
CONVERT	016355	4496L	4572
CRCSUM	040027	4680L	
CTLFLG	040011	910	1097 1102 1107 1182 1372 1375 1386 1582 2127 2625 4661L
CUI1	000165	1066L	1123 1135
D.CON	040110	574L	1635 4398
D.CPB	000040	524E	
D.CTF	000005	514E	
D.DAT	000171	340E	
D.FBS	000007	516E	
D.FFD	000300	528E	
D.FOR	000004	513E	
D.FT	000006	515E	
D.OECHT	040264	758E	1538
D.RAM	040240	577L	1683
D.RAML	000037	746E	1684

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 113

D.REA	000010	517E	3673			
D.REC	000001	510E	3644	3665		
D.RSE	000003	512E				
D.RSY	000002	511E				
D.SDP	040206	752E	1642			
D.SDT	040166	753E	4527			
D.SEK	000013	520E	3656			
D.STA	000170	339E	340			
D.TDR	000000	509E	3624			
D.TT	040240	754E	4526			
D.VEC	040130	576L				
D.WPS	000011	518E				
D.WRI	000012	519E				
DAT	006023	2595E	2693	2695	3117	3132
DATA	040066	2107	2227	4698L		3135
DD.BOOT	000000	378L				
DD.CPY	000013	389L				
DD.DS	000202	413L				
DD.FRMO	000014	390L				
DD.FRM1	000015	391L				
DD.FRM2	000016	392L				
DD.FRM3	000017	393L				
DD.LSC	000003	381L	3128			
DD.RAD	000004	382L				
DD.RAS	000002	380L	3114			
DD.RDBL	000205	416L				
DD.REA	000005	383L				
DD.REAB	000007	385L	2690			
DD.ROL	000203	414L				
DD.RRDY	000020	394L	3190			
DD.RST	000001	379L				
DD.SDC	000200	411L				
DD.SPF0	000020	400L				
DD.SPF1	000021	401L				
DD.SPF2	000022	402L				
DD.SPF3	000023	403L				
DD.SPF4	000024	404L				
DD.SPF5	000025	405L				
DD.ST	000201	412L				
DD.WDLB	000210	419L				
DD.WRD	000011	387L				
DD.WRDB	000012	388L				
DD.WRI	000006	384L				
DD.WRIB	000010	386L				
DD.WTBL	000206	417L				
DD.WTDL	000207	418L				
DD.WTL	000204	415L				
DEV1.	002377	1720	1730L			
DEV170	002355	1714L				
DEV174	002367	1710	1724L			
DEV2	003006	1718	1728	1736	1740L	
DEVICE	002273	1351	1408	1677E		
DF.CLR	000376	595E				
DF.DI	000040	220E				
DF.DSO	000002	216E				
DF.DS1	000004	217E				
DF.DS2	000010	218E				

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 114

DF.EMP	000377	594E
DF.HD	000001	210E
DF.MD	000020	219E
DF.SD	000010	213E
DF.ST	000100	221E
DF.TD	000002	211E
DF.WG	000001	215E
DF.WP	000004	212E
DF.WR	000200	222E
DIR.ALD	000025	610L
DIR.CLU	000015	603L
DIR.CRD	000023	609L
DIR.EXT	000010	598L
DIR.FGN	000020	606L
DIR.FLG	000016	604L
DIR.LGN	000021	607L
DIR.LSI	000022	608L
DIR.NAM	000000	597L
DIR.PRO	000013	599L
DIR.VER	000014	600L
DIRELEN	000027	612E 719
DIRIDL	000015	601E
DK.CON	000170	255E 3439 3502 3520 3532 3558
DK.INT	000171	256E 3417 3536 3540
DK.PORT	000170	248E 250 251 252 253 254 255 256
DLEDS	040021	4674L
DLY	000053	948L 3423 3446 3621 3640
DM.MR	000000	171E
DM.MW	000001	172E
DM.RR	000002	173E
DM.RW	000003	174E
DOD	003122	1837L
DP.DC	000177	208E 1618 1686
DS.HOLE	000001	2803E 2828 2834
DSPMOD	040007	4656L
DSPROT	040006	4655L
DY10.5	007244	2995L 3828
DY3.3	011201	2929 3400L
DY3.5	011211	3403 3407L
DY3.7	007153	2932L 3410
DY5.53	007230	2974 2978L
DY9.3	011160	1157 3382L
DY9.4	011171	3386 3390L
DY9.5	003315	1999L 3394
DY9.8	003330	2004 2008L
DYASC	003143	1865E 1892 1905 1915 2976 3024 3830 4458 4468
DYASC1	003144	1868L 1870
DYBYT	003160	1885L 2014 2988 3388 3396 3405 3411
DYBYT.1	003163	1886L 4441
DYBYT.2	003174	1890 1894L
DYBYT.4	003213	1903 1907L
DYBYT.6	003227	1913 1917E
DYBYTH	016262	4434 4445L
DYBYTH1	016303	4454 4456L
DYBYTH2	016312	4457 4460L
DYBYTH3	016325	4464 4466L
DYBYTH4	016334	4467 4472L

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 115

DYBYTO	016250	4436L
DYBYTX	016240	1885
DYMEM5.5	007221	2970E
DYMEM	007116	2906L
DYMEM1	007122	2912L
DYMEM10	013252	2012
DYMEM11	007251	2997L
DYMEM2	007127	2914L
DYMEM3	007140	2917
DYMEM4	007167	1148
DYMEM5	007172	2946L
DYMEM6	000273	1142L
DYMEM7	000276	1143L
DYMEM9	000307	1152L
DYMM5	016336	2968
DYMSG	007265	1158
DYMSG.5	007275	3022
EDYMEM	007375	3077L
EIXIT	034027	756E
ERPTCMT	000012	757E
ERRMSG	014046	1615
ERROR	000322	1005
ESPEED	007372	3071L
EUC	016201	1515
EUC.	016215	1662
FD.CMD	000172	251E
FD.DAT	000173	254E
FD.SEC	000172	253E
FD.STAT	000172	250E
FD.TRK	000173	252E
FDC.FI	000320	273E
FDC.RDA	000300	269E
FDC.RDS	000200	266E
FDC.RDT	000340	270E
FDC.RST	000000	260E
FDC.SEK	000020	261E
FDC.STI	000100	263E
FDC.STO	000140	264E
FDC.STP	000040	262E
FDC.WTS	000240	267E
FDC.WTT	000360	271E
FDF.DDM	000001	292E
FDF.DLF	000004	290E
FDF.HLB	000010	278E
FDF.MRF	000020	288E
FDF.S12	000001	282E
FDF.S20	000002	283E
FDF.S30	000003	284E
FDF.S6	000000	281E
FDF.SLF	000010	289E
FUF.SSI	000002	291E
FDF.UTR	000020	277E
FDF.VRF	000004	279E
FDS.BSY	000001	308E
FDS.CRC	000010	303E
FDS.DRQ	000002	307E
FDS.HLD	000040	298E

FDS.IND 000002	306E						
FDS.LDT 000004	305E	3560					
FDS.NRD 000200	296E	3560					
FDS.RNF 000020	302E						
FDS.RTE 000040	299E	3560					
FDS.SEK 000020	301E						
FDS.TKO 000004	304E	3486					
FDS.WPV 000100	297E						
FDS.WTF 000040	300E						
FEDEV 013222	3817L	4615	4637				
FPLEDS 040013	4665E						
GETBND 016060	4334L						
GETBND. 016073	3323	4339L					
GETBND1 001024	1230L	4347					
GETCON 012376	3634	3646	3661	3669	3685	3696L	
GETCPT 013130	3767L	3773					
GETST 013110	3748	3758L	3761	3805			
GO 001222	1340	1362L					
GO. 000063	958L	1362	2270				
G088 001146	1327L	4545					
G088.1 001177	1330	1339L					
GTCON 013004	3701L	3708	3711				
GTCON1 013025	3703	3716L					
H17 002207	1632E	4603					
H17A 002237	1650L	1652					
H17X 017024	1656	4520L					
H37 011221	3416L	4625					
H37. 011317	3455L	3458	3461				
H371 011335	3448	3468L					
H371. 012002	3492L	3495					
H371B 011356	3468	3478L					
H371C 011373	3478	3486L					
H372 012045	3511	3519L					
H373 012067	3466	3487	3523	3531L			
H67 012174	3617L	4611	4633				
H671 012215	3626L	3629					
H671. 012231	3634L	3641					
H672 012250	3635	3643L					
H673 012330	3653	3672L					
H67UNI 012365	3631	3682	3689L				
H88.CTL 000362	129E	2061	2229	2907			
H88.SH 000362	133E	1708	1714	1724	2068	2098	3370
H888.CK 000002	130E	2060					
H888.SS 000001	131E						
H885.0 000014	139E						
H885.4 000003	141E	1744					
H885.AT 000200	134E	3371					
H885.BR 000100	135E	2069					
H885.DV 000020	137E	1709					
H885.M 000040	136E	2099					
HORN 002140	1576L	2637					
HRNO 002143	950	1579L					
HRN2 002160	1590L	1591					
HRNX 006045	1593	2625L					
IHA 015244	4101	4227L					
IHA. 015245	4228L	4506					
IHA1 015253	4232L	4243	4250				

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 117

IHA3	015301	4234	4245L
IHA4	015314	4246	4254L
IHB	015123	4107	4148L
IHB1	015126	4150L	4161 4176
IHB2	015151	4155	4165L
IHC	015214	4113	4198L
IN.	006170	1276	2613 2750E 3166 3170 3763 3778 3807 4013
IN.1	006174	2732	2753L
IN1.	006150	1281	2727E 3701 3719 3737 3758 3767 3798
INIT	000073	881	883 980L 984
INIT0	000000	879L	
INIT0.0	000003	880L	2108
INITOX	004000	879	2060L
INITOX1	004050	2091L	2092 2094 4359
INIT1	000107	993L	998
INIT2	000117	1000L	
INPUT	014233	4002L	4557
INTOX0	016113	2090	4354L
INT1	000010	888E	
INT2	000020	904E	
INT3	000030	923L	
INT4	000040	930L	
INT5	000050	937L	
INT6	000060	955L	
INT7	000070	964L	
INTXIT	000172	1075L	1105 1377
IOA	015023	1232	1317 1338 2350 4040 4099L 4336 4343
IOA1	005166	1796	2440L
IOA2	005176	2445L	2460 2469
IOA3	005230	2447	2462L
IOA4	005245	2463	2473L
IOAO	003062	1796L	4103 4503
IOB	015036	4009	4047 4105L
IOB1	003070	1812L	1819 1848 1855
IOB1.5	003126	1830	1845L
IOB2	003135	1817	1852L
IOBO	003066	1811L	4109
IOC	015051	2359	2386 4111L
IOC.	005271	2446	2499L
ICO	005266	2498L	4115
IOWRK	040002	1230	1234 2348 2812 2850 2852 3851 3873 4036 4042 4046 4049
		4334	4338 4341 4345 4381 4498 4508 4650L
IP.DS	000177	2799E	2827 2833
IP.PAD	000360	123E	
IP.TPC	000371	146E	
IP.TPD	000370	148E	
IROC	015012	1306	1310 1329 2345 2426 3314 4095L
IROC1	005156	2419	2424L
IROCH	015326	4097	4265L 4275
IROCO	005140	2414L	4096
LRA	003047	1779L	
LRA.	003052	1116	1300 1334 1780L 2246 2264
LSA.2	000037	505E	
LUNM	000140	504E	
M.INI	242355	333E	
M.OUTI	243355	334E	
MCU	015223	3951	4183 4205L

MTR90-1 - H/Z-89 MONITOR

#09-02-01

XREF V1.2.1

Page 118

NMI1.5	004206	2209	2215L
NMI2	004212	2218L	
NMI2.2	004225	2225	2227L
NMI2.5	004236	2192	2197 2200 2216 2233L
NMI3	004237	2204	2213 2235L
NMIENT	000146	1044L	
NMIRET	040064	2169	2176 4697L
NODEV	002171	1452	1510 1614E 1661 2299 2313 3085 3093 3095 3119 3138 3533
		3637	3647 3662 3670 3686
NODEV1	002177	1617L	3819
NOISE	006053	1597	2635L
ONDRO	000022	2807E	2813
OP.CTL	000360	124E	1098 1374 1385
OP.DC	000177	2798E	2814
OP.DIG	000360	125E	
OP.SEG	000361	126E	
OP.TPC	000371	147E	
OP.TPD	000370	149E	
OPCOM	000037	503E	
OUT.	006063	2647E	3082 3751 4051
OUT.1	006070	2651L	2717
OUT1.	006140	2712E	3208 3618 3717 3731
OUTCOM	013055	3735L	
OUTPUT	014265	4033L	4560
OVL.IN	000001	651E	
OVL.NUM	000014	653E	
OVL.RES	000002	652E	
OVL.UCS	000200	654E	
PCA	001103	1297L	4551
PCA1	001137	1307	1315L
PCF.MH	011012	3268	3304L
PCF.MO	011017	3266	3305L
PCFA	010316	3222	3264L
PCFA.	010341	3273L	3358
PCFA1	010357	3277	3282L
PCFA2	010361	3280	3284L
PCFA3	010362	3286L	3298
PCFA3.	010371	3291L	3294
PCFA4	011007	3287	3300L
PCFAA	010333	3267	3269L
PIN	001067	1275E	1278 2697 3118 3193
PRIM	041120	1741	2650 2715 2729 2752 3855 4007 4043 4384 4708L
PRSL	000007	880	4663E
PRSRAM	040004	880	4651E 4663
PRSRDM	003371	2045E	2104
R.ABORT	033366	750E	4520 4529
R.READ	034077	751E	1660
R.SDP	002044	1536E	1641 1649 4524
R.SDP1	002063	1542	1544L
RAD.HEX	014217	3972	3983 3993L
RAD.OCT	014211	3964	3980 3992L
RADFLG	040071	3967	3975 4133 4317 4355 4700L
RADIX	014072	3947L	4563
RADIX1	014100	3950L	3960
RADIX2	014131	3953	3964L
RADIX3	014144	3955	3972L
RADIX4	014160	3957	3980L

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

409.02.01.

XREF V1.2.1

Page 120

S.OVLFL	040371	656L
S.OVLS	040376	659L
S.QVSTK	041035	689L
S.RFHA	040356	637L
S.SCI	041024	677L
S.SCR	041121	728L
S.SDO	041010	673L
S.SOVR	041146	581L 583
S.SSN	041002	662L
S.SW0	000002	347E
S.SW1	000004	348E
S.SW2	000010	349E
S.SW3	000020	350E
S.UCSF	040372	657L
S.UCSL	040374	658L
S.VAL	040277	578L
SAE	001063	1262L
SAVALL	000132	892 908 1022L
SAVALLR	000151	1046 1048E 2129
SAVALLX	004105	1037 2124E
SB.BTO	000001	364E
SB.CRC	000010	361E
SB.DLD	000040	359E
SB.ILC	000002	363E
SB.LTD	000004	362E
SB.MRF	000020	360E
SB.UNR	000200	357E
SB.WPD	000100	358E
SC.ACE	000350	809E 1868 1874 1968 1972 1989 1994 2066 2078 2081 2083 2085 2292 2296
SC.UART	000372	770E
SDP3	036073	755E 1544
SEC.M	000037	440E
SID.0	000000	433E
SID.1	000200	434E
SID.M	000200	436E
SINCR	004000	986E 988 989
SPEED	006240	2809L 3071
SPEED01	006257	2815L 2859
SPEED02	006275	2823 2826L
SPEED03	006300	2827L 2829 2840
SPEED04	006307	2833L 2835
SPEED05	006357	2853 2856L
SSIZ.M	004000	444E
SST1	001235	959 1375L
SSTEP	001225	1370E
ST.ERR	000002	491E
ST.LUN	000140	489E 3693
ST.PER	000001	492E
ST.SPR	000034	490E
STACK	042200	585E
STACKL	001032	583E
START	040000	989 2912 2945 3850 3874 4380 4649L
START1	001265	1409L 1422
STK	041124	1471 1512 1528 4712L
STPRTN	001244	911 1383E
SUBM	004370	2343L 4548

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 122

SUBM1	005013	2353L	2366	2373
SUBM10	014352	2385	4063L	
SUBM10.	014370	4072L	4084	
SUBM11	014373	4064	4075L	
SUBM2	005027	2359L	2380	
SUBM3	005042	2365L	2390	
SUBM4	005046	2363	2368L	
SUBM5	005053	2371L	2393	
SUBM6	005062	2369	2375L	
SUBM7	005075	2360	2382L	
SUBM8	005077	2384L	2387	
SUBM9	005105	2386L	2400	
SYDD	040130	575E		
TO.DNR	000004	536E		
TO.DNS	000005	537E		
TO.MDS	000007	539E		
TO.NIS	000001	533E		
TO.NSC	000002	534E		
TO.NST	000000	532E		
TO.NTO	000006	538E		
TO.WFT	000003	535E		
T1.BBF	000011	552E		
T1.CDE	000010	551E		
T1.DMFN	000003	546E		
T1.DTE	000006	549E		
T1.FE	000012	553E		
T1.ID	000000	543E		
T1.IDNF	000002	545E		
T1.RNF	000004	547E		
T1.SKE	000005	548E		
T1.UDE	000001	544E		
T1.WP	000007	550E		
T2.IDA	000001	558E		
T2.IFN	000002	559E		
T2.ILC	000000	557E		
TFDATA	013173	3744	3796L	
TFREQ	013176	3798L	3801	3810
THA	016001	4119	4299L	
THA1	016007	4303L		
THB	015350	4125	4279L	
THB1	015351	4280L	4304	4306
THB2	015366	4286	4292L	
THB3	015376	4294	4296L	
TICCNT	040033	1093	1095	1586
TMFG	041121	1753	2301	2309
TMOUT	004304	1703	2291E	
TMOUT1	004347	2314L	2316	
TMOUT2	004363	2307	2315	2320L
TMOUT3	004365	2319	2322L	
TMOUT4	004323	2294	2301L	
TOA	015064	1309	2353	3352
TOA.	005305	2518L	2858	
TOAO	005300	2515L	4121	
TOB	015077	1550	2355	4021
TOB1	005332	2542L	2550	
TOBO	005322	2519	2521	2535L
TPERRX	040031	4681L	4127	

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 123

TYPMSG	006100	1200	1246	1298	1328	1433	1616	2261	2344	2670L	2676	2810	2856
		3232	3255	3269	3818	3948	3965	3973	3987	4003	4034	4316	4497
UC.ZSB	000004	835E											
UC.58W	000000	831E											
UC.68W	000001	832E											
UC.78W	000002	833E											
UC.88W	000003	834E	2082										
UC.BI	000020	854E											
UC.CTS	000020	863E											
UC.DCS	000001	859E											
UC.DDR	000002	860E											
UC.DLA	000200	840E	2065										
UC.DR	000001	850E	1969	2293									
UC.DRL	000010	862E											
UC.DSR	000040	864E											
UC.DTR	000001	843E											
UC.EDA	000001	821E											
UC.EPS	000020	837E											
UC.FE	000010	853E											
UC.IID	000006	828E											
UC.IIP	000001	827E											
UC.L00	000020	847E											
UC.MSI	000010	824E											
UC.OR	000002	851E											
UC.DU1	000004	845E											
UC.DU2	000010	846E											
UC.PE	000004	852E											
UC.PEN	000010	836E											
UC.RI	000100	865E											
UC.RLS	000200	866E											
UC.RSI	000004	823E											
UC.RTS	000002	844E											
UC.SB	000100	839E											
UC.SKP	000040	838E											
UC.TER	000004	861E											
UC.THE	000040	855E	1869	1990									
UC.TRE	000002	822E											
UC.TSE	000100	856E											
UCI.ER	000020	792E											
UCI.IE	000002	794E											
UCI.IR	000100	790E											
UCI.RE	000004	793E											
UCI.RO	000040	791E											
UCI.TE	000001	795E											
UDR	000000	767E											
UF.FCT	000100	237E											
UF.RDA	000001	234E											
UF.ROR	000002	235E											
UF.RPE	000004	236E											
UF.TBM	000200	238E											
UIVEC	040037	923	930	937	955	964	1069	1390	1693	1704	3428	3430	4405
		4686L											
UMI.16X	000002	785E											
UMI.1B	000100	775E											
UMI.1X	000001	784E											
UMI.28	000300	777E											
UMI.64X	000003	786E											

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 124

UMI.HB	000200	776E
UMI.L5	000000	780E
UMI.L6	000004	781E
UMI.L7	000010	782E
UMI.L8	000014	783E
UMI.PA	000020	779E
UMI.PE	000040	778E
UNT.O	000000	424E
UNT.I	000040	425E
UNT.Z	000100	426E
UNT.3	000140	427E
UNT.M	000140	429E
UD.CLK	000001	203E 1067 1691
UD.DDU	000002	202E 1178
UD.HLT	000200	200E 1109
UD.NFR	000100	201E 1178
UP.DP	000174	228E
UP.FC	000175	229E
UP.SC	000176	231E
UP.SR	000176	232E
UP.ST	000175	230E
UR.DLL	000000	816E 2081
UR.DLM	000001	818E 2078
UR.IER	000001	820E 2085
UR.IIR	000002	826E
UR.LCR	000003	830E 2066 2083
UR.LSR	000005	849E 1868 1968 1989 2292
UR.MCR	000004	842E
UR.MSR	000006	858E
UR.RBR	000000	812E 1972 2296
UR.THR	000000	814E 1874 1994
USERFWA	042200	586E 1494 1657 3513 3525 3546 3796 4415
USR	000001	768E
USR.FE	000040	799E
USR.DE	000020	800E
USR.PE	000010	801E
USR.RXR	000002	803E
USR.TXE	000004	802E
USR.TXR	000001	804E
VEH.NPC	011024	3231 3254 3307L
VEWHLD	040072	3317 3327 3343 4357 4701L
VIEW	001044	1245L 4569
VIEW1	001055	1249L 3056
VIEW12	011111	3055 3351E
VIEW2	002066	1250 1549L 2579
VIEW3	006000	1556 2579L
VIEW3.	003340	1555 2021L 3238
VIEW3.A	003352	2024 2026L
VIEW3A	007351	1247 3053L
VIEW3A.	007355	2582 3055L
VIEW3B	011127	3354 3357L
VIEW3C	011131	3356 3358L
VIEW4	007363	1553 3058L 3236
VIEW5	010171	2034 3222L
VIEW5.	010212	3227 3230L
VIEW5A	010174	3223L 3239
VIEW6	010224	3229 3235L 3262

MTR90-1 - H/Z-89 MONITOR
Cross Reference Table

#09.02.01.

XREF V1.2.1

Page 125

VIEW6.	010227	3234	3236L
VIEW7	010241	3225	3242L
VIEW7.	010302	3252	3258L
VIEW7..	010305	3257	3259L
VIEW7A	010270	3250	3253L
VIEW8	011032	3053	3314L
VIEW8.	011103	3336	3343L
VIEW8A	011051	3315	3323L
VIEW8B	011054	3321	3325L
VIEW9	003355	1554	2033L 2580
W.RES	000002	352E	1489
HCC	003302	1125	1217 1220 1421 1445 1552 1823 1988L 2357 2371 2379
		2384	2399 2425 2449 2467 2473 2524 2547 2555 2572 2574 2636 2674
		3235	3245 3247 3258 3260 3292 3867 3879 3959 4160 4165 4235 4248
		4254	4274 4296 4308 4373
HCC1	003303	1989L	1991
WCR	005361	2568L	2570
WCR.	005370	1339	1439 2516 2572L 3872 3894 3986 4019 4301
WDN	010104	2698	3084 3137 3156L 3201
WDN1	010111	3160L	3168
WDN2	010137	3164	3173 3177L
WDNA	175000	3158	3181E
WHD	036235	740E	1651
WNH	036271	741E	1650
WRONG	001310	1413	1419E 1427
WTDON1	006032	2613L	2615
Z47	001372	1468E	4607 4629
Z47A	001376	1473E	1530
Z47X	010000	1490	3082L
Z47X.	010011	3092L	3107

21374 bytes free

Appendix B


Octal Definitions

Binary numbers are converted to either hexadecimal or octal numbers for display, depending on the current radix setting. This section describes binary to octal conversion. For a description of binary to hexadecimal and octal to hexadecimal conversion, see Appendix C.

The following table shows binary to octal conversion.

<u>BINARY NUMBER</u>	<u>OCTAL DIGIT</u>
000	0
001	1
010	2
011	3
100	4
101	5
110	6
111	7


Each 8-bit byte is displayed as three octal digits as shown below. The octal numbers lie in the range 000 to 377 for binary numbers in the range 00000000 to 11111111.




Since there are only eight bits in a byte, the most significant octal digit only represents two bits and is therefore displayed as 0 to 3. If you inadvertently enter the octal digits 4 through 7 as the most significant digit, the most significant two bits will be interpreted in modulus 4. That is to say, entering the octal digits 4 through 7 will cause MTR-90 to interpret the digits as 0 through 3, respectively.

Also note that 16-bit numbers, such as memory addresses and certain register contents, are made up of two eight-bit binary numbers. The two groups of eight-bit numbers can be represented by two groups of three octal numbers in the range of 000 to 377. This representation of 16-bit binary numbers is known as offset octal or **split octal**. Where the current radix setting is octal, split octal is used consistently for displays of 16-bit numbers.

Split octal should not be confused with octal. For example:



The lower representation shows true octal representation of a 16-bit binary number. True octal representation is rarely used in standard Zenith Data Systems software. Occasionally, you will see split octal numbers printed with a decimal point separating the upper and lower bytes. For example:



Note that 001.000 follows 000.377.


Appendix C

Hexadecimal Definitions

If the radix setting is hexadecimal, all display addresses are given in hexadecimal. The following table shows binary to hexadecimal conversion.

<u>BINARY NUMBER</u>	<u>HEX DIGIT</u>
0000	0
0001	1
0010	2
0011	3
0100	4
0101	5
0110	6
0111	7
1000	8
1001	9
1010	A
1011	B
1100	C
1101	D
1110	E
1111	F

Each byte is displayed as two hexadecimal digits as shown below. Hexadecimal numbers lie in the range 00 to FF for binary numbers 00000000 to 11111111.



Converting Split Octal to Hexadecimal

To convert a split octal number to hexadecimal, first convert the split octal number to binary. In split octal representation, each of the two bytes of a sixteen-bit number are converted independently to octal. Thus, the most significant split octal digit only represents two bits. The following illustrates the conversion to binary of the split octal value 377.377:


3	7	7
11	111	111

3	7	7
11	111	111

Having converted the split octal number to binary, regroup the bits into nybbles, then convert to hexadecimal. For example:

11	11	1 111	11	11	1	111
<u>1111</u>		<u>1111</u>	<u>1111</u>		<u>1</u>	<u>111</u>
F	F	F	F	F		F

Appendix D

SW501**SW501 Switch Settings**

DIP Switch SW501, located on the lower right of the Z-89/90 CPU logic circuit board, incorporates eight individual bits (0-7) which may be set to either one or zero. These switch settings perform the following functions:

SWITCH SECTION DESCRIPTION

7 6 5 4 3 2 1 0

Selects the device located at port 07CH (174Q). The settings of these two sections are:

X X X X X X 0 0 - Hard-sectorized 5.25-inch disk
 X X X X X X 0 1 - H/Z-47
 X X X X X X 1 0 - H/Z-67 hard disk/floppy
 X X X X X X 1 1 - No device

Selects the device located at port 078H (170Q). The settings of these two sections are:

X X X X 0 0 X X - Soft-sectorized 5.25-inch disk
 X X X X 0 1 X X - H/Z-47
 X X X X 1 0 X X - H/Z-67 Winchester disk-floppy
 X X X X 1 1 X X - No device

Determines whether the primary boot device is at port 07CH (174Q) or at 078H (170Q). The port not configured as primary becomes the secondary device.

X X X 0 X X X X X - Primary boot from device at 07CH (174Q)
 X X X 1 X X X X X - Primary boot from device at 078H (170Q)

Disables/enables memory diagnostic on power up.

X X 0 X X X X X X - Initiate memory test on power up
 X X 1 X X X X X X - Disable memory test on power up

Sets console (H/Z-19) baud rate.

X 0 X X X X X X X - Sets console baud rate at 9600
 X 1 X X X X X X X - Sets console baud rate at 19,200 (not currently supported)

Selects type of boot process

0 X X X X X X X X - Normal boot (normal)
 1 X X X X X X X X - Auto boot on power up or reset (not recommended)

Appendix E

CPU Jumpers

MEMORY JUMPERS

The memory decode ROM is located at U517. An older ROM (#442-42) allowed for a maximum of 48K of memory. A newer ROM allows for up to 64K of memory. Memory jumpers should be set as follows:

Older CPU boards have four jumpers.

When you are using the old ROM (#444-42):

	<u>JJ501</u>	<u>JJ502</u>	<u>JJ503</u>	<u>JJ504</u>
16K	0	0	0	0 (or B)
32K	1	0	0	0 (or B)
64K	0	1	0	0 (or B)

When you are using the new ROM (#444-66):

16K	0	0	**	0 (or B)
32K	1	0	**	0 (or B)
48K	0	1	**	0 (or B)
64K*	1	1	**	0 (or B)

* Requires WH-88-16 Accessory Board

** A jumper is required between the center pin of JJ503 and pin 17 of P509 — or P4 of WH-88-16 (which connects to pin 17 of P509). This jumper was permanently installed on some boards.

Newer CPU boards have three jumpers.

They also have the newer decoder ROM, and the jumper wire is part of the circuit foils. These boards should not be used with the old ROM (#444-42). The jumpers are set as follows:

	<u>JJ501</u>	<u>JJ502</u>	<u>JJ503</u>
16K	0	0	0 (or B)
32K	1	0	0 (or B)
48K	0	1	0 (or B)
64K	1	1	0 (or B)

SECONDARY ADDRESS DECODER — U516

MTR-90 requires the use of IC #444-83 at location U516 on the left-hand side of the CPU circuit board. Four nearby jumpers (JJ505, JJ506, JJ507, and JJ508 on older units; or JJ504, JJ505, JJ506, and JJ507 on newer units) must be set as follows:

Older Units	<u>JJ505</u>	<u>JJ506</u>	<u>JJ507</u>	<u>JJ508</u>
Newer Units	<u>JJ504</u>	<u>JJ505</u>	<u>JJ506</u>	<u>JJ507</u>
	1	*	1	1 (or B)

* MTR-90 requires a jumper (#134-1159) from the center pin of JJ506 (or JJ505) to pin 14 of P508.